



Toshiba RAS-10 Owner's Manual

1
2
3
4

--

•

Bookmarks

--

Quick Links

[Download this manual](#) See also: [Owner's Manual](#), [Installation Manual](#)



OWNER'S MANUAL

AIR CONDITIONER (SPLIT TYPE)
For general public use

Indoor unit

RAS-10, 13, 16 SKV Series

Outdoor unit

RAS-10, 13, 16 SAV Series

LIAN
MA
TOSHIBA



[Next Page](#)

1
2
3
4

Related Manuals for Toshiba RAS-10

[Air Conditioner Toshiba 16N3KV2-E1 Installation Manual](#)

(276 pages)

[Air Conditioner Toshiba RAS-B10 Series Installation Manual](#)

(68 pages)

[Air Conditioner Toshiba RAS-10 Owner's Manual](#)

(48 pages)

[Air Conditioner Toshiba RAS-10 Installation Manual](#)

(28 pages)

[Air Conditioner Toshiba 24N3KV2 Series Owner's Manual](#)

(26 pages)

[Air Conditioner Toshiba RAS-B10 Owner's Manual](#)

Split type; r32 or r410a inverter (20 pages)

[Air Conditioner Toshiba RAS-10 Owner's Manual](#)

18ufv series, 18sav series (19 pages)

[Air Conditioner Toshiba RAS-107 Owner's Manual](#)

Air conditioner (18 pages)

[Air Conditioner Toshiba RAS-13BKV-E Installation Manual](#)

(15 pages)

[Air Conditioner Toshiba RAS-10 Owner's Manual](#)

(12 pages)

[Air Conditioner Toshiba RAS-B10 SERIES Installation Manual](#)

(10 pages)

[Air Conditioner Toshiba RAS-10, 13SKPX Series Owner's Manual](#)

Split type (8 pages)

[Air Conditioner Toshiba RAS-B10 Owner's Manual](#)

(8 pages)

[Air Conditioner Toshiba RAS-B10 Owner's Manual](#)

Split type (6 pages)

[Air Conditioner Toshiba RAS-10 NAH Series Owner's Manual](#)

(5 pages)

[Air Conditioner Toshiba RAS-10 Series Owner's Manual](#)

Indoor and outdoor unit (5 pages)

Summary of Contents for Toshiba RAS-10

[Page 1](#) O WNE R'S MANUA L AIR CONDITIONER (SPLIT TYPE) For general public use ENGL ISH Indoor unit SPANISH RAS-10, 13, 16 SKV Series FRENCH Outdoor unit RAS-10, 13, 16 SAV Series ITALIAN GERMAN PORTUGUESE POL ISH CZECH CROATIAN HUNGARIAN DUTCH...

[Page 2](#) å gi deg alternativ kontakt med "ONE-TOUCH" av knappen. Hvis du foretrekker andre innstillinger kan du velge mellom mange andre driftsfunksjoner på Toshiba- 1 Hi POWER (Grønn) Modeller: RAS-10, 13, 16SKVR-E, RAS-13, 16SKV-E enheten din.

[Page 3](#) • Ikke bruk bensin, fortynner, poleringsmiddel eller kjemisk behandlede støvkluter. fjernkontrollen til å bli A. Rengjøring av luftionisator (Kun hver sjetten måned) (RAS-10, 13,

16SKVR-E Kun) 2. Fjernkontroll A har ikke "A" visning. 1. Slå av klimaanlegget ved bruk av fjernkontrollen og strømforsyningen.

[Page 4](#) DECLARATION OF CONFORMITY We, TOSHIBA CARRIER (THAILAND) CO., LTD., 144/9 Moo 5, Bangkadi Industrial Park, Tivanon Road, Tambol Bangkadi, Amphur Muang, Pathumthani, 12000, Thailand, declare under our responsibility that the product, Household split type Room Air Conditioner, to which this declaration relates is in conformity with the provisions of Council Directive 89/336/EEC Electromagnetic Compatibility and 73/23/EEC Low Voltage Directive.