



Asus Xonar D2 Installation Manual

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68

69
70
71
72
73
74
75
76
77
78
79
80

•

Quick Links

[Download this manual](#) See also: [User Manual](#)



ASUS

Xonar D2 **ASUS**®



audio card

ASUS *Installation Guide*



ASUS Xonar D2 Installation Guide

[Next Page](#)

- 1
- 2
- 3
- 4
- 5

Related Manuals for Asus Xonar D2

[Sound Card Asus Audio Card Xonar D2 User Manual](#)

Asus xonar d2 audio card user manual (84 pages)

[Sound Card Asus Xonar D2 Installation Manual](#)

(71 pages)

[Sound Card Asus Xonar D2 Test Manual](#)

7.1 channel audio card 192khz/24bit duplexhd featuring dolby and dts technologies for home entertainment, rmaa 6.0.5 test guide and results (17 pages)

[Sound Card Asus PCI Express Audio Card Xonar DX User Manual](#)

Asus network adapter user's manual (80 pages)

[Sound Card Asus Audio Card Xonar D2X Quick Installation Manual](#)

Asus audio card quick installation guide (71 pages)

[Sound Card Asus Xonar D2X User Manual](#)

Masterpiece audio card for home theater & gaming in your pci express slot (88 pages)

[Sound Card Asus XONAR D2X - Sound Card - 192 kHz Quick Installation Manual](#)

Asus xonar d2x quick installation guide (10 pages)

[Sound Card Asus Xonar D2X User Manual](#)

(20 pages)

[Sound Card Asus XONAR ESSENCE - Sound Card - 192 kHz User Manual](#)

User manual (49 pages)

[Sound Card Asus Xonar Essence STX Reports Manual](#)

Audio precision test report (10 pages)

[Sound Card Asus Xonar D1 User Manual](#)

Dolby home theater technologies & richest gaming audio effects for best pc audio upgrade (72 pages)

[Sound Card Asus Xonar DG User Manual](#)

Pci 5.1 & headphone amp audio card (58 pages)

[Sound Card Asus Xonar DGX User Manual](#)

Pcie 5.1 & headphone amp audio card (58 pages)

[Sound Card Asus Xonar DS User Manual](#)

(54 pages)

[Sound Card Asus Xonar DSX User Manual](#)

7.1 pcie audio card (53 pages)

[Sound Card Asus Xonar U3 User Manual](#)

Mobile headphone amp usb soundcard (38 pages)

Summary of Contents for Asus Xonar D2

[Page 1](#) ASUS Xonar D2 ® audio card Installation Guide ASUS Xonar D2 Installation Guide...

Page 2: Installation Requirements

ASUS Xonar D2 installation ® Installation requirements To ensure a successful installation of the Xonar D2 audio card, your computer must meet the following requirements: • IBM compatible PC with one PCI 2.1 (or higher) compatible slot for the audio card •...

Page 3: Card Installation

Align and insert the Xonar card into the PCI slot until it seats in place. Make sure the goldfingers are properly inserted to the slot. Secure the bracket screw that holds the Xonar D2 audio card in place. Refer to the picture below for the bracket screw hole.

Page 4: Driver Installation

Driver installation After installing the Xonar D2 audio card on your computer, you need to install the device driver that enables the Xonar D2 audio card to work with Windows operating system. The version and content of the driver CD are subject to change without notice.

Page 5: Connecting Speakers

Connecting speakers For Analog Spakers 2 Speakers 2.1 Speakers ASUS Xonar D2 Installation Guide...

[Page 6](#) 4 Speakers 4.1 Speakers ASUS Xonar D2 Installation Guide...

[Page 7](#) 5.1 Speakers 6.1 Speakers ASUS Xonar D2 Installation Guide...

Page 8: Spdif Out

You can also use a coaxial cable for a S/PDIF connection. Just plug the coaxial RCA male connector to the S/PDIF-Out combo jack and connect the other end into the coaxial S/PDIF input on your decoder. ASUS Xonar D2 Installation Guide...

Page 9 You can also use a coaxial cable for a S/PDIF digital connection. Just plug the coaxial RCA male connector to the S/PDIF-In combo jack and connect the other end into the coaxial S/PDIF output on the player. Connecting headphone / microphone ASUS Xonar D2 Installation Guide...

[Page 10](#) Connecting Line-In audio sources ASUS Xonar D2 Installation Guide...

[illegible][illegible]

Page 13

[Page 14](#)

[illegible]

Page 16 4 4.1

Page 17 5.1 6.1

Page 18 7.1 SPDIF 00 000000 TOSL N 0 000000 S/D Out 00000000 000000 TOSL N 0 00000000 S/D Out 00000000 000000 TOSL N 0 000000 S/D Out 00000000 000000 000000 TOSL N 0 00000000 S/D Out 00000000 00000000 R 0 00000000 00000000 000000 S/D Out 00000000 00000000 00000000 000000 S/D Out 00000000 00000000 00000000 00000000...

[Page 19](#)

Page 20 Line-In

Page 21 ® ASUS Xonar D2 □□ □□□□ □□

 ...

Page 22 Xonar D2 1.1

Page 23

[illegible]

[Page 25](#)

[Page 26](#)

[Page 27](#)

Page 28

Out: [REDACTED] F [REDACTED]

[illegible]

[Page 30](#)

Page 31 ASUS Xonar D2 ® 繁體中文 安裝 ASUS Xonar D2 繁體中文...

[Page 32](#) ※ 580 MB • CD-ROM DVD-ROM • DTS • ASUS Xonar D2 • ASUS Xonar D2 CD • ASUS Xonar D2 ...

[illegible][illegible]

Page 35 2.1 ASUS Xonar D2

Page 36

[Page 37](#) 5.1 ASUS Xonar D2 安裝說明書... 6.1 安裝說明書... 7.1 安裝說明書...

[Page 38](#)

Page 39 S/PDIF 00 CD 0000 MD 0000 TOSLINK 000000 S/PDIF0000000000000000 TOSLINK
0 0000 MD/CD/DVD 000000 S/PDIF 0000000000000000 00 S/PDIF 0000000000000000000000
000000 0 RCA 00000000 S/PDIF00000000 0000000000 00000000000000 S/PDIF 00000000
00 000 0/00000000 000 000 00 000 0 ASUS Xonar D2 00000000...

Page 40 CD MP3 ASUS Xonar D2

Page 41 ASUS Xonar D2 ® 华硕 Xonar D2 华硕 Xonar D2 华硕 Xonar D2...

[illegible]

[Page 43](#) 00000 0000 0000 00000000. 0000000 00 00 PCI 0000 0000000. Xonar 0000 PCI 0000 0000 0 0000 00 0
0 0000 0000 0000 0 00000000 00000000. 0000 0000 Xonar D2 0000 0000 00000000. 00 0000 0000 0000 00000000. 0 0
0...

Page 44 0000 00 Xonar D2 000 000 0000 0000 0 Windows 00 00000 Xonar D2 000 0000 0000 00 0

Page 62 Yüksek bağlılıkta Kartın Ultra sesini dinlemek için Dolby Dijital veya DTS dekodeerleri ile birlikte yüksek kalitede kulaklık, elektrikli analog hoparlörler veya dijital hoparlörler Kurulum

öncesi, aşağıdaki öğeler için ASUS Xonar D2 ses kartınızın paketini kontrol edin: • ASUS Xonar D2 ses kartı...

[Page 63](#) Boş PCI yuvasını anakartta bulun. Xonar kartını PCI yuvasında hizalayın ve yerine oturuncaya kadar yerleştirin. Altın parmakların yuvada düzgün yerleştirildiğinden emin olun. Xonar D2 ses kartını yerinde tutan destek vidasını sabitleyin. Destek vidasının deliği için aşağıdaki resme bakınız. Şasi kapağını geri yerleştirin.

[Page 64](#) çalışan Xonar D2 ses kartını etkinleştiren aygıt sürücüsünü kurmanız gereklidir. Sürücü CD'sinin sürümü ve içeriği önceden haber verilmeden değiştirilebilir. Daha önceden ASUS Xonar D2 ses kartı kurulmuş ise sürücü kurulumu sırasında veya öncesinde Bulunan Yeni Donanım Sihirbazının penceresi açılabilir. Aşağıdaki şekle bakınız.

[Page 65](#) Hoparlörlerin bağlanması Analog Hoparlörler İçin 2 Hoparlörler 2.1 Hoparlörler ASUS Xonar D2 Kurulum Kılavuzu...

[Page 66](#) 4 Hoparlörler 4.1 Hoparlörler ASUS Xonar D2 Kurulum Kılavuzu...

[Page 67](#) 5.1 Hoparlörler 6.1 Hoparlörler ASUS Xonar D2 Kurulum Kılavuzu...

[Page 68](#) MD/CD/DVD çalarınızın S/PDIF giriş portunu TOSLINK optik kablosunun bulunduğu optik adaptöre takın Ayrıca S/PDIF bağlantısı için koaksiyal kablo da kullanabilirsiniz. Koaksiyal RCA erkek konektörünü S/PDIF-Out combo jakına takın ve diğer ucunu dekoderin koaksiyal S/PDIF girişine takın. ASUS Xonar D2 Kurulum Kılavuzu...

[Page 69](#) MD/CD/DVD çalarınızın S/PDIF çıkış portunu TOSLINK optik kablosu bulunan optik adaptöre takın Ayrıca S/PDIF dijital bağlantısı için koaksiyal kablo da kullanabilirsiniz. Koaksiyal RCA erkek konektörünü S/PDIF-Girişi combo jakına takın ve diğer ucunu çalardaki koaksiyal S/PDIF çıkışına takın. Kulaklığın / mikrofonun takılması ASUS Xonar D2 Kurulum Kılavuzu...

[Page 70](#) Hat Girişi ses kaynaklarının bağlanması ASUS Xonar D2 Kurulum Kılavuzu...

[Page 71](#) ASUS Xonar D2...

[Page 72](#) ASUS Xonar D2...

[Page 73](#) ASUS Xonar D2...

[Page 74](#) ASUS Xonar D2...

[Page 75](#) ASUS Xonar D2...

[Page 76](#) ASUS Xonar D2...

[Page 77](#) ASUS Xonar D2...

[Page 78](#) ASUS Xonar D2...

[Page 79](#) ASUS Xonar D2...

[Page 80](#) ASUS Xonar D2...