



# Table Of Contents - Toshiba D-R4SU Owner's Manual



1
Table Of Contents
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17

18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67

68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92  
93  
94  
95  
96  
97  
98  
99  
100  
101  
102  
103  
104  
105  
106  
107  
108  
109  
110  
111  
112  
113  
114  
115  
116  
117

118  
119  
120  
121  
122  
123  
124  
125  
126  
127  
128  
129  
130  
131

• PAGE

2

OF 131 GO

•

## Table of Contents

- 

## Bookmarks

--







Introduction

# of Contents

## [Introduction](#)

### [Caution for safety](#)

[About this product](#) ..... 5

[Choosing a disc](#) ..... 6

[Index to parts and controls](#) ..... 12

..... 12

[Front panel](#)

[Rear panel](#) ■ ..... 14

[Remote control](#) ■ ..... 18

[Display](#) ■

**Before operating this recorder** ..... 20

**Key operation - EASY NAVI & QUICK MENU** .. 23

## **Recording**

### **Before recording**

[Initializing a DVD-RAM/RW disc \(Logical format\)](#)

[DVD-RAM physical format](#)

[Entering characters](#)

### **Selecting a disc according to purposes of use**

**(DVD-RAM/DVD-R/RW)** ..... 32

### **Setting for recording on a DVD-R/RW disc in**

**Video mode** ..... 33

**Recording a TV program** ..... 34

**Recording an external source** ..... 38

**Programming a recording** ..... 41

**Others** ..... 47

[To delete recorded content](#)

[To protect recorded content](#)

[Technical information](#)

## **Playback**

**Information on playback** ..... 50

**Playing recorded contents** ..... 51

**Playing a DVD video disc** ..... 55

[Locating a title using the top menu](#)

### **Pausing a TV broadcast to resume later**

**(Pause TV)** ..... 57

### **Playing a TV program currently being**

**recorded (Chase Play)** ..... 58

Downloaded From Disc-Player.com Toshiba Manuals

## **2**

..... 16

..... 29

..... 30

..... 47

..... 47

..... 48

..... 56

**Playing at various speeds** ..... 59

[Playing in fast reverse or fast forward](#)

[Skipping to the next/previous chapter or track](#)

[Playing in slow-motion](#)

[Playing frame by frame](#)

[Viewing still pictures](#)

[\(Playing a disc that contains still pictures\)](#)

**Locating by entering the number** ..... 62

[Locating by entering the number of a desired](#)

..... 62

[section](#)

[Locating a specific point by entering its elapsed time](#)

[\(Time Search\)](#)

..... 63

ManualsLib.com

<a href="#">Selecting the camera angle</a> .....	64	
<a href="#">Selecting subtitles</a> .....	65	
<a href="#">Zooming a picture</a> .....	66	
<a href="#">Selecting the sound</a>		
....	28	
<a href="#">Viewing JPEG files</a>		
JPEG files compatibility .....		
<a href="#">Playing MP3/WMA files</a> .....	72	
Playable files		
.....	73	
<a href="#">Pausing a TV broadcast</a>		■
<a href="#">(Freeze function)</a> .....	74	
<a href="#">Checking the current status and settings</a> .....	75	
Operational status and setting details		
Using the time bar		
<a href="#">Functions in Quick Menu</a> .....	77	
<a href="#">Editing</a>		■
<a href="#">Before editing</a> .....	82	■
<a href="#">Creating chapters</a> .....	84	
<a href="#">Playlist editing</a>		
<a href="#">(Collecting desired scenes)</a> .....	89	
<a href="#">Creating thumbnails</a>		
<a href="#">(Changing the picture on CONTENT MENU)</a> ..	93	■
<a href="#">High speed dubbing</a>		■
<a href="#">(Dubbing only a specified part)</a> .....	96	■
<a href="#">Deleting selected items</a>		
<a href="#">(Deleting multiple specified parts)</a> .....	98	■
<a href="#">DVD-Video finalizing process</a> .....	100	
.....	59	
.....	60	■
.....	60	
.....	61	
.....	61	■
.....	75	
.....	76	■
71		—

[Previous Page](#)  
[Next Page](#)

1  
2  
3  
4  
5  
6

Quick Links:

[Remote Control](#)

[Before Recording](#)

[Recording a Tv Program](#)

[Recording an External Source](#)

## Related Manuals for Toshiba D-R4SU

[DVD Recorder Toshiba D-R4SU Owner's Manual](#)

Dvd video recorder (195 pages)

[DVD Recorder Toshiba D-R4SC Owner's Manual](#)

Dvd video recorder (131 pages)

[DVD Recorder Toshiba D-R4SU Owner's Manual](#)

Dvd video recorder (53 pages)

[DVD Recorder Toshiba D-R4SU Service Manual](#)



Dvd video recorder (22 pages)

[DVR Toshiba D-KR4 Owner's Manual](#)

Toshiba d-kr4: installation guide (52 pages)

[DVR Toshiba D-R4 Specifications](#)

Digital video recorder (2 pages)

[DVR Toshiba DR420 Quick Manual](#)

Dvd video recorder (2 pages)

[DVR Toshiba D-R410KU Owner's Manual](#)

D-r410ku user's guide (101 pages)

[DVR Toshiba D-R410KU Service Manual](#)

Toshiba d-r410ku dvd video recorder service manual (66 pages)

[DVR Toshiba D-R420KU Owner's Manual](#)

D-r420ku user's guide (103 pages)

[DVR Toshiba DR420KU Owner's Manual](#)

Dvd video recorder (111 pages)

[DVR Toshiba DR430KU Owner's Manual](#)

Dr430ku user's guide (103 pages)

[DVR Toshiba DR430KU Owner's Manual](#)

Dvd video recorder (110 pages)

[DVR Toshiba D-R560KU Owner's Manual](#)

D-r560ku user's guide (117 pages)

[DVR Toshiba D-R550 Owner's Manual](#)

Dvd video recorder (125 pages)

[DVR Toshiba DR570KU Owner's Manual](#)

Toshiba dr570ku dvd video recorder owner's manual (123 pages)

## Related Content for Toshiba D-R4SU

[v632uk Changing The Preset Station Table](#)

Toshiba v632uk

[HDR5010KB Package Contents](#)

Toshiba HDR5010KB

[D-KVR20KU Structure Of Disc Contents](#)

Toshiba D-KVR20KU

[RD-XS35SU Structure Of Disc Contents](#)

Toshiba RD-XS35SU

[RD-XS32SB Structure Of Disc Contents](#)

Toshiba RD-XS32SB

[Surveillix XVSv16-240-X Maximum Fps Table](#)

Toshiba Surveillix XVSv16-240-X

[DR420KU Table Of Contents](#)

Toshiba DR420KU

[DR430KU Table Of Contents](#)

Toshiba DR430KU

This manual is also suitable for:

[D-r4scD-kr4su](#)