

TOSHIBA

Toshiba HGN-6B Using Instruction Manual

1
2
3
4
5
6
7
8

--

•

[Table of Contents](#)

•

Bookmarks

--

Table of Contents

[1 Parts and Functions](#)

[2 Maintenance](#)

[3 Safety Caution](#)

[4 Specifications](#)

[Download this manual](#)



TOSHIBA HOTPLATE

Using Instruction Manual

Model: HGN-6B

HGN-6D

HGN-6BI

HGN-6DI

•

TOSHIBA

Thank you for buying Toshiba hotplate today.

•

To apply this product safely and properly, please read the



instruction thoroughly to well understand before operation.

•

After reading, please keep this manual handy for operation purposes.

NHNL12530000000 (Cover)

(FOR HOUSEHOLD USE)

1

19/3/08, 13:13

[Table of Contents](#)

[Next Page](#)

1
2
3
4
5

Summary of Contents for Toshiba HGN-6B

[Page 1](#) Model: HGN-6B HGN-6D HGN-6BI HGN-6DI • Thank you for buying Toshiba hotplate today. • To apply this product safely and properly, please read the instruction thoroughly to well understand before operation. • After reading, please keep this manual handy for operation purposes.

[Page 2: Parts And Functions](#)

PARTS AND FUNCTIONS For the first time operation, please remove the paper of precautions and the papers between the heating plate, the metal plate and the dimple plate. Lid Knob (For grilling) Dimple Plate Metal Plate Handle Protective Frame It is detachable for cleaning Body Heating Plate...

[Page 3](#) PROPER OPERATION Do not leave a pin or d For the first time you use this product, the smoke and the smell may occur. Please be advised that these are on the magnetic plug. not abnormal. Such smoke and smell will not affect It may cause an electric shoc the operation at all.

[Page 4](#) CAUTION During or right after the operation, do not touch Do not leave a pin or dust the hottest parts such as a lid, a dimple plate, or on the magnetic plug. a metal plate. It may cause an electric shock, Such parts may cause burns due to the high a short circuit, and fire.

[Page 5: Maintenance](#)

MAINTENANCE • Maintain the plate every time after CAUTION unplugging. • Always keep the dimple plate, the metal Maintain the plate after plate, and the lid clean. • In case of using cleaner, please use the cooling it off. kitchen detergent. Do not use cleanser or a Touching the hot part can Maintain after it scrubbing brush, whitening components,...

[Page 6: Safety Caution](#)

It may cause fire and electric shock. It may cause electric shock and injury. For repair, please contact the shop you purchased or Toshiba repair information center. Remove is prohibited. Wet Hand is prohibited. Hold the tip of the power cord when connecting.

[Page 7](#) WARNING Don't allow children to touch, keep Don't let the product wet or spray/ it out of reach from the small sprinkle the water on the product. children. And don't set the hotplate while it is wet. It may cause burn, electric shock, and injury.

[Page 8: Specifications](#)

CAUTION Do not remove the dimple plate from the frame. Don't touch the lid, dimple plate or It may cause fire, burns and the change of the heat sensor while using or right color. after using. You may get burned from the heat. As the lid knob may be hot, don't touch it by bare hands.