

TOSHIBA

Toshiba D-VR4SU Service Manual

Hi-fi vcr & dvd video recorder

1
2
3
4
5
6
7
8
9

--

•

[Table of Contents](#)

•

Bookmarks

--

Quick Links

[Download this manual](#) See also: [Service Manual](#), [Owner's Manual](#)



SERVICE MANUAL

Hi-Fi VCR & DVD VIDEO

RECORDER

TOSHIBA

Use this service manual together with the original service manual of D-VR4SU/SC. (File No. 810-200521)



D-VR4SU TOSHIBA D-VR4SC

- SUMMARY -

FILE NO. 813-200503

Revised. 01

Nov., 2005 (OR)



[Table of Contents](#)

[Next Page](#)

1
2
3
4
5

Related Manuals for Toshiba D-VR4SU

[DVR Toshiba D-VR4SU Service Manual](#)

Hi-fi vcr & dvd video recorder (166 pages)

[DVD VCR Combo Toshiba D-VR4XSU Owner's Manual](#)

Hi-fi vcr & dvd video recorder (92 pages)

[DVD VCR Combo TOSHIBA D-VR4SU Owner's Manual](#)

Hi-fi vcr & dvd video recorder (88 pages)

[DVD VCR Combo Toshiba D-VR4 Owner's Manual](#)

Hi-fi vcr & dvd video recorder (88 pages)

[DVD VCR Combo Toshiba D-VR4 Specification Sheet](#)

Toshiba specification sheet (2 pages)

[DVD VCR Combo Toshiba D-VR610KU Owner's Manual](#)

Dvd video recorder / video cassette recorder (126 pages)

[DVD VCR Combo Toshiba DVR610 - DVD/ VCR Combo Service Manual](#)

Dvd video recorder /video cassette recorder (87 pages)

[DVD VCR Combo Toshiba DVR670KU Owner's Manual](#)

Dvd video recorder / video cassette recorder (124 pages)

[DVD VCR Combo Toshiba D-VR600 Owner's Manual](#)

Hi-fi vcr & dvd video recorder (80 pages)

[DVD VCR Combo Toshiba D-VR650KU Owner's Manual](#)

Dvd video recorder / video cassette recorder (123 pages)

[DVD VCR Combo Toshiba D-VR3SU Owner's Manual](#)

Dvd recorder-vcr (124 pages)

[DVD VCR Combo Toshiba DVR670KU Owner's Manual](#)

Dvd video recorder/video cassette recorder (126 pages)

[DVD VCR Combo Toshiba DVR20KB Owner's Manual](#)

Dvd / video cassette recorder (80 pages)

[DVD VCR Combo TOSHIBA DVR70DTKF2 Owner's Manual](#)

Dvd / video cassette recorder (80 pages)

[DVD VCR Combo Toshiba DVR19DTKB Owner's Manual](#)

Dvd/video cassette recorder (80 pages)

[DVD VCR Combo Toshiba D-VR50KF Service Manual](#)

Dvd video recorder /video cassette recorder (127 pages)

Summary of Contents for Toshiba D-VR4SU

Page 1 FILE NO. 813-200503 Revised. 01 SERVICE MANUAL Hi-Fi VCR & DVD VIDEO RECORDER D-VR4SU D-VR4SC - S U M M A R Y - Use this service manual together with the original service manual of D-VR4SU/SC. (File No. 810-200521) Nov., 2005 (OR)

Page 2: Removal Of Mechanical Parts And P.c. Boards

1-3: FLAP (Refer to Fig. 1-3) Open Flap to 90° and flex in direction of arrow (A), at the CP504 CP8302 CP8303 same time slide in direction of arrow (B). Fig. 1-4 CP8301 Then lift in direction of arrow (C). B1-1 D-VR4SU/D-VR4SC...

[Page 3: Service Mode List](#)

Refer to the "WHEN REPLACING EEPROM (MEMORY) IC". DVD mode Releasing of PARENTAL LOCK. STOP 2 sec. (No disc) Refer to the "PARENTAL CONTROL - RATING LEVEL". Region setting. DVD mode STOP 2 sec. Refer to the "WHEN REPLACING NEW DVD LOADER". (STOP) C2-1 D-VR4SU/D-VR4SC...

[Page 4: Servicing Fixtures And Tools](#)

In case of using a cassette tape, press the EJECT button to insert or eject a cassette tape. Turn on the power and re-check the cable before checking the trouble points. When you servicing with connection of DVD, perform the operations above step 2 to step 3. D1-1 D-VR4SU/D-VR4SC...

[Page 5: Chassis Replacement Parts List](#)

H5001 AE004714 1523Q91004 HEAD,AUDIO CONTROL VTR-1X2RPE22-772 H5002 AD301676 1543Q02014 HEAD (FULL ERASE) VTR-1X2ERS11-154 M101 AE005552 1596S98002 MOTOR,LOADING MDB2B66B M2001 AE005853 1510S98044 CAPSTAN DD UNIT F2QVB73B M2003 AE003673 1589S11020 MICRO MOTOR I2OAL34 UN4001 AE006680 A2F401H500 CYLINDER UNIT ASS'Y A2F401H500 K2-1 D-VR4SU...

[Page 6](#) CHASSIS REPLACEMENT PARTS LIST Location No. TSB P/N Reference No. Description
AE006965 A2G001H420A DECK ASSY A2G001H420A AE005514 85OA400245 PINCH ROLLER
BLOCK VA2 AE006679 85OP900759 LEVER,FLAP(S) BZ710193 85OP200290 BELT,CAPSTAN (S)
BZ710515 85OP600581 WORM AE005919 85OP500091 BASE,AC HEAD BZ710112 85OP800324
SPRING,AC HEAD AE006676 85OA000529 MAIN CHASSIS ASS'Y(S)

[Page 7: Electrical Replacement Parts List](#)

ELECTRICAL REPLACEMENT PARTS LIST D-VR4SU MFR'S VERSION A MFR'S VERSION B REF. NO.
PART NO. DESCRIPTION TSB P/N PART NO. DESCRIPTION TSB P/N CAUSE R3055 R803R9473J 47K
OHM 1/16W AE001797 DELETE MICON VERSION UP. R3056 R803R9223J 22K OHM 1/16W
AE001891...

[Page 8](#) D-VR4SC MFR'S VERSION A MFR'S VERSION B REF. NO. PART NO. DESCRIPTION TSB
P/N PART NO. DESCRIPTION TSB P/N CAUSE R3055 R803R9473J 47K OHM 1/16W AE001797
DELETE MICON VERSION UP. R3056 R803R9223J 22K OHM 1/16W AE001891 DELETE R3057
R803R9683J 68K OHM 1/16W AD302291 DELETE R3058...

[Page 9](#) TOSHIBA CORPORATION 1-1, SHIBAURA 1-CHOME, MINATO-KU, TOKYO 105-8001,
JAPAN...

This manual is also suitable for:

D-vr4sc