

Manual Operation - Sanyo SAP-URV246EH Instruction Manual

Inverter-controlled split system air conditioner

1

2

Table Of Contents

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32

--

•

[Table of Contents](#)

-

Troubleshooting

•

Bookmarks



2. Manual Operation

(NOT ACTIVE FOR MODELS
URV-FRV)

Operation with the Remote Control Unit (continued)


STEP 4

STEP 5

Check that the circuit breaker on the power panel is turned on and that the

NOTE


operation selector of the indoor unit is in the ON position.

If the automatic operation settings of the unit do not meet your needs, press  the setting buttons as described below and change the settings as desired.

STEP 1

STEP 2

STEP 3



STEP 4

STEP 5

To stop the air conditioner, press the ON/OFF operation button again.

STEP 2

STEP 3

STEP 1

Press the MODE selector button and select the desired mode.

For heating operation

For dehumidifying operation

For cooling operation

For fan only operation

To start the air conditioner, press the ON/OFF operation button.

Press the TEMP. setting buttons to change the temperature setting to the desired temperature.

Adjustable temperature range:

30 °C max.

16 °C min.

Set the FAN SPEED selector button to the setting you want.

Press the FLAP button and set the airflow direction as desired.

(Refer to "Adjusting the Airflow Direction" on page 21.)

→

→

→


→

or

86 °F max.

60 °F min.

15



ManualsLib.com

Table of Contents

[Previous Page](#)
[Next Page](#)

1
...
12
13
14
15
16
17
18
19

Quick Links:

[Features](#)

[Product Information](#)

[Alert Symbols](#)

[Table of Contents](#)

[Electrical Requirements](#)

[Troubleshooting](#)

Related Manuals for Sanyo SAP-URV246EH

[Air Conditioner Sanyo SAP-URV96EH Installation Instructions Manual](#)

Split system (47 pages)

[Air Conditioner Sanyo UR9X Installation Instructions Manual](#)

Split system air conditioner (52 pages)

[Air Conditioner Sanyo SAP-KRV9AG Instruction Manual](#)

Inverter-controlled split system air conditioner (22 pages)

[Air Conditioner Sanyo SAP-KRV123EH Technical & Service Manual](#)

Dc inverter split system air conditioner (77 pages)

[Air Conditioner Sanyo SAP-CRV93EHN Technical & Service Manual](#)

Dc inverter split system air conditioner (77 pages)

[Air Conditioner Sanyo SAP-K18AM Instruction Manual](#)

Split system air conditioner (37 pages)

[Air Conditioner Sanyo SAP-CMRV1424EH Technical & Service Manual](#)

Dc inverter multi-system air conditioner (114 pages)

[Air Conditioner Sanyo SAP-KRV96EHDS Technical & Service Manual](#)

Dc inverter split system air conditioner (77 pages)

[Air Conditioner Sanyo SAP-KMRV74EH Installation Instructions Manual](#)

Inverter multi split system air conditioner (28 pages)

[Air Conditioner Sanyo SAP-KMRV74EH Installation Instructions Manual](#)

Inverter split system air conditioner (24 pages)

[Air Conditioner Sanyo SAP-K91GJA \(?\) Technical & Service Manual](#)

Multi-split system air conditioner (50 pages)

[Air Conditioner Sanyo SAP-K92A Technical & Service Manual](#)

Multi-split system (39 pages)

[Air Conditioner Sanyo SAP-K161GJA Technical & Service Manual](#)

Split system air conditioner (86 pages)

[Air Conditioner Sanyo SAP-K77GHAX Technical & Service Manual](#)

(164 pages)

[Air Conditioner Sanyo SAP-C302AH-S Technical & Service Manual](#)

(45 pages)

[Air Conditioner Sanyo SAP-K71GJA-S Technical & Service Manual](#)

(81 pages)

Related Content for Sanyo SAP-URV246EH

[SAP-K301AH Manual Operation](#)

Sanyo SAP-K301AH

[SAP-KRV91EH Manual Operation](#)

Sanyo SAP-KRV91EH

[SAP-K181AHA-S Manual Operation](#)

Sanyo SAP-K181AHA-S

[SAP-K91AHA Manual Operation](#)

Sanyo SAP-K91AHA

[KHS1872 + CH1872 Manual Operation](#)

Sanyo KHS1872 + CH1872

[XS1271 Manual Operation](#)

Sanyo XS1271

[COOL Manual Operation](#)

Sanyo COOL

[SAP-KRV96EHDS Manual Operation](#)

Sanyo SAP-KRV96EHDS

This manual is also suitable for:

[Sap-urv96ehSap-urv186ehSap-ftvr246ehSap-ftvr186ehSap-urv126ehSap-ftvr126h](#) ... [Show all](#)

[Save PDF](#)