

Installation Location; Electrical Requirements; Safety Instructions - Sanyo SAP-URV246EH Instruction Manual

Inverter-controlled split system air conditioner

1
2
Table Of Contents
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32

--

•

[Table of Contents](#)

-

Troubleshooting

•

Bookmarks



CAUTION

4

Installation Location

• **We recommend that this air conditioner be installed properly by qualified installation technicians in accordance with the Installation Instructions provided with the unit.**

• Before installation, check that the voltage of the electric supply in your home or office is the same as the voltage shown on the nameplate.

• **Do not install this air conditioner where there are fumes or flammable gases, or in an extremely humid space such as a**



WARNING

greenhouse.

Do not install the air conditioner where excessively high heat-generating objects are placed.

Avoid:

To protect the air conditioner from heavy corrosion, avoid installing the outdoor unit where salty sea water can splash directly onto it or in sulphurous air near a spa.

Electrical Requirements

1. All wiring must conform to the applicable local codes. Consult your dealer or a qualified electrician for details.



WARNING

2. Each unit must be properly grounded with a ground (or earth) wire or through the supply wiring.

3. Wiring must be done by a qualified electrician.

Safety Instructions

Read this Instruction Manual carefully before using this air conditioner. If you still have any difficulties or problems, consult your dealer for help.

This air conditioner is designed to give you comfortable room conditions. Use this only for its intended purpose as described in this Instruction Manual.

Never use or store gasoline or other flammable vapor or liquid near the air conditioner — it is very dangerous.

This air conditioner has no ventilator for intaking fresh air from outdoors. You must open doors or windows frequently when you use gas or oil heating appliances in the same room, which consume a lot of oxygen from the air. Otherwise there is a risk of suffocation in an extreme case.

Do not turn the air conditioner on and off from the power mains switch. Use the ON/OFF operation button.

Do not stick anything into the air outlet of the outdoor unit. This is dangerous because the fan is rotating at high speed.

Do not let children play with the air conditioner.

Do not cool or heat the room if children, babies or invalids are present.



WARNING

[Previous Page](#)
[Next Page](#)

1
2
3
4
5
6
7
8

Quick Links:

[Features](#)

[Product Information](#)

[Alert Symbols](#)

[Table of Contents](#)

[Electrical Requirements](#)

[Troubleshooting](#)

Related Manuals for Sanyo SAP-URV246EH

[Air Conditioner Sanyo SAP-URV96EH Installation Instructions Manual](#)

Split system (47 pages)

[Air Conditioner Sanyo UR9X Installation Instructions Manual](#)

Split system air conditioner (52 pages)

[Air Conditioner Sanyo SAP-KRV9AG Instruction Manual](#)

Inverter-controlled split system air conditioner (22 pages)

[Air Conditioner Sanyo SAP-KRV123EH Technical & Service Manual](#)

Dc inverter split system air conditioner (77 pages)

[Air Conditioner Sanyo SAP-CRV93EHN Technical & Service Manual](#)

Dc inverter split system air conditioner (77 pages)

[Air Conditioner Sanyo SAP-K18AM Instruction Manual](#)

Split system air conditioner (37 pages)

[Air Conditioner Sanyo SAP-CMRV1424EH Technical & Service Manual](#)

Dc inverter multi-system air conditioner (114 pages)

[Air Conditioner Sanyo SAP-KRV96EHDS Technical & Service Manual](#)

Dc inverter split system air conditioner (77 pages)

[Air Conditioner Sanyo SAP-KMRV74EH Installation Instructions Manual](#)

Inverter multi split system air conditioner (28 pages)

[Air Conditioner Sanyo SAP-KMRV74EH Installation Instructions Manual](#)

Inverter split system air conditioner (24 pages)

[Air Conditioner Sanyo SAP-K91GJA \(?\) Technical & Service Manual](#)

Multi-split system air conditioner (50 pages)

[Air Conditioner Sanyo SAP-K92A Technical & Service Manual](#)

Multi-split system (39 pages)

[Air Conditioner Sanyo SAP-K161GJA Technical & Service Manual](#)

Split system air conditioner (86 pages)

[Air Conditioner Sanyo SAP-K77GHAX Technical & Service Manual](#)

(164 pages)

[Air Conditioner Sanyo SAP-C302AH-S Technical & Service Manual](#)

(45 pages)

[Air Conditioner Sanyo SAP-K71GJA-S Technical & Service Manual](#)

(81 pages)

Related Content for Sanyo SAP-URV246EH

[SAP-K91AA Installation Location](#)

Sanyo SAP-K91AA

[SAP-FDRV96EH Installation Location](#)

Sanyo SAP-FDRV96EH

[SAP-K77GHAX Installation Location](#)

Sanyo SAP-K77GHAX

[SAP-K71GJA Installation Location](#)

Sanyo SAP-K71GJA

[SAP-K161GJA Installation Location](#)

Sanyo SAP-K161GJA

[KS2432 Installation Location](#)

Sanyo KS2432

[SAP-KMV91G-S Installation Location](#)

Sanyo SAP-KMV91G-S

[SAP-K91A Installation Location](#)

Sanyo SAP-K91A

This manual is also suitable for:

[Sap-urv96ehSap-urv186ehSap-ftv246ehSap-ftv186ehSap-urv126ehSap-ftv126h](#) ... [Show all](#)

[Save PDF](#)