



Toshiba \*\*BL502B Retuning



1  
2  
3  
4

--


•

Bookmarks

--

[Download this manual](#)

### Quick Links



# Retuning: Toshiba Televisions

This guide can be used to help you retune the following models: \_\_BL502B, \_\_BL505B, \_\_BL702B - \_\_BL712B series, \_\_BV501B - \_\_BV504B series, \_\_BV512B, \_\_BV701B - BV 715B series, \_\_BV801B, \_\_DL502B, \_\_DL504B, \_\_DL702B - \_\_DL712B series, \_\_DL833B, \_\_DL933B, \_\_DL934B, DV501B - \_\_DV504B series, EL833B, KV501B, KV701B

If your remote control is different to the one below take a look to see if the buttons are similar - you may still be able to retune using the steps below.

**Manufacturer Helpline: 0844 856 0730**

Please note retuning can affect your favourites list, please refer to your manufacturer's instruction book.





!

= Handy tip

= Attention

( \_\_ = Screen size)

The message 'Do you want to start an automatic channel scan?' will appear

These retune steps will work for most cases, however, if you find after retuning you are missing services or have the wrong regional news, you can try a manual retune using the steps on pages 3-4

1)

Press the

Menu

button

2)



Use the

Right Arrow

button to select

Install and Retune.

Install and Retune.

(open carton icon)

Press the

OK

button.

3)

Use the

Down Arrow

button to select

Automatic channel

scan (Retune).

Press the

OK

button.

4)

Use the

Down Arrow

button to select

Digital.

Press the

OK

button.

5)

Don't worry!

Press the

OK

button to

select



Yes.

[www.toshiba.co.uk](http://www.toshiba.co.uk)

Steps 1-5

Steps 1-5

Steps 1-5

Page 1 of 4

Page 1 of 4

Page 1 of 4

1  
2  
3  
4

## Related Manuals for Toshiba \*\*BL502B

### [TV Toshiba 32CV711B Owner's Manual](#)

Digital series (57 pages)

### [TV Toshiba COLORSTREAM BBE 32AF44 Owner's Manual](#)

(48 pages)

### [TV Toshiba 23L1350UC User Manual](#)

Integrated high definition led television (123 pages)

### [TV TOSHIBA 32RV600E Owner's Manual](#)

Lcd colour tv (40 pages)

### [TV Toshiba 26HF86C Owner's Manual](#)

Toshiba color television owner's manual 26hf86c, 30hf86c (88 pages)

### [TV Toshiba 19AV500U Owner's Manual](#)

Integrated high d.efinition lcd teleyision (57 pages)

### [TV Toshiba CT-RC2US-17 Quick Setup Manual](#)

43"/49"/55"/65" 2160p 4k, 60hz, led google cast tv (2 pages)

### [TV Toshiba fire tv 43C350KU Quick Setup Manual](#)

(19 pages)

### [TV Toshiba 27D47 Service Manual](#)

(49 pages)

### [TV Toshiba 26DL933B Owner's Manual](#)

Digital series (60 pages)

### [TV Toshiba 32LV703R Service Manual](#)

Lcd color television (132 pages)

### [TV Toshiba 30HF66 Service Manual](#)

Toshiba color tv service manual (67 pages)

### [TV Toshiba 30HF66 Owner's Manual](#)

Integrated high definition color television (88 pages)

### [TV Toshiba 65L350U Instruction Manual](#)

65" 1080p 120hz led tv (81 pages)

### [TV Toshiba 42VL963B Owner's Manual](#)

VI96 digital series (92 pages)

### [TV Toshiba 43L310U Manual](#)

43"/49"/55" 1080p 60hz led tv (90 pages)

## Summary of Contents for Toshiba \*\*BL502B

**Page 1** Retuning: Toshiba Televisions Steps 1-5 Steps 1-5 Steps 1-5 This guide can be used to help you retune the following models: \_\_BL502B, \_\_BL505B, \_\_BL702B - \_\_BL712B series, \_\_BV501B - \_\_BV504B series, \_\_BV512B, \_\_BV701B These retune steps will work for most cases, however, if - BV 715B series, \_\_BV801B, \_\_DL502B, \_\_DL504B, you fi...

**Page 2** Retuning: Toshiba Televisions Steps 6-9 Steps 6-9 Steps 6-9 This guide can be used to help you retune the following models: \_\_BL502B, \_\_BL505B, \_\_BL702B - \_\_BL712B series, \_\_BV501B - \_\_BV504B series, \_\_BV512B, \_\_BV701B These retune steps will work for most cases, however, if - BV 715B series, \_\_BV801B, \_\_DL502B, \_\_DL504B, you fi...

[Page 3](#) Manual Retuning: Toshiba Televisions Steps 1-5 Steps 1-5 Steps 1-5 This guide can be used to help you retune the following models: \_\_BL502B, \_\_BL505B, \_\_BL702B - \_\_BL712B series, \_\_BV501B - \_\_BV504B series, \_\_BV512B, \_\_BV701B First, enter your postcode at: - BV 715B series, \_\_BV801B, \_\_DL502B, \_\_DL504B, [www.digitaluk.co.uk/manualretune...](http://www.digitaluk.co.uk/manualretune...)

[Page 4](#) Manual Retuning: Toshiba Televisions Step 6-8 Step 6-8 Step 6-8 This guide can be used to help you retune the following models: \_\_BL502B, \_\_BL505B, \_\_BL702B - \_\_BL712B series, \_\_BV501B - \_\_BV504B series, \_\_BV512B, \_\_BV701B If you are missing services after doing a basic retune,...

This manual is also suitable for:

[\\*\\*bl712b\\*\\*bl505b\\*\\*bv501b\\*\\*bl702b\\*\\*bv504b\\*\\*bv512b](#) ... [Show all](#)