



Toshiba VC-EA100CV Owner's Manual

1
2
3
4
5

--

•

Bookmarks

[Download this manual](#)

Quick Links



VC-EA100CV

VC-EA100C

-Thank you for choosing Toshiba Vacuum Cleaner

-Please, read this manual carefully for a proper

-and efficient use of your Vacuum Cleaner

TOSHIBA
Leading Innovation >>>

TOSHIBA Vacuum Cleaner ..

Maximum Power

«HOME USES»

Owner's

odels

[Next Page](#)

1
2
3
4
5

Related Manuals for Toshiba VC-EA100CV

[Vacuum Cleaner Toshiba VC-GC33BSA Owner's Manual](#)

(48 pages)

[Vacuum Cleaner Toshiba VC-GC32BSA Owner's Manual](#)

Household vacuum cleaner (40 pages)

[Vacuum Cleaner Toshiba VC-PD9 Instructions](#)

(2 pages)

[Vacuum Cleaner Toshiba VC-GC31CPT Owner's Manual](#)

Household vacuum cleaner (38 pages)

[Vacuum Cleaner Toshiba VC-CLS1BF User Manual](#)

(10 pages)

[Toshiba VC-CLS1BF - HAND STICK VACUUM CLEANER Manual](#)

(article)

[Vacuum Cleaner Toshiba VC-CL3000XBF User Manual](#)

(18 pages)

[Toshiba VC-CLX50BF - 1.5KG HAND STICK VACUUM CLEANER Manual](#)

(article)

[Vacuum Cleaner Toshiba HCV-6KALU Instruction Manual](#)

Vacuum contactor (30 pages)

Summary of Contents for Toshiba VC-EA100CV

[Page 1](#) VC-EA100CV VC-EA100C -Thank you for choosing Toshiba Vacuum Cleaner -Please, read this manual carefully for a proper -and efficient use of your Vacuum Cleaner TOSHIBA Vacuum Cleaner .. Maximum Power «HOME USES»...

[Page 2: Safety Precautions](#)

Use only attachments recommended A-24 Hold the plug when rewinding onto the cord by TOSHIBA. reel, to prevent the cord from whipping. Do not pull or carry by the cord, use the cord A-23 SAVE THIS INSTRUCTIONS...

[Page 3](#) D-After Use B-Preparing for Use D-1 Press ON/OFF power switch to turn off the B-1 To connect hose, push it into the hose inlet power, and unplug from wall socket. on the main unit. Connect extension tube and D-2 Press the cord rewind button and store the floor brush.

[Page 4](#) F-Maintenance G-Repair Hose Cleaning Air Outlet Filter and Biomimetic Fiber In case the hose close to the swivel connector is (EA100CV) torn, take the following steps; F-9 Take off the air outlet cover. G-1 Unhook the 4 ridges and separate the swivel F-10Take out the air outlet cover and biomimetic connector from the hose.

[Page 5: Troubleshooting](#)

Power cord can Is the cord entwined ? Press the cord rewind button not be rewind or repeat «rewind» and «pull out» pull out for 2 to 3 times. Specification Model VC-EA100CV VC-EA100C Power Consumption 1600W 1600W P.M. 1400W 1400W Power supply...

This manual is also suitable for:

Vc-ea100c