



Whirlpool ACH 846/BB/WP Service Manual

Gas cooker

1
2
3
4
5
6

--

•

[Table of Contents](#)

•

Bookmarks

--

Table of Contents

[1 Technical Data](#)

[2 Spare Part List](#)

[3 Exploded View](#)

[4 Wiring Diagram](#)

[Download this manual](#)



Model

Version

Whirlpool Europe

Customer Services



Service Manual

Gas cooker

ACH 846/BB/WP

ACH 846/BB/WP

8520 846 10000

Technical data

Spare part list

Exploded view

Wiring diagram

This documentation is only intended for qualified technicians who are aware of the respective safety regulations.

Date: 16.07 .1997

Document-No.: 4812 715 16733

ACH 846/BB/WP

Page

2

3

4 - 5

6

Subject to modification

[Table of Contents](#)

[Next Page](#)

1
2
3
4
5

Related Manuals for Whirlpool ACH 846/BB/WP

[Cookers Whirlpool AGB 405/WP Manual](#)

Electric tilting cooker (13 pages)

[Cookers Whirlpool Need For Speed WFG775H0HV Wiring Diagram](#)

(2 pages)

[Cookers Whirlpool ACMT 6533/IX/2 Instructions For Use Manual](#)

(32 pages)

[Cookers Whirlpool ACMT 6533/WH Instructions For Use Manual](#)

(76 pages)

[Cookers Whirlpool AGG540IX Instruction Manual](#)

(15 pages)

[Cookers Whirlpool ADN 632 Instructions For Installation, Use And Maintenance Manual](#)

Gas fry top (12 pages)

[Cookers Whirlpool Gas Range User Manual](#)

Whirlpool gas range cooker (48 pages)

[Cookers Whirlpool WL B4560 NE/W Manual](#)

(82 pages)

[Cookers Whirlpool ACG 900 IX User Manual](#)

Installation & servicing (25 pages)

[Cookers Whirlpool ACG540IX Service Manual](#)

(9 pages)

[Cookers Whirlpool W6 OS4 4S1 H BL Quick Start Manual](#)

(73 pages)

[Cookers Whirlpool WS Q5760 NE Manual](#)

(35 pages)

[Cookers Whirlpool ADN 612 Instructions For Installation Manual](#)

Gas kitchens with pilot (16 pages)

[Cookers Whirlpool AKR 951 Installation Sheet](#)

(20 pages)

[Cookers Whirlpool AKT 617 Product Description Sheet](#)

(4 pages)

[Cookers Whirlpool WF S7977 CPNE Manual](#)

(103 pages)

Summary of Contents for Whirlpool ACH 846/BB/WP

[Page 1](#) Whirlpool Europe S E R V I C E ACH 846/BB/WP Customer Services Service Manual Gas cooker ACH 846/BB/WP Model ACH 846/BB/WP Version 8520 846 10000 Page Technical data Spare part list Exploded view 4 - 5 Wiring diagram This documentation is only intended for qualified technicians who are aware of the respective safety regulations.

[Page 2: Technical Data](#)

16.07 .1997 / Page 2 ACH846/BB/WP Whirlpool Europe S E R V I C E Doc. No: 4812 715 16733 8520 846 10000 Customer Service Technical data Electrical connection Voltage

220-240/380-415 Frequency 50/60 Upper heating element Lower heating element 1200...

[Page 3: Spare Part List](#)

Whirlpool Europe ACH 846/BB/WP 16.07 .1997 / Page 3 S E R V I C E Customer Service 8520 846 10000 Doc. No: 4812 715 16733 Spare part list Model ACH 846/BB/WP Service No. 852084610000 Version 852084610000 Pos. No. 12NC Code Description Pos.

[Page 4: Exploded View](#)

16.07 .1997 / Page 4 ACH846/BB/WP Whirlpool Europe S E R V I C E Doc. No: 4812 715 16733 8520 846 10000 Customer Service Exploded view...

[Page 5](#) Whirlpool Europe ACH846/BB/WP 16.07 .1997 / Page 5 S E R V I C E Customer Service 8520 846 10000 Doc. No: 4812 715 16733 Exploded view...

[Page 6: Wiring Diagram](#)

16.07 .1997 / Page 6 ACH846/BB/WP Whirlpool Europe S E R V I C E Doc. No: 4812 715 16733 8520 846 10000 Customer Service Wiring diagram...