## Important Safety Instructions - Whirlpool SWASH Quick Start Manual

Table Of Contents

•


Table of Contents











```
IMPORTANT SAFETY INSTRUCTIONS
WARNING:
To reduce the risk of fire, electric shock, or injury to persons when using the
follow basic precautions, including the following:
Read all instructions before using the
Use the
SWASH
System only for its intended use.
To reduce the risk of electric shock, do not immers that an uals Lib.con of the
System in water or other liquids.
SWASH
Never yank cord to disconnect from outlet; instead, grasp
plug and pull to disconnect.
Do not allow cord to touch hot surfaces. Let the
System cool completely before putting away. Loop cord
loosely around the
SWASH
Always disconnect the
SWASH
when not in use, or when cleaning the
Do not operate the
SWASH
cord, or if it has been dropped or damaged. To reduce
the risk of electric shock, do not disassemble or attempt
to repair the
System. Contact a qualified service
SWASH
person for examination and repair. Incorrect reassembly
or repair could cause a risk of fire, electric shock, or
injury to persons when the
Close supervision is necessary for any appliance being
used near children.
Use care when interrupting a cycle; interior surfaces may
be hot if the
                                           ManualsLib.con
System is opened when in use.
SWASH
System.
SWASH
SWASH
System when storing.
```

```
System from electrical outlet
System.
SWASH
System with a damaged
System is used.
SWASH
System,
SWASH
To reduce the likelihood of circuit overload, do not
operate other high-wattage hardware (i.e. refr
                                         ManualsLib.con
air conditioner, etc) on the same circuit.
The
System is intended for household use only.
SWASH
Do not use outdoors.
Do not use in garages or near any flammable liquids.
Do not use an extension cord.
The use of accessories other than those supplied with the
System is not recommended and may cause injury.
SWASH
Use and store the
SWASH
paths to reduce the possibility of tip-over.
Keep the area clear around the base of the
to make sure ventilation openings in the bottom of the
System are not blocked.
SWASH
Do not modify
SWASH PODS
formulas. The
System was designed to work safely
SWASH
using only the unique
SWASH PODS
                                         ManualsLib.com
could reduce user safety. Burns could occur
from touching hot metal parts.
SAVE THESE INSTRUCTIONS
System out of regularly traveled
System
SWASH
```

cups or use any alternate <sup>™</sup>	
cups. Any modifications	
3	
	Table of Contents
	Provinus Page
	Previous Page Next Page

Quick Links:		
How to Use Your How Does It Work		
Emptying the Reservoir		
Troubleshooting		

## Related Manuals for Whirlpool SWASH

Household Appliance Whirlpool SFF1000CLN0 Owner's Manual

Swash system (17 pages)

## Related Products for Whirlpool SWASH

Whirlpool SFF1000CLN0

Whirlpool SFF1000CSA0

Whirlpool SWA1040Q

Whirlpool SWA2040Q

Whirlpool SWA3020Q

Whirlpool SWA4020Q

Whirlpool SWA3220Q

Whirlpool SWA4220Q

Whirlpool SWA3120Q

Whirlpool SWA4120Q

Whirlpool SW8 AM2C XR

Whirlpool SW6AM2QW

Whirlpool SW8 AM2Y XR 2

Whirlpool SW8AM2QX2

Whirlpool SW8 AM2C XR2

Whirlpool SW8 AM2 D XR 2

Save PDF