



# Product Overview; Front View - Asus HG100 Quick Start Manual



1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
Table Of Contents
17



- 

[Table of Contents](#)

•

## Bookmarks







# Product overview

## Front View

The LED status indicator helps identify the current status of your ASUS

HG100. Refer to the following table for details:

Color  
Solid Blue



Fast Blinking Blue  
Fast Blinking Red  
Slow Blinking Blue

4

Status


HG100 and AP-Router connected

HG100 and AP-Router not connected

Warning

Connecting device

LED status indicator



[Table of Contents](#)

[Previous Page](#)  
[Next Page](#)

1  
2  
3  
4  
5  
6  
7  
8

## Related Manuals for Asus HG100

[Gateway Asus HG100 User Manual](#)

(160 pages)

[Security System Asus security system User Manual](#)

(26 pages)

[Security System Asus AS101 User Manual](#)

(116 pages)

## Related Content for Asus HG100