

TOSHIBA

Toshiba PA3674U-1ETB User Manual

Wireless presenter

1
2
3
4
5
6
7
8

--

-

Troubleshooting

•

Bookmarks

[Download this manual](#)

Quick Links



User's Manual **TOSHIBA** Wireless Presenter

Introduction

Thank you for purchasing the Toshiba Wireless Presenter. The Wireless Presenter with Laser Pointer enables you to control your onscreen presentations within a range of 50 feet, making it perfect for large conference rooms. The presenter supports the most

common PowerPoint

Page Down, and Darken Screen & Resume Screen. It also has a laser pointer to help you focus on key messages. The small size allows you to control your presentation with ease and enjoy freedom of movement as you present. Just plug and play, no software is required.

TOSHIBA

Package Contents



Wireless Presenter with receiver unit



User's Manual



Warranty booklet



AAA Battery (1)

Minimum System Requirements



USB port

ManualsLib.com



Windows

®

presentation functions including Page Up,

®

Vista™ /XP/2000

This is a Class 2 Laser product. Please DO NOT look at or direct the laser beam at anyone's eye.

[Table of Contents](#)

[Next Page](#)

1
2
3
4
5

Summary of Contents for Toshiba PA3674U-1ETB

[Page 1](#) User's Manual Wireless Presenter Introduction Thank you for purchasing the Toshiba Wireless Presenter. The Wireless Presenter with Laser Pointer enables you to control your onscreen presentations within a range of 50 feet, making it perfect for large conference rooms. The presenter supports the most ®...

[Page 2](#) Functions and Features: Functions and Features: - Page Up - Auto on/off function - Page Down - Self contained receiver unit - Darken Screen - Low battery warning light - Resume Screen - Up to 50 foot range - Laser Pointer - Compact for travel Top Side Laser Button: Laser Pointer On/Off...

[Page 3: Getting Started](#)

Receiver Unit Receiver Unit USB Plug Reset Button Getting Started Inserting the Battery Open the battery cover and insert 1 AAA battery. Follow the same procedure as outlined above when replacing the battery. Removing the Receiver To remove the receiver unit from its compartment, pull up on the small nub on the back of the receiver.

[Page 4](#) Connecting the Receiver Connecting the Receiver Insert the USB receiver into an available USB port on your computer. Connection to the presenter is automatic. Switching Channels (if necessary) This is a plug-and-play device. Normally, it is not necessary to set the RF channel. If you should experience interference, please follow the steps below to select a new RF channel: 1.Plug the receiver unit into one of the USB ports on the computer and press and release the reset button.

[Page 5: Troubleshooting](#)

Storing the Receiver Unit Storing the Receiver Unit Replace the receiver unit into the compartment in the back the presenter. With the small nub pointing up, slide the USB end of the receiver unit into the compartment and press down gently until the receiver clicks into place.

[Page 6](#) Consult the dealer or an experienced radio/TV technician for help. WARNING: Changes or modifications made to this equipment, not expressly approved by TOSHIBA or parties authorized by TOSHIBA could void the user's authority to operate the equipment.

[Page 7](#) (1) This device may not cause harmful interference (2) This device must accept any interference received. Including interference that may cause undesired operation. Contact Address: TOSHIBA America Information Systems, Inc. 9740 Irvine Boulevard Irvine, California 92618-1697 Telephone: (949) 583-3000 IC Information This device complies with RSS 210 of Industry Canada.

[Page 8: Specifications](#)

Specifications Wireless Presenter Presenter Button: Left: Page up Right: Page down Top: Laser Pointer Bottom: Darken Screen/Resume Screen Dimension (D x W x H): 115 x 30 x 23 mm 4.5 x 1.2 x 0.9 inches Weight: 35g (1.2 ounces) Battery Type: 1.5V, AAA x 1 Interface:...