TOSHIBA

Toshiba MMW-AP0271LQ-E Owner's Manual

Hot water module (multi type)

```
Table Of Contents
2
3
4
5
6
7
8
9
10
11
12
13
```

Table of Contents






Quick Links

- 1 Basic Operation
- 2 Troubleshooting

Download this manual

See also: Service Manual , Installation Manual





HOT WATER MODULE (MULTI TYPE)
Owner's Manual
Indoor Unit
For commercial use
Model more HIBA
Hot Water Module
Leading Innovation >>>
MMW-AP0271LQ-E
MMW-AP0561LQ-E



ManualsLib.con

Table of Contents





Related Manuals for Toshiba MMW-AP0271LQ-E

Air Conditioner Toshiba MMW-AP0271LQ-E Service Manual

Hot water module (108 pages)

Water Heater Toshiba MMW-AP0271LQ-E Installation Manual

Hot water module (multi type) (34 pages)

Water Heater Toshiba MMW-AP0271LQ-TR Installation Manual

Hot water module (multi type) (68 pages)

Water Heater Toshiba MMW-AP0481CHQ-E Manual

Hot water module (33 pages)

Water Heater Toshiba DSK ES Series Installation Instruction

Electric water heater (12 pages)

Summary of Contents for Toshiba MMW-AP0271LQ-E

<u>Page 1</u> HOT WATER MODULE (MULTI TYPE) Owner's Manual Indoor Unit For commercial use Model name: Hot Water Module MMW-AP0271LQ-E MMW-AP0561LQ-E English...

Page 2: Table Of Contents

<u>Page 3</u> (including the hot water modules) made by Toshiba Carrier Corporation or, alternatively, he or she has been instructed in such matters by an individual or individuals who have been trained and is thus thoroughly acquainted with the knowledge related to this work.

Page 4: Precautions For Safety

- 3 - Precautions for safety • After the installation work has been completed, have the installer explain about the circuit breaker positions. In the event that error has The manufacturer shall not assume any liability for the damage caused occurred in the hot water module, set the circuit breaker to the OFF by not observing the description of this manual.

<u>Page 5</u> • Do not climb onto or place objects on top of the outdoor unit. You may Relocation fall or the objects may fall off of the outdoor unit and result in injury. • When the hot water module is to be relocated, do not relocate it yourself but contact a qualified installer or a qualified service person.

Page 6 - 5 - • Check whether the installation base and other equipment have ☐ Information on the transportation, handling and storage of the become deteriorated after being used for a long time. Leaving them carton such condition may result in the unit's falling down and causing injury. •...

Page 7: Part Names

Part names \square Hot water module Electrical control box Water outlet Earth screw Equipped on the electrical Water inlet control box SETTING indicator Central control indicator Displayed when setting the timer or other Displayed when the air conditioner is controlled functions.

Page 8: Basic Operation

- 7 - Basic operation [] Operation section Once the settings have been configured, all you need to do is push the button from then on. When you use the hot water module for the first time or change the settings, follow the procedures below. From next time, pushing the button starts

running of the hot water module with the chosen settings.

Page 9: Timer Operation

Timer operation Installation Select a timer type from the following three: (Max. 168 hours) [] Location OFF timer: Stops running after the specified period. Repeat-OFF timer: Stops running after the specified period every time you use the hot water module. •...

Page 10: Notes On Operations And Performance

- 9 - Notes on operations and performance Maintenance ☐ Before the operating season WARNING ☐ Check before operation The protective device may activate in the following cases: Ask a qualified service person to clean the drain For daily maintenance, make •...

Page 11: Troubleshooting

Troubleshooting CAUTION If any of the following conditions occur, turn off the main power supply When the following symptoms are found, check the points described below before asking repair servicing. switch and immediately contact the dealer: Symptom Cause • White misty cold air or water •...

Page 12: Specifications

Model Weight (kg) Main unit Heating The check code is only displayed during the operation. MMW-AP0271LQ-E 17.8 If the display disappears, operate the air conditioner or hot water MMW-AP0561LQ-E 20.3 module according to the following "Confirmation of error log" for confirmation.

<u>Page 13</u> (Name of the manufacturer) TOSHIBA CARRIER CORPORATION 336 Tadehara, Fujishi, Shizuoka-ken (Address, city, country) 416-8521 Japan (Name of the Importer / Distributor in EU) Toshiba Carrier UK Ltd. Porsham Close, Belliver Industrial Estate, PLYMOUTH, (Address, city, country) Devon, PL6 7DB. United Kingdom EH99945499...

This manual is also suitable for:

Mmw-ap0561lq-e