



Toshiba AT10-C User's Information Manual

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17

Table Of Contents

--

•

•

Bookmarks

--

[Download this manual](#)

Quick Links



User Information Guide

TOSHIBA AT10-C

User Information Guide

1

Leading Innovation >>>

ManualsLib.com

[Table of Contents](#)

[Next Page](#)

1
2
3
4
5

Related Manuals for Toshiba AT10-C

[Tablet Toshiba AT105-SP0160M User Manual](#)

At105-sp0160m user's guide (132 pages)

[Tablet Toshiba AT105-SP0102C Manual Del Usuario](#)

User guide 2 (142 pages)

[Tablet Toshiba PDA01U-00501F Brochure](#)

Brochure (3 pages)

[Tablet Toshiba Thrive AT105-T108S Specifications](#)

Toshiba thrive tablet detailed product specification (3 pages)

[Tablet Toshiba PDA01U-00101F Brochure](#)

Brochure (3 pages)

[Tablet Toshiba Thrive AT105-T10162 Specifications](#)

Toshiba thrive tablet detailed product specification (3 pages)

[Tablet Toshiba Thrive 32GB User Manual](#)

Toshiba thrive 32gb: user guide (131 pages)

[Tablet Toshiba Thrive 10.1 8GB User Manual](#)

Toshiba thrive 10.1 8gb: user guide (131 pages)

[Tablet Toshiba AT100 User Manual](#)

(86 pages)

[Tablet Toshiba AT1S0 User Manual](#)

(82 pages)

[Tablet Toshiba AT1S0 User Manual](#)

(83 pages)

[Tablet Toshiba Excite Pure AT10 User Manual](#)

A series (132 pages)

[Tablet Toshiba AT10LE-A Series User Manual](#)

(103 pages)

[Tablet Toshiba AT10-B User Manual](#)

(86 pages)

[Tablet Toshiba Excite Pro Specifications](#)

(3 pages)

[Tablet Toshiba Excite Write Specifications](#)

(3 pages)

Summary of Contents for Toshiba AT10-C

[Page 1](#) User Information Guide TOSHIBA AT10-C User Information Guide...

[Page 2: Safety Icons](#)

Safety icons Safety icons are used in this guide to bring important information to your attention. Each type of icon and its implication are identified as shown below. Indicates a potentially hazardous situation, which could result in death or serious injury, if you do not follow instructions.

[Page 3: Unpack The Box](#)

Unpack the box 1. Remove the components and tablet from the box. Save the packing materials in case you need them later. 2. Remove the documentation package for important information. All product specifications, configurations, prices, system/component/options availability are all subject to change without notice. Check the components Your tablet comes with: AC adaptor (2-pin or 3-pin)

[Page 4: Charging Your Tablet](#)

Charging your tablet Your tablet contains a rechargeable battery that may need to be charged prior to use. 1. Plug the USB connector of the Micro-USB cable into the AC adaptor and the other smaller connector into the Micro-USB port on your tablet. Depending on the model, either a 2-pin or 3-pin AC adaptor will be bundled with the tablet.

[Page 5: Quick Tour](#)

Quick tour The following figure shows each important part of your tablet. 1. Power button ⑩ 2. Speakers ⑨ ① 3. Headphone/Microphone combo jack ② ② 4. Micro HDMI port ③ 5. Memory media slot ④ □ 6. Battery indicator ⑤...

[Page 6](#) Task View Task view () is launched from Windows taskbar at the bottom of the screen. You can view the apps that are currently running by tapping the Task view () icon. Search Search on the Windows taskbar allows you to find apps, files, settings, and more on the computer. When Internet connection is available, it also shows you the best search result from the Internet.

[Page 7: Turning On/Off](#)

Windows Store Although many applications are pre-installed in your tablet, you can also download many others from the Windows Store. You can search for and browse thousands of apps, all grouped into easy-to-find categories there. Sign-in options Windows offers a number of sign-in options including Password (), PIN () and Picture password (...)

[Page 8: Creating Recovery Media](#)

Creating Recovery Media It is strongly recommended that you create recovery media before using your tablet for the first time. This will enable you to return your system to its out-of-box state. A recovery image of the software on your tablet is stored on the internal storage, and can be copied to a USB Flash Memory by using the following steps: 1.

[Page 9](#) Restoring the pre-installed software from the Internal Storage A portion of the total internal storage space is used to store the recovery image which can be used to restore pre-installed software in the event of a problem. 1. Tap the Power () icon on the Main screen and then select Shut down.

[Page 10](#) Copyright © 2015 by TOSHIBA Corporation. All rights reserved. Under the copyright laws, this manual cannot be reproduced in any form without the prior written permission of TOSHIBA. No patent liability is assumed, with respect to the use of the information contained herein.

[Page 11: Eu Declaration Of Conformity](#)

ENERGY STAR logo and the following information applies. TOSHIBA is a partner in the ENERGY STAR Program and has designed this computer to meet the latest ENERGY STAR guidelines for energy efficiency. Your computer ships with the power management options preset to a configuration that will provide the most stable operating environment and optimum system performance for both AC power and battery modes.

[Page 12](#) 15 minutes of inactivity in AC power mode. TOSHIBA recommends that you leave this and other energy saving features active, so that your computer will operate at its maximum energy efficiency. You can wake the computer from Sleep Mode by pressing the power button.

[Page 13: Information For Wireless Devices](#)

Because Wireless products operate within the guidelines found in radio frequency safety standards and recommendations, TOSHIBA believes Wireless products is safe for use by consumers. These standards and recommendations reflect the consensus of the scientific community and result from deliberations of panels and committees of scientists who continually

review and interpret the extensive research literature.

[Page 14: Usa-Federal Communications Commission \(Fcc\)](#)

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of this device. The term "IC" before the equipment certification number only signifies that the Industry Canada technical specifications were met.

[Page 15](#) Consult the dealer or an experienced radio/TV technician for help. ■ 3. This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

[Page 16: Setting Sound Volume](#)

for devices with detachable antenna(s), the maximum antenna gain permitted for devices in the ■ bands 5250-5350 MHz and 5470-5725 MHz shall be such that the equipments still complies with the e.i.r.p. limit; for devices with detachable antenna(s), the maximum antenna gain permitted for devices in the ■...

[Page 17: Before You Call](#)

Before you call Some problems you experience may be related to software or the operating system so it is important that you investigate other sources of assistance first. Before contacting TOSHIBA, try the following: Review troubleshooting sections in the documentation supplied with your ■...