

Adjusting The Fan Speed; Fan Only - Sanyo KS2432 Instruction Manual

Split system air conditioner; wall-mounted type ceiling-mounted type recessed type cool/fan model

1
2
Table Of Contents
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17

18
19
20
21
22
23
24



•

-

Troubleshooting

•

Bookmarks



2. Adjusting the

14

Downloaded from

www.Manualslib.com

Operation with the Remote Control Unit (continued)

Choose the best position in the room for the remote control unit, which

NOTE

also acts as the sensor for room comfort and transmits the operating instructions. Once you've found this best position, always keep the remote control unit there.

This appliance has a built-in 3-minute time delay circuit to ensure reliable operation. When the operation button is pressed, the compressor will start running within three minutes. In the event of power failure, the unit will stop. When the power is restored, the unit will restart automatically after three minutes.

Fan Speed

A. Automatic

Simply set the FAN SPEED selector to the

A microcomputer in the air conditioner automatically controls the fan speed when the

the difference between the room temperature and the set temperature is detected by the microcomputer which then automatically switches the fan speed to the most suitable level.



Cooling mode:

When difference between room

temperature and set temperature is

4 °F and over

Between 4 °F and 2 °F

Below 2 °F

The above table assumes that the sensor on the remote control is being

NOTE

used. If the sensor on the indoor unit is being used (the actual operation may differ slightly from the operation described in the table.

(Refer to "A/C SENSOR button" on page 10.)



B. Manual

If you want to adjust fan speed manually during operation, just set the FAN SPEED selector as desired. [



3. Fan Only

If you want to circulate air without any temperature control, follow these steps:

STEP 1: Press the MODE selector button to switch to the fan mode.

STEP 2: Press the ON/OFF button.

STEP 3: Press the FAN SPEED button to select the fan speed of your choice

mode is selected. When the air conditioner starts operating,

ON / OFF

MODE

STEP 1

FLAP

FAN SPEED

STEP 3

TIME SET

SELECT

(

)

(

,

, or

).

position.

position.

FAN SPEED


High

Medium

Low



ManualsLib.com



, or

]

STEP 2

NIGHT
OFF
ON
SETBACK
CLOCK
HH

MM
A/C
ACL
SENSOR
BATTERIES

indicator is on),

OI-201-14EG



[Table of Contents](#)

[Previous Page](#)

[Next Page](#)

1
...
11
12
13
14
15
16
17
18

Quick Links:

[Features](#)

[Product Information](#)

[Names of Parts](#)

[Remote Control Unit](#)

[Care and Cleaning](#)

[Troubleshooting](#)

Related Manuals for Sanyo KS2432

[Air Conditioner Sanyo C2432A Installation Instructions Manual](#)

(50 pages)

[Air Conditioner Sanyo KS2432 Instruction Manual](#)

Split system air conditioner cool/fan model (24 pages)

[Air Conditioner Sanyo XS4232 Technical Data And Service Manual](#)

(66 pages)

[Air Conditioner Sanyo C4232 Technical Data & Service Manual](#)

Split system air conditioner (66 pages)

[Air Conditioner Sanyo KS3032 Service Manual](#)

Split system air conditioner (56 pages)

[Air Conditioner Sanyo KS3032 Service Manual](#)

(54 pages)

[Air Conditioner Sanyo C3032 Service Manual](#)

Split system air conditioner (54 pages)

[Air Conditioner Sanyo TS2432 Service Manual](#)

Split system air conditioner (48 pages)

[Air Conditioner Sanyo XS2432 Service Manual](#)

Split system air conditioner (48 pages)

[Air Conditioner Sanyo C1852 Service Manual](#)

Split system air conditioner (45 pages)

[Air Conditioner Sanyo XS1822 / CL1822 Service Manual](#)

Split system air conditioner (39 pages)

[Air Conditioner Sanyo PNR-XS2432 Installation Instructions Manual](#)

Split system air conditioner (27 pages)

[Air Conditioner Sanyo 18XLS52 Specifications](#)

Ductless split system air conditioners & heat pumps (3 pages)

[Air Conditioner Sanyo 24XS32A Submittal Sheet](#)

Indoor/outdoor ceiling recessed (4-way) air conditioner (3 pages)

[Air Conditioner Sanyo 30KS32A Specifications](#)

Wall mounted air conditioner (3 pages)

[Air Conditioner Sanyo 36TS32A Datasheet](#)

Ceiling suspended air conditioner (3 pages)

Related Content for Sanyo KS2432

[SAP-FDRV96EH Adjusting The Fan Speed](#)

Sanyo SAP-FDRV96EH

[SAP-K77GHAX Adjusting The Fan Speed](#)

Sanyo SAP-K77GHAX

[SAP-K71GJA Adjusting The Fan Speed](#)

Sanyo SAP-K71GJA

[SAP-K161GJA Adjusting The Fan Speed](#)

Sanyo SAP-K161GJA

[SAP-KMV91G-S Adjusting The Fan Speed](#)

Sanyo SAP-KMV91G-S

[SAP-K91A Adjusting The Fan Speed](#)

Sanyo SAP-K91A

[SAP-DMRV93GJ Adjusting The Fan Speed](#)

Sanyo SAP-DMRV93GJ

[SAP-URV246EH Adjusting The Fan Speed](#)

Sanyo SAP-URV246EH

This manual is also suitable for:

[Ts2432Xs1852Xs1822Ts4232Ts3632Ks3632](#) ... [Show all](#)