

Setting The Timer - Sanyo KS2432 Instruction Manual

Split system air conditioner; wall-mounted type ceiling-mounted type recessed type cool/fan model

1
2
Table Of Contents
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17

18
19
20
21
22
23
24



•

-

Troubleshooting

•

Bookmarks



ON I /OFF
OFF
ON
MODE
CLOCK
FLAP
HH
FAN SPEED
MM
ACL
TIME SET
SELECT
BATTERIES

1. How to set the present time


PM

2. How to set the OFF time

PM

01-201-17EG

Downloaded from




Setting the Timer

NIGHT
SETBACK

A/C
SENSOR

(Example) To set to 9:10 p.m.

1. Press the Program button (times.
2. Press displayed.
- Press the MM button until 10 is displayed.



(Example) When air conditioner is running, turning it off at 11:30 p.m.

1. Press the Program button (OFF
2. Press the HH button until PM 11 is displayed.
- Press the MM button until 30 is displayed.




3. Press the TIMER SELECT button once to set OFF time.

manuals search engine


Operation

OFF
CLOCK

the
HH
button
until



ManualsLib.com



OFF
CLOCK

Indication



ON
) three

The time indication alone
flashes.

The
display

PM

9
is
matically
except for the ":" symbol
after 10 sec.




ON
) once.

The
timer
time indications flash.

The display will change automatically show the present time after 10 sec.

The present are displayed.

OFF will auto-stop flashing and OFF back to time and 17



[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1
...
14
15
16
17
18
19
20
21

Quick Links:

[Features](#)

[Product Information](#)

[Names of Parts](#)

[Remote Control Unit](#)

[Care and Cleaning](#)

[Troubleshooting](#)

Related Manuals for Sanyo KS2432

[Air Conditioner Sanyo C2432A Installation Instructions Manual](#)

(50 pages)

[Air Conditioner Sanyo KS2432 Instruction Manual](#)

Split system air conditioner cool/fan model (24 pages)

[Air Conditioner Sanyo XS4232 Technical Data And Service Manual](#)

(66 pages)

[Air Conditioner Sanyo C4232 Technical Data & Service Manual](#)

Split system air conditioner (66 pages)

[Air Conditioner Sanyo KS3032 Service Manual](#)

Split system air conditioner (56 pages)

[Air Conditioner Sanyo KS3032 Service Manual](#)

(54 pages)

[Air Conditioner Sanyo C3032 Service Manual](#)

Split system air conditioner (54 pages)

[Air Conditioner Sanyo TS2432 Service Manual](#)

Split system air conditioner (48 pages)

[Air Conditioner Sanyo XS2432 Service Manual](#)

Split system air conditioner (48 pages)

[Air Conditioner Sanyo C1852 Service Manual](#)

Split system air conditioner (45 pages)

[Air Conditioner Sanyo XS1822 / CL1822 Service Manual](#)

Split system air conditioner (39 pages)

[Air Conditioner Sanyo PNR-XS2432 Installation Instructions Manual](#)

Split system air conditioner (27 pages)

[Air Conditioner Sanyo 18XLS52 Specifications](#)

Ductless split system air conditioners & heat pumps (3 pages)

[Air Conditioner Sanyo 24XS32A Submittal Sheet](#)

Indoor/outdoor ceiling recessed (4-way) air conditioner (3 pages)

[Air Conditioner Sanyo 30KS32A Specifications](#)

Wall mounted air conditioner (3 pages)

[Air Conditioner Sanyo 36TS32A Datasheet](#)

Ceiling suspended air conditioner (3 pages)

Related Content for Sanyo KS2432

[XS1271 Setting The Timer](#)

Sanyo XS1271

[COOL Setting The Timer](#)

Sanyo COOL

[SAP-KRV96EHDS Setting The Timer](#)

Sanyo SAP-KRV96EHDS

[SAP-KRV96EH Setting The Timer](#)

Sanyo SAP-KRV96EH

[SAP-CRV93EHN Setting The Timer](#)

Sanyo SAP-CRV93EHN

[SAP-KRV94EHDX Setting The Timer](#)

Sanyo SAP-KRV94EHDX

[KS1872 Setting The Timer](#)

Sanyo KS1872

[KMHS0972 Setting The Timer](#)

SANYO KMHS0972

This manual is also suitable for:

[Ts2432Xs1852Xs1822Ts4232Ts3632Ks3632](#) ... [Show all](#)