

Installation Location; Electrical Requirements; Safety Instructions - Sanyo KS2432 Instruction Manual

Split system air conditioner; wall-mounted type ceiling-mounted type recessed type cool/fan model

1

2

Table Of Contents

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18
19
20
21
22
23
24



•

-

Troubleshooting

•

Bookmarks



Installation Location

We recommend that this air conditioner be installed properly by qualified installation technicians in accordance with the Installation Instructions provided with the unit.

Before installation, check that the voltage of the electric supply in your home or office is the same as the voltage indicated on the nameplate.

Do not install this air conditioner where there are fumes or flammable gases, or in an extremely humid space such as a greenhouse. Do not install the air conditioner where excessively high heat-



WARNING

generating objects are placed.

To protect the air conditioner from heavy corrosion, avoid installing the

Avoid:

outdoor unit where salty sea water can splash directly onto it or in sulphurous air near a spa.

The unit may malfunction when the receiver in the indoor unit is

exposed to the inverter lamp light.

Electrical Requirements



WARNING

1. All wiring must conform to the local electrical codes. Consult your dealer or a qualified electrician for details.

2. Each unit must be properly grounded with a ground (or earth) wire or through the supply wiring.

3. Wiring must be done by a qualified electrician.

Power supply: 60 Hz, single-phase, 230/208 volts.

To warm up the system, the power mains

CAUTION

must be turned on at least five (5) hours before operation. Leave the power mains ON unless you will not be using this appliance for an extended period. (CL MODEL)

Safety Instructions

Read this Instruction Manual carefully before using this air conditioner.

If you still have any difficulties or problems, consult your dealer for help.



This air conditioner is designed to give you comfortable room

conditions. Use this only for its intended purpose as described in this Instruction Manual.

Never touch the unit with wet hands.

Never use or store gasoline or other flammable vapor or liquid near the air conditioner — it is very dangerous.

This air conditioner has no ventilator for intaking fresh air from

outdoors. You must open doors or windows frequently when you use gas or oil heating appliances in the same room, which consume a lot of oxygen from the air. Otherwise there is a risk of suffocation in an extreme case.

CAUTION

Do not turn the air conditioner on and off from the power mains switch.



WARNING

Use the ON/OFF operation button.

Do not stick anything into the air outlet of the outdoor unit. This is dangerous because the fan is rotating at high speed.

Do not let children play with the air conditioner.

Do not cool the room too much if babies or invalids are present.

manuals search engine

Power mains

ON

01-201-04EG

[Table of Contents](#)

[Previous Page](#)

[Next Page](#)

1
2
3
4
5
6
7
8

Quick Links:

[Features](#)

[Product Information](#)

[Names of Parts](#)

[Remote Control Unit](#)

[Care and Cleaning](#)

[Troubleshooting](#)

Related Manuals for Sanyo KS2432

[Air Conditioner Sanyo C2432A Installation Instructions Manual](#)

(50 pages)

[Air Conditioner Sanyo KS2432 Instruction Manual](#)

Split system air conditioner cool/fan model (24 pages)

[Air Conditioner Sanyo XS4232 Technical Data And Service Manual](#)

(66 pages)

[Air Conditioner Sanyo C4232 Technical Data & Service Manual](#)

Split system air conditioner (66 pages)

[Air Conditioner Sanyo KS3032 Service Manual](#)

Split system air conditioner (56 pages)

[Air Conditioner Sanyo KS3032 Service Manual](#)

(54 pages)

[Air Conditioner Sanyo C3032 Service Manual](#)

Split system air conditioner (54 pages)

[Air Conditioner Sanyo TS2432 Service Manual](#)

Split system air conditioner (48 pages)

[Air Conditioner Sanyo XS2432 Service Manual](#)

Split system air conditioner (48 pages)

[Air Conditioner Sanyo C1852 Service Manual](#)

Split system air conditioner (45 pages)

[Air Conditioner Sanyo XS1822 / CL1822 Service Manual](#)

Split system air conditioner (39 pages)

[Air Conditioner Sanyo PNR-XS2432 Installation Instructions Manual](#)

Split system air conditioner (27 pages)

[Air Conditioner Sanyo 18XLS52 Specifications](#)

Ductless split system air conditioners & heat pumps (3 pages)

[Air Conditioner Sanyo 24XS32A Submittal Sheet](#)

Indoor/outdoor ceiling recessed (4-way) air conditioner (3 pages)

[Air Conditioner Sanyo 30KS32A Specifications](#)

Wall mounted air conditioner (3 pages)

[Air Conditioner Sanyo 36TS32A Datasheet](#)

Ceiling suspended air conditioner (3 pages)

Related Content for Sanyo KS2432

[SAP-K91AA Installation Location](#)

Sanyo SAP-K91AA

[SAP-FDRV96EH Installation Location](#)

Sanyo SAP-FDRV96EH

[SAP-K77GHAX Installation Location](#)

Sanyo SAP-K77GHAX

[SAP-K71GJA Installation Location](#)

Sanyo SAP-K71GJA

[SAP-K161GJA Installation Location](#)

Sanyo SAP-K161GJA

[SAP-KMV91G-S Installation Location](#)

Sanyo SAP-KMV91G-S

[SAP-K91A Installation Location](#)

Sanyo SAP-K91A

[SAP-DMRV93GJ Installation Location](#)

Sanyo SAP-DMRV93GJ

This manual is also suitable for:

[Ts2432Xs1852Xs1822Ts4232Ts3632Ks3632](#) ... [Show all](#)