



# M.2 Anchor Installation - Asus PRIME H310M-E Manual



1
2
Table Of Contents
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17

18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28



•

•

## Bookmarks







## Installing a DIMM



To remove a DIMM

## M.2 Anchor Installation

The M.2 Anchor is a tool-less design to easily fasten and secure your M.2 SSD card to your motherboard without using extra tools.

To install the M.2 SSD card using the M.2 Anchor:

1.




Locate the M.2 mounting hole on your motherboard and firmly insert the M.2 Anchor into the hole.

2.

Insert the M.2 SSD card into the M.2 slot. The notch at the end of the M.2 SSD card shall align with the rod of the M.2 Anchor.

ASUS PRIME H310M-E



1-9

[Table of Contents](#)

[Previous Page](#)  
[Next Page](#)

1  
...  
14  
15  
16  
17  
18  
19  
20  
21

Quick Links:

[Table of Contents](#)

[Prime H310M-E Specifications Summary](#)

[Motherboard Overview](#)

[Rear Panel Connectors](#)

[M.2 Anchor Installation](#)

[Bios Setup Program](#)

## Related Manuals for Asus PRIME H310M-E

[Motherboard Asus PRIME H310M-E Quick Start Manual](#)

(2 pages)

[Motherboard Asus PRIME H310M-E R2.0 Manual](#)

(28 pages)

[Motherboard Asus PRIME H310M-A User Manual](#)

(29 pages)

[Motherboard Asus PRIME H310M-A R1.0 Instruction Manual](#)

(29 pages)

[Motherboard Asus Prime H310M-C Manual](#)

(28 pages)

[Motherboard Asus PRIME H310M-C R2.0 Manual](#)

(28 pages)

[Motherboard Asus PRIME H310M-F R2.0 Manual](#)

(25 pages)

[Motherboard Asus PRIME H310M-R R2.0 Manual](#)

(25 pages)

[Motherboard Asus TUF H310M-PLUS GAMING R2.0 Manual](#)

(27 pages)

[Motherboard Asus PRIME H310M-D Manual](#)

(29 pages)

[Motherboard Asus PRIME H310M-DASH Manual](#)

(27 pages)

[Motherboard Asus PRIME H310M-A R2.0 Manual](#)

(29 pages)

[Motherboard Asus PRIME H310M-DASH R2.0 Manual](#)

(26 pages)

[Motherboard Asus PRIME H310M-AT R2.0 Manual](#)

(29 pages)

[Motherboard Asus H310M-IM-A Manual](#)

(66 pages)

[Motherboard Asus PRIME H310M-C/PS R2.0 Manual](#)

(54 pages)

## Related Content for Asus PRIME H310M-E

[PRIME A320M-E M.2 Anchor Installation](#)

Asus PRIME A320M-E

[PRIME B450M-K M.2 Anchor Installation](#)

Asus PRIME B450M-K

[PRIME B365M-K M.2 Anchor Installation](#)

Asus PRIME B365M-K

[PRIME H310M-A M.2 Anchor Installation](#)

Asus PRIME H310M-A

[PRIME B760M-AJ Cpu Installation](#)

Asus PRIME B760M-AJ

[ROG CROSSHAIR VIII HERO Installation Tools And Components](#)

Asus ROG CROSSHAIR VIII HERO

[Z790-AYW OC WIFI Cpu Installation](#)

Asus Z790-AYW OC WIFI

[Pro Q670M-CE Cpu Installation](#)

Asus Pro Q670M-CE

Save PDF