



Asus ASUSPRO Ultra User Manual

1
2

--


•

Bookmarks

--

[Download this manual](#)

Quick Links



Enlarged version

ASUSPRO Ultra

Docking Station

User Guide

15060-63700000

E10613 ASUSPRO Ultra 6.0 User Guide V2

Hardware features

Top View

Power adapter

indicator

Switch

USB connector with docking pins

Docking hooks

Docking stand

Power button with LED indicator

Bottom View

12" Notebook PC

Rubber feet lock

14" and 15" Notebook PC

Model switch

Adjustable rubber feet

Rear View

Power input port

LAN port

USB 3.0 with USB Charger

Microphone output jack port

USB 3.0 ports

VGA port

Headphone output jack port

Displayport

HDMI port

Left Side

Right Side

Key lock

Kensington® Security slot

Safety notices

ASUSPRO Ultra Docking Station

WARNING!

The bottom of the ASUSPRO Ultra Docking Station can get warm to hot while in use or while charging the battery pack. When working on your ASUSPRO Ultra Docking Station, do not place it on surfaces that can block the vents.

CAUTION!

This ASUSPRO Ultra Docking Station should only be used in environments with ambient temperatures between 5°C (41°F) and 35°C (95°F).

Refer to the rating label on the bottom of your ASUSPRO Ultra Docking Station and ensure that your power adapter complies with this rating.

The power adapter may become warm to hot while in use. Do not cover the adapter and keep it away from you.


Docking your Notebook PC

2015/7/15


10:20:43

Hardware features


Top View



Bottom View



Rear View



Left Side



Right Side



Safety notices for your ASUSPRO Ultra Docking Station

WARNING!

The bottom of the ASUSPRO Ultra Docking Station can get warm to hot while in use or while charging the battery pack. When working on your ASUSPRO Ultra Docking Station, do not place it on surfaces that can block the vents.

CAUTION!

- This ASUSPRO Ultra Docking Station should only be used in environments with ambient temperatures between 5°C (41°F) and 35°C (95°F).
- Refer to the rating label on the bottom of your ASUSPRO Ultra Docking Station and ensure that your power adapter complies with this rating.
- The power adapter may become warm to hot while in use. Do not cover the adapter and keep it away from your body while it is connected to a power source.

[Next Page](#)

1
2

Related Manuals for Asus ASUSPRO Ultra

[Docking Station Asus ADSU001 Quick Start Manual](#)

Professional dock (96 pages)

[Docking Station Asus DC300 User Manual](#)

Triple display usb-c dock (84 pages)

[Docking Station Asus Power Station II V2.0 User Manual](#)

(13 pages)

[Docking Station Asus XG Station PRO Quick Start Manual](#)

(15 pages)

[Docking Station Asus USB2.0_HZ-1 DOCKING-STATION User Manual](#)

Usb 2.0 docking station (140 pages)

[Docking Station Asus DC200 User Manual](#)

Dual 4k usb-c dock (74 pages)

[Docking Station Asus ROG XG MOBILE Service Manual](#)

(17 pages)

[Docking Station Asus HZ-1 User Manual](#)

Usb 3.0 docking station (194 pages)

[Docking Station Asus T100 Series User Manual](#)

Mobile dock (6 pages)

[Docking Station Asus XG Station Quick Installation Manual](#)

Asus xg station quick installation guide q3493 (150 pages)

[Docking Station Asus HZ-3A User Manual](#)

Usb 3.0 hz-3a docking station (186 pages)

[Docking Station Asus DC100 User Manual](#)

Usb-c mini dock (84 pages)

[Docking Station Asus ROG XG-Station 2 Quick Start Manual](#)

External graphics card dock (112 pages)

[Docking Station Asus TwinView Dock User Manual](#)

(116 pages)

[Docking Station Asus PadFone Station Quick Start Manual](#)

Padfone station quick start guide (16 pages)

Summary of Contents for Asus ASUSPRO Ultra

[Page 1: Docking Station](#)

ASUSPRO Ultra Docking Station WARNING! The bottom of the ASUSPRO Ultra Docking Station can get warm to hot while in use or while charging the battery pack. When working on your ASUSPRO Ultra Docking Station, do not place it on surfaces that can block the vents.

[Page 2](#) EN 301 489-1 V1.9.2(2011-09) EN 300 440-1 V1.6.1(2010-08) EN 301 489-3 V1.4.1(2002-08) ASUS will only be responsible for or indemnify you for loss, damages or claims based in contract, tort or EN 300 440-2 V1.4.1(2010-08) EN 301 489-4 V1.4.1(2009-05) infringement under this Warranty Statement.