

Asus X00ADC User Manual


Bookmarks


•

Download this manual

Quick Links







Speaker NOTES: Remove the rearrange of the speake dual micro SIM and microSD card slots.	۲	
The micro SIM card slots support LTE, WCDMA, and GSM/EDGE network bands.	First Edition / April 2016	Side features
The microSD card slot supports microSD and microSDHC card formats. 1. Locate the groove on the bottom-right corner of your ASUS Phone.	Model: ASUS_X00ADC (ZBS00KL)	Power key Audio jack
ASOS FIGURE. 2. Pry the cover loose and then pull the rear cover off. 3. Remove the battery. ASUS Phone 1. 1. 2016/7/20 11:16:15	Before you start, ensure that you have read all the safety information and operating instructions in this User Guide to prevent injury or damage to your device. NOTE: For the latest updates and more detailed information, please visit <u>www.asus.com</u> .	

1 2

Related Manuals for Asus X00ADC

Telephone Asus Go ZB500KL User Manual (32 pages) Cell Phone Asus X00BD User Manual Zb500kg (84 pages) Cell Phone Asus X00BD User Manual (23 pages) Cell Phone Asus ZenFone 3 Max User Manual (24 pages) Cell Phone Asus X014D User Manual (20 pages) Cell Phone Asus X017DA User Manual (20 pages) Cell Phone Asus ZenFone Max Pro ZB601KL User Manual (73 pages) Cell Phone Asus ZB552KL User Manual (111 pages) Cell Phone Asus X00QSA User Manual (20 pages) Cell Phone Asus X009DD User Manual (107 pages) Cell Phone Asus Padfone X Station (T00DP) Important Notice (13 pages) Cell Phone Asus M307 M307 Owner's Manual Asus cell phone owner's manual (78 pages) Cell Phone Asus AI220 User Manual (43 pages) Cell Phone Asus ROG PHONE 8 User Manual (87 pages) Cell Phone Asus Zenfone 9 User Manual (83 pages)

Summary of Contents for Asus X00ADC

Page 1: User Guide

Installing a microSD card your device. • Using the bundled power adapter and ASUS Phone To install a microSD card: signal cable to connect your ASUS Phone to a power outlet is the best way to charge your ASUS Phone. • The input voltage range between the wall outlet and this adapter is AC 100V - 240V. The output voltage of the micro USB cable is DC 5.2V, 1A/1.35A.

Page 2: Safety Information

Manual or website, and shall remain Semnătură Locul emiterii Local de emissão Assinatura 25/07/2016 Jerry Shen the exclusive property of ASUS and/or its licensors. Nothing in this Manual Jerry Shen 25/07/2016 Jerry Shen 25/07/2016 Nom en caractères d'imprimerie Date d'Emission not be placed in municipal waste.

This manual is also suitable for:

Zb500kl