



# Asus GK1100 Quick Start Manual

Mechanical keyboard



1  
2

|  |
|--|
|  |
|--|


•

Bookmarks

|  |
|--|
|  |
|--|

[Download this manual](#)

### Quick Links



Enlarged version



# GK1100 Mechanical Keyboard

English

## Package Contents

ASUS GK1100 keyboard x1  
Quick Start Guide x1  
ASUS Warranty Card x1  
Spare puller key cap puller x1, extra 13 key caps  
(... Q, W, E, R, A, S, D, F, ESC)

## Specifications Summary

### GK1100 Keyboard

456.5 x 148.5 x 23 mm (L x W x H)

10 / Windows

8.1 / Windows

8 / Windows

1080 ± 10g (with cable)

1935 ± 20mm

19mm / 2.2 ± 0.6mm of key travel / 4.5 - 0.5mm;

50 million keystrokes' lifespan

5V ± 0.25

## Installing your GK1100 Keyboard

Connect your keyboard to the USB port on your computer.

## Replacing the Key Caps

2. Replace with extra key cap(s).  
1. Use a key cap puller to take out the ...  
Q, W, E, R, A, S, D, F, ESC key cap(s).

## Hotkeys

FN + Previous track

Multi media

When selected, these buttons become playback controls.

FN + Play/Pause

function

buttons in an audio media player.

FN + Next track

LED backlight

FN +

Press to adjust the brightness of the keyboard backlight

OR

brightness

(Level 1-4).

LED lighting

FN +

Press to adjust the lighting mode rotate frequency (Level

LED function

mode rotate

OR

1-4).

frequency

Press these hotkeys to switch among the 7 preset

FN +

lighting modes. Press FN + 0 to turn off the LED.

Lock/Unlock

FN +

Windows®

Press to lock / unlock the Windows® Key.

Key

Other

CapLock key

functions

Press to enable / disable the Capital Lock function.

SL key

Press to enable / disable the Scroll Lock function.

NUM key

Press to enable / disable the Number Keypad.

ASUS

Customizing your keyboard (Macro commands, Button functions, Lighting

and others)

Go to the ASUS website at [www.asus.com](http://www.asus.com) to download and install the latest keyboard driver to

customize your keyboard's macro commands, button functions, lighting, and other functions.

7 / Windows

XP

Fransais

Clavier GK1100 x1

Guide de démarrage rapide x1

Carte de garantie ASUS x1

4.4 mm de distance d'activation

extracteur de capuchons de

touches x 1, 13 capuchons de

touches supplémentaires (...)

A, Z, E, R, Q, S, D, F, ESC

Caractéristiques

Nom du modèle : clavier GK1100

Dimensions : 456.5 x 148.5 x 23

mm (L x l x H)

5 système d'exploitation : Windows®

10 / Windows® 8.1 / Windows® 8 /

Windows® 7 / Windows® XP

Poids : 1080 ± 10g (avec câble)

Longueur du câble : 1935 ± 20mm

D distance d'activation

des touches : 19mm / 2.2 ±

0.6mm de distance d'activation

des touches / 4.5 - 0.5mm; durée

de vie de 50 millions de frappes

Tension nominale : 5V ± 0.25

Connectez le clavier au port USB

de votre ordinateur.

1.

Utilisez l'extracteur de

capuchons de touches pour

retirer les touches (...)

A, Z, E, R, Q, S, D, F, ESC

2. Remplacez-les par des

capuchons de touches

supplémentaires.

Fonctions multimédia :

FN +

(Piste précédente)

ManualsLib.com

ManualsLib.com

FN +  
(Lecture/Pause)  
FN +  
(Play/Pause)  
Simuler les boutons de contrôle  
de votre lecteur multimédia.

Fonctions d'éclairage :  
FN +  
ou  
(Luminosité)

(Luminosité)  
du rétro-éclairage) : Régle la  
luminosité du rétro-éclairage du  
clavier (Niveau 1-4).

FN +  
ou  
(Fréquence de  
rotation du mode d'éclairage  
LED) : Régle la fréquence de  
rotation du mode d'éclairage  
(Niveau 1-4).

FN +  
: Appuyez  
sur ces touches d'accrocs  
pour basculer entre les modes  
d'éclairage prédéfinis.

FN + 0 pour désactiver l'éclairage.  
Autres fonctions :

FN +  
(Verrouillage)  
déverrouillage de touche  
Windows® : Verrouille /  
déverrouille la touche Windows®.

Touche de verrouillage des  
majuscules : Active / désactive  
la fonction de verrouillage des  
majuscules.

Touche d'arrêt du défilement :  
Active / désactive la fonction de  
défilement.

Touche de verrouillage  
numérique : Active / désactive le  
pavé numérique.

Visitez le site Web d'ASUS www.  
asus.com pour télécharger et  
installer la dernière version du  
pilote de votre clavier pour  
profiter pleinement de toutes ses  
fonctionnalités.

Q12730 / Revised Edition / March 2017  
Italiano  
Русский

• Клавиатура ASUS QK1100 x1  
• Tastiera ASUS QK1100 x1  
• Краткое руководство x1  
• Guida rapida x1  
• Certificato di garanzia ASUS x1  
• Garantijski list ASUS x1  
• K it ricambi / Ricambi tasti x1, 13  
• K omlještva / Omlještva :  
съемник, 13 дополнительных  
tasti aggiuntivi / Extra (...,  
клавиша (...), O, W, E, R, A, S,  
O, W, E, R, A, S, O, F, ESC,  
O, F, ESC)  
le spre  
ИКАИ

• D imensjon: 148,5 x 148,5 x 23  
mm (L x P x H)  
(D x W x H)  
• S istemi operativi supportati:  
• П оддержка операционных ОС:  
Windows® 7, Windows® 8.1,  
Windows 10, Windows 8.1,  
Windows® 7 / Windows® 7 /  
Windows 8 / Windows 7 /  
Windows 8 / XP

Windows XP  
• Peso: 1080 ± 10g (con cavo)  
• Вес: 1080 ± 10g (с кабелем)  
• Lunghezza cavo: 1935 ± 20mm  
• Длина кабеля: 1935 ± 20mm  
• P orte USB (con cavo)  
• D istanza tasti/Corsa tasti/Asse:  
19mm (2,2 ± 0,6mm / 4,5 - 0,5  
19mm) / corsa: 2,2 ± 0,6mm / 4,5 -  
mm; срок службы 50 миллионов  
0,5mm; durata 50 milioni di click  
нажатий

• Specifiche: 5V ± 0,25  
• Parametri: 5B ± 0,25

Подключите клавиатуру к  
Collega la tastiera alla porta USB  
разъему USB компьютера.  
del computer.

1. ASUS  
1. Usa l'istruttoria tasti per  
(..., O, W, E, R, A, S, O, F, ESC,  
estrazione tasti (...), Q,  
помощью съемника.  
(..., O, W, E, R, A, S, O, F, ESC,  
2. Занесите их  
2. Sostituisci i tasti.  
дополнительными  
клавишами

Funzioni multimediali:  
Мультимедийные функции:  
FN +  
(Trasce presentate)  
FN + (Precedente/dorogka)  
FN +  
(Riproduci/pausa)  
FN + (Воспроизведение)  
FN +  
(Trasce successiva)  
(Play)

Se selezioni questi pulsanti  
FN + (Cassa/dorogka)  
forniscono controlli per la  
riproduzione quando un lettore  
Quando выбран, эти кнопки  
multimediale è in esecuzione.  
становятся кнопками управления  
активным медиаплеером.

Funzioni LED:  
Подсветка  
FN +  
O  
(Luminosità  
retroilluminazione LED):  
FN + или (яркость  
Регуляла la luminosità della  
подсветки): Надавите для  
retroilluminazione (Livello 1-4)  
регулировки яркости подсветки  
клавиатуры (уровень 1 - 4).

FN +  
O

ManualsLib.com





aktivujte/deaktivujte číselnou  
klávesnici



Navštivte stránku ASUS na adrese  
[www.asus.com](http://www.asus.com) stáhněte a  
nainstalujte nejnovější ovladač  
klávesnice. Tento ovladač  
umožňuje přizpůsobovat příkazy  
makro klávesnice, funkce tlačítek,  
osvětlení a další funkce.



Next Page

1  
2

## Related Manuals for Asus GK1100

[Keyboard Asus GK1050 User Manual](#)

(21 pages)

[Keyboard Asus Cerberus User Manual](#)

Multi-color backlit gaming keyboard (8 pages)

[Keyboard Asus Cerberus User Manual](#)

Led backlit usb gaming keyboard (7 pages)

[Keyboard Asus Cerberus Quick Start Manual](#)

Mechanical rgb keyboard (48 pages)

[Asus TUF GAMING K5 - Mechanical Gaming Keyboard Quick Start Guide](#)

(article)

[Asus ROG STRIX SCOPE RX - Mechanical Gaming Keyboard Quick Start](#)

(article)

[Keyboard Asus Strix Tactic Pro User Manual](#)

(14 pages)

[Asus ROG Strix Scope RX TKL Wireless Deluxe Quick Start Guide](#)

(article)

[Keyboard Asus Cerberus MKII User Manual](#)

Multi-color backlit gaming keyboard (8 pages)

[Keyboard Asus ROG STRIX SCOPE TKL Quick Start Manual](#)

(3 pages)

[Keyboard Asus ROD STRIX SCOPE TKL GUNDAM LTD Quick Start Manual](#)

(2 pages)

[Keyboard Asus CERBERUS Quick Start Manual](#)

Led backlit usb gaming keyboard (46 pages)

[Keyboard Asus TUF GAMING K1 Quick Start Manual](#)

Membrane gaming keyboard (4 pages)

[Keyboard Asus CERBERUS Quick Start Manual](#)

Multi-color backlit gaming keyboard mkii (48 pages)

## Summary of Contents for Asus GK1100

[Page 1](#) для включения или отключения numérique : Active / désactive le klávesnici. цифровой клавиатуры. pavé numérique. Go to the ASUS website at [www.asus.com](http://www.asus.com) to download and install the latest keyboard driver to Personalizzare la tastiera Индивидуальная настройка Přizpůsobení klávesnice Personnaliser votre clavier customize your keyboard's macro commands, button functions, lighting, and other functions.

[Page 2](#) Przycisk skrótów 2. Înlocuiți cu capacele 2. Замініть на додаткові клавіші. Função multimédia: ASUS recycling and takeback programs come from our commitment to the highest standards for protecting our environment. We believe in providing Kisayol Tuşları Multimédia funció: suplimentare ale tastelor. Realice el cambio con las solutions for you to be able to responsibly recycle our products, batteries, other components, as well as the packaging materials.