Asus Lyra MAP-AC2200 Quick Start Manual

Tri-band wi-fi system

1
2

-

Available languages

EN

ES

Quick Links

See also: Quick Start Manual

Lyra

Quick Start Guide

1

2

Connect

Setup

Unplug your cable / DSL

modem*. Remove the

battery if it has one.

Download the free ASUS Lyra app.

* If you are using DSL

Launch the ASUS Lyra app on your mobile

internet, you will need

device, and follow the instructions in just

a username/password

a few moments.

from your internet

service provider (ISP) to

* Make sure your device supports BLE,

properly configure your

Bluetooth 4.0 or above.

router.

Connect your modem to Lyra with the

network cable provided.

Power on your cable / DSL modem, and

check your cable / DSL modem LED lights

to ensure the connection is active.

Plug in the power adapter to Lyra and

wait until the LEDs turn to solid white to

ensure that your Lyra is ready for setup.

Connect PC or mobile devices via WiFi

Primary Lyra

"ASUS_XX".

You will be guided through the Setup

Wizard. If not, navigate to http://lyra.

asus.com.

Primary Lyra

3

Adding other Lyra to current network

1
App
2
Web GUI

Launch Lyra
Press the
the upper
until the LED
Lyra to current network and follow the
Press the Pairing button on the second Lyra
instructions to complete.
until the LED starts to flash green light, then
turns solid light cyan, indicating the pairing
process is completed.
Primary Lyra
* Pairing feature only works with the Primary Lyra
device connected to modem.

Colors

* While setting up through Web GUI, ensure that
you pair other Lyra hub(s) with the Primary Lyra
using the Pairing button.

Light Cyan
Everything is good

Red
Loss connection to the primary Lyra. Move it closer.

Orange
Loss connection to the internet. Please check the cable connected with your modem.

Solid White
Lyra is ready for setup. It will start blinking when setting up with the app.

Random Breathing
Lyra is booting up or applying settings.

S13319 / Primera edición/ Septiembre 2017

Related Manuals for Asus Lyra MAP-AC2200

[Wireless Access Point Asus Lyra MAP-AC2200 Quick Install Manual](#)

Tri-band wi-fi system (70 pages)

Summary of Contents for Asus Lyra MAP-AC2200

[Page 1](#) LED starts to blink green light. f or a class B dig ital device, pursuant to part 15 of the FCC Rules. The radiated output power of the ASUS Wireless Device is below * If you are using DSL for...

[Page 2](#) Restriction of Chemicals) regulatory framework, we published the XX_AMAPS". Abra un explorador web. Será ¡ Todo está correcto ! asocia otros miniconcentradores Lyra con su Lyra chemical substances in our products at ASUS REACH website at Lyra principal Primary Lyra redirigido al Asistente para configurar ASUS.