

# Sanyo FWSB415E A Setup Manual



1  
2  
3  
4


--

•

## Bookmarks

[Download this manual](#)

### Quick Links







REMARKS

Connections

Connect AC Power cord from Soundbar to an electric outlet.

Turn Soundbar On using Remote (POWER/Standby).

Alignez la barre de son à l'aide de la télécommande (MARCHÉ/Voie).

Verifiez la séquence de ledmiere des voyants DEL lorsque vous allumez l'appareil.

Rear of TV

The INPUT indicator lights up when you select your connected INPUT (e.g. OPTICAL).

Le voyant lumineux indique votre entrée sélectionnée (par ex. OPTICAL).

NOTE 5

- Make sure the Soundbar is Turned Off when Connecting Cables.
Check whether all Connection Cables are properly connected.
If you Connect from the Headphone Output on the Device's Source to the Line-Input on the Soundbar, make sure the Volume of the Headphone Output on the Device's Source is set to an appropriate mid-level sound. Setting it too Low will produce weak output from the Soundbar or setting it too High could cause distortion.
The line on the amplifier cannot be removed. Do not apply force to them.
The OPTICAL indicator continuously flashes when the Sound is heard from the Unit therefore it is not possible to change the INPUT of any input source signal on this Unit. Check your TV or other Audio output sources to ensure they are properly connecting a Digital audio input format such as Dolby Digital or DTS that are supported by the Unit. If the Dolby Digital or DTS is not supported, please refer to the supplied LINE IN cable.
Carefully position the Subwoofer Cable when you connect it to the Unit. Do not apply force to the cable.
DO NOT pull hard on the Subwoofer Cable when you connect it to the Unit. Do not apply force to the cable.

Trademark Information

The Bluetooth word mark and logo are registered trademarks owned by Bluetooth SIG, Inc. and any use of the marks by Funai Electric Co., Ltd. is under license. Other trademarks and trade names are those of their respective owners.

Le mot Bluetooth et le logo sont des marques déposées appartenant à Bluetooth SIG, Inc. et toute utilisation de ces marques par Funai Electric Co., Ltd. est sous licence. Les autres marques et noms commerciaux sont la propriété de leurs propriétaires respectifs.



Servicing

If this unit becomes inoperative, do not try to correct the problem by yourself. There are no user-serviceable parts inside. Place the Unit into Standby mode, Unplug the Power Plug and then please visit: sanyo-av.com/support

Caractéristiques générales

General Specifications



Table with 2 columns: Feature and Specification. Includes power requirements, output power, dimensions, and supported audio formats.



Press (Bluetooth icon) button on the Remote Control to switch the Soundbar to Bluetooth mode.
Appuyez sur la touche (icône Bluetooth) sur la télécommande pour faire passer la barre de son en mode Bluetooth.
Turn On your Bluetooth compatible device.
Alignez votre dispositif compatible Bluetooth.
On your Bluetooth compatible device search for and select 'SANYO\_Soundbar' to pair or register your Soundbar with your Bluetooth compatible device.

NOTE 5: If reconnecting the Bluetooth device to the Soundbar fails, delete the registered profile of this Soundbar from the Bluetooth device, then perform pairing again. This unit can store up to 9 device profiles.
Si la reconnexion du dispositif Bluetooth à la barre de son échoue, supprimez le profil enregistré de cette barre de son à partir du dispositif Bluetooth, puis effectuez à nouveau le pairing. Cet appareil peut stocker jusqu'à 9 profils de dispositif.

Warranty information and contact details for Sanyo. Includes phone numbers for customer support in various regions.



ManualsLib.com watermark

ManualsLib.com watermark

R  
B  
éplage du  
luetooth  
-----  
[PAGE]  
[PAGE] sur la  
D  
épannage

0160801 13339  
0240801 13339

[Next Page](#)

1  
2  
3  
4

## Related Manuals for Sanyo FWSB415E A

[Speakers Sanyo FWSB415E Owner's Manual](#)

(42 pages)

[Speaker System Sanyo FWSB415E Quick Start Manual](#)

(26 pages)

[Speaker System Sanyo FWSB415E Owner's Manual](#)

(24 pages)

[Speakers Sanyo FWSB405FS Setup Manual](#)

(2 pages)

[Speakers Sanyo FWSB426F Owner's Manual](#)

(24 pages)

[Speakers Sanyo FWSB426F Setup Manual](#)

(2 pages)

## Summary of Contents for Sanyo FWSB415E A

[Page 1](#) Si vous prévoyez utiliser des câbles audio analogiques coaxiaux rouges SANYO is a registered trademark of SANYO Electric Co., Ltd. and is used by Funai Electric Co., Ltd. and Funai Corporation, Inc.

[Page 2](#) WHAT IS NOT COVERED - EXCLUSIONS AND LIMITATIONS: Nettoyez uniquement avec un tissu sec. Communiquez avec le centre de service à la clientèle: sanyo-av.com No coloque la unidad sobre un mueble que pueda volcar si algún niño o adulto pièces d'ancrage Molly pour vous assurer que les vis ne ombent pas. Même This Limited Warranty applies only to new company manufactured products that can be Ne bloquez pas les ouvertures de ventilation.

[Page 3](#) SOUNDBAR onnections onnexion luetooth etting églage du luetooth Setup Manual Press (Bluetooth Icon) button on the Remote Control to switch the Soundbar to Bluetooth mode. Connect AC Power cord from Soundbar to an electric outlet. Use one of the Connection Methods shown below to Connect the Soundbar to your TV before plugging in the AC Power cord.

[Page 4](#) OF ALL OTHER LIABILITIES ON THE PART OF FUNAI, ALL OTHER WARRANTIES INCLUDING 12. Utilisez uniquement le chariot, le support, le trépied, la platine de CAN ICES-3 (B)/NMB-3(B) • Ne pas utiliser des vis plus longues ou plus courtes que leur longueur indiquée. ENGLISH ENGLISH ESPAÑOL...