



Toshiba RZE-BT700E Operation Manual

Wireless earphone, bluetooth

1
2

--


•

Bookmarks

--

[Download this manual](#)

Quick Links



RZE-BT700E

Wireless Earphone

Operation Manual

Thank you for purchasing this product.
To use this product safely, read and understand this operation manual thoroughly before using it. After reading this manual, please refer to the instructions used when necessary.

Safety precautions

The information you need to prevent danger to the user and other people as well as property damage is described below. "Description of signs" shows different categories of the degree of danger or damage that may occur due to wrong handling. "Description of symbols" shows the meaning of the symbols.

Important notes

- This book is only a guide for user's operation, not a criterion for configuration.
- Only use attachments/accessories specified by the manufacturer.
- The lightning flash is intended to alert the user to the presence of dangerous voltage within the product's enclosure, and touching the internal components may result in a risk of electric shock to persons. The exclamation mark is intended to alert the user to the presence of important operating instructions.

To reduce the risk of electric shock or fire, do not open the cover. Refer servicing to qualified service personnel.

Description of signs

Indicates that there is a risk of electric shock or fire.
Indicates that there is a risk of property damage.

Description of symbols

Indicates "Prohibition" or "You must"
Indicates "Mandatory Action" or "Do as
not do" with pictures and text.
Indicated" with pictures and text.

What to do in the case of an abnormality

- Stop using the device immediately in case of an abnormality or failure.
- Remove the USB cable immediately when water or any foreign object enters the interior of the device. It may cause a fire or electric shock. Remove the USB cable immediately, and contact your dealer for a repair.

Usage

Do not use this product while driving for traffic safety.

- Do not use the product while riding a bicycle or driving a car or motorbike.

Surrounding sounds may not be heard clearly, which may cause a traffic accident.
• Besides during driving, do not use the product in places where when surrounding sounds cannot be heard may be dangerous, such as railroad crossings, station platforms, roadways, or construction sites.

Do not disassemble, repair, or modify the product.

- Doing so may cause a fault. Contact your dealer for a repair.

Do not leave in places within the reach of small children.

- Small children might use the product by mistake and cause injury.

Do not expose the product to a strong shock, such as dropping or stepping on the product.

- Doing so may cause a fault.

Do not use the volume too high.

- Listening at ear-splitting volume for a long time may affect your hearing.

When using the product, turn down the volume until surrounding sounds can be heard clearly.

- Otherwise, it may cause hearing accident.

180530x3_RZE-BT700E_EN.indd

1

Notes on usage

About handling

- If you feel unwell while using the product, stop using it immediately.
- Do not place the product eyes, face, or head directly smoky, steamy places, near a heater, or in direct sunlight.
- Do not leave the product where it gets extremely hot such as in a car.
- Do not spray insecticide or any volatile material. Also do not keep the product touched with rubber or plastics for a long time. The product may become discolored or its painting may come off.

About static electricity precautions

When wearing the earphone, you may feel the sound and stimulus caused by static electricity.

In dry-weather seasons or places with dry air, static electricity likely occurs, you can reduce it by avoiding wearing clothes made of synthetic fiber, or using an antistatic rug.

About maintenance

- Wipe with a dry, soft cloth.
- If the ear piece gets dirty, take it off from the earphone and wash it with diluted neutral detergent by hand.
- Never use alcohol, paint thinner or benzine to clean this product. Doing so may cause the product's surface deterioration.

Rechargeable battery (Lithium polymer ion)

To reduce the risk of fire, electric shock or product damage,

- Do not attempt to replace the battery by yourself, it is built-in and is not changeable.

- Do not heat, disassemble, or short-circuit the battery. Doing so may cause the battery and power supply to generate heat, rupture, or ignite.

- Do not attempt to charge the battery in temperatures outside the temperature range of 0°C - 40°C.

- Do not continue charging the battery if it does not reach full charge within the specified charging time. Overcharging may cause the battery to become hot, rupture, or ignite.

- Do not expose the battery to excessive heat such as under the sun or near the fire or the like.

Overheat, leakage, or rupture may occur, resulting in burns or injury.

If you touch the battery fluid, rinse it off with water and consult with the doctor. If the battery fluid spills over the device, wipe it off without touching the fluid.

If you leave the unit unused for a long period of time, the built-in rechargeable battery will be in an over discharge state due to self discharge, and the charging capacity may deteriorate or the battery may be no longer rechargeable. Even if you are not using the unit, charge the battery once or twice a year for 1.5 hours each time.

Disclaimer

- Toshiba shall not be responsible for any damage caused by an earthquake, thunderstorm, flood damage, fire for which Toshiba is not responsible, acts of a third party, other accidents, or damages caused by the user's willful acts or negligence, misuse, or use in abnormal conditions.
- Toshiba shall not be responsible for any damage caused by failure to observe the instructions described in the operation manual.

Disposal

- When disposing of this device, observe the laws, or ordinances and rules of the local government.
- When disposing of the battery, make a request to a recycle agency for disposal.
- This product contains a built-in lithium ion rechargeable battery. There is a risk of injury due to fire, explosion or leakage if the battery is not used, handled, replaced or disposed of properly. Dispose of the battery as required by local ordinances or regulations. Do not disassemble, crush or expose the battery to fire or high temperatures.

This unit is designed for use with the HFP, HSP, SPP, A2DP and AVRCP stream specifications. For details, refer to the device's user manual or technical support to determine if your Bluetooth® device supports these profiles.

Frequency band used

This unit uses the 2.4 GHz frequency band. However other wireless devices may use 2.4 GHz frequency band as well and may cause interference with each other. To avoid interference, please refrain from the use of the unit at the same time with other wireless devices.

Certification of this device

This unit conforms to frequency restrictions and has received certification based on frequency laws, so a wireless permit is not necessary. However, the following action is punishable by law in some countries:

- Taking apart/modifying the unit.

Usage restrictions

- Wireless transmission and/or use with all Bluetooth® equipped devices is not guaranteed.
- A device featuring the Bluetooth® function is required to conform to the Bluetooth® standard specified by Bluetooth SIG, and be authenticated. Even if the connected device conforms to the above mentioned Bluetooth® standard, some devices may not be connected or work correctly, depending on Bluetooth® version or specifications of the device.

Range of use

Use this device within an unobstructed 10 m range. The range of use or perimeter may be shortened depending on any obstructions, devices causing interference, other people in the room, or the construction of the building. Please note that the range mentioned above is not guaranteed.

The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc. and are used under license.

Note

- This unit may receive radio interference caused by mobile telephones during use. If such interference occurs, please increase separation between this unit and the mobile telephone.

1 Charging case opening button

2 Charging status indicator for the case

3 Micro USB charging socket

4 Charging status indicator for the earphone

CAUTION



CAUTION



2 3 4
5

Multifunction button (Power on / Power off /
Answer a call / Answer a call / Reject a call)

6

6

Microphone / Earphone status indicator

5

7

Charging port

7

8

Charging pins

8

The earphones and the charging case have built-in lithium-ion polymer batteries. Charge them fully beforehand.

Charging the Earphones

1

Place each earphone in the charging case in the right position.

The earphone status indicator lights up on each earphone.

Note

• The earphone status indicator is turned off when fully charged.

Charging the Charging Case

1

Insert the supplied USB cable into the Micro USB charging socket on

the charging case.

2

Connect the USB cable to a USB port of your computer or a mobile

USB charger.

The charging status indicator for the case lights up in red.

Note

• The charging status indicator on the case is turned off when fully charged.

• When charging the earphones using the battery on the charging case, the charging status indicator for the earphones lights up in green.

Check the left and right, wear the ear piece in your ears.

• The one marked with "R" is for the right ear, and the one

marked with "L" is for the left ear.

• After use, take them off your ears carefully.

L

Caution

• Pressing the earphones against your ears roughly may hurt your

eardrums. Put on or take them off gently.

R

13-25-16



TOSHIBA

Bluetooth

CAUTION



CAUTION



CAUTION

CAUTION

CAUTION

[Next Page](#)

1
2

Related Manuals for Toshiba RZE-BT700E

[Headphone Toshiba RZE-BT700E User Manual](#)

True wireless stereo sweat-resistant bluetooth 4.1 earphones built-in microphone

(6 pages)

[Headphone Toshiba RZE-BT900E Operation Manual](#)

Wireless earphone (2 pages)

[Headphone Toshiba RZE-BT900E Operation Manual](#)

Wireless earphone (4 pages)

[Headphone Toshiba RZE-BT31E Operation Manual](#)

Wireless earphone (2 pages)

[Headphone Toshiba RZE-BT1050E Instruction Manual](#)

(4 pages)

[Headphone Toshiba RZE-BT166H Operation Manual](#)

(6 pages)

[Headphone Toshiba T750E-R Operation Manual](#)

Wireless earphone (2 pages)

Summary of Contents for Toshiba RZE-BT700E

[Page 1](#) Description of symbols misuse, or use in abnormal conditions. Note • Toshiba shall not be responsible for any damage caused by failure to observe the Indicates "Prohibition" or "You must Indicates "Mandatory Action" or "Do as information described in the operation manual.

[Page 2](#) Turn on your mobile phone's Bluetooth function and search for the buttons for 3 seconds.) name "RZE-BT700E" to connect it. (once connected, "connected" is Once both of the earphones are turned on, they start to establish a connection between heard and then blue light flash slowly) the left and right earphones.