

TOSHIBA

Toshiba Strata DK16 User Manual

Add-on module and direct station selection console

1
2
Table Of Contents
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17



-

[Table of Contents](#)

•

Bookmarks

Quick Links

[Download this manual](#) See also: [System Administrator Manual](#), [Instruction and Installation Manual](#)



ADD-ON MODULE AND DIRECT STATION SELECTION CONSOLE USER GUIDE

Release 1

© COPYRIGHT 1993 TOSHIBA AMERICA INFORMATION SYSTEMS, INC.

All rights reserved. No part of this manual may be reproduced in any form or by any means — graphic, electronic, or mechanical, including recording, taping, photocopying, or the use of information retrieval systems — without express written

permission of the publisher of this material.

Issue 1, March 1993

[Table of Contents](#)

[Next Page](#)

1
2
3
4
5

Related Manuals for Toshiba Strata DK16

[Telephone System Toshiba Strata DK8 Installation And Maintenance Manual](#)

Digital key telephone systems (609 pages)

[Telephone Toshiba strata DK8 Installation Instructions Manual](#)

(584 pages)

[Telephone System Toshiba Strata DK 16 Installation And Maintenance Manual](#)

Toshiba digital key telephone systems installation and maintenance manual (321 pages)

[IP Phone Toshiba Strata DK 2000-series User Manual](#)

Toshiba digital telephone user guide (164 pages)

[IP Phone Toshiba DK User Manual](#)

Includes lcd, add-on module, and direct station selection console (163 pages)

[IP Phone Toshiba CT User Manual](#)

Includes lcd, add-on module, and direct station selection console (136 pages)

[Telephone Toshiba Strata DK User Manual](#)

Electronic telephone (134 pages)

[Handsets Toshiba Strata AirLink User Manual](#)

Integrated wireless handset (132 pages)

[Handsets Toshiba Strata AirLink Integrated Wireless Handset User Manual](#)

Toshiba integrated wireless handset user guide (131 pages)

[Cordless Telephone Toshiba Strata DK User Manual](#)

Cordless digital telephone (107 pages)

[Telephone Toshiba Strata DK8 User Manual](#)

Digital telephone (90 pages)

[Telephone Toshiba Strata DK System Administration Manual](#)

(60 pages)

[IP Phone Toshiba Strata DK User Manual](#)

Digital single line telephone (60 pages)

[Telephone System Toshiba Strata DK14 System Administrator Manual](#)

Strata dk digital business telephone systems (56 pages)

[Telephone Toshiba Strata DK8 User Manual](#)

Dk digital lcd telephone (48 pages)

[Telephone Toshiba Strata DK8 Quick Reference Manual](#)

Business telephone (9 pages)

Summary of Contents for Toshiba Strata DK16

[Page 1](#) USER GUIDE Release 1 © COPYRIGHT 1993 TOSHIBA AMERICA INFORMATION SYSTEMS, INC. All rights reserved. No part of this manual may be reproduced in any form or by any means — graphic, electronic, or mechanical, including recording, taping, photocopying, or the use of information retrieval systems — without express written permission of the publisher of this material.

[Page 2](#) Toshiba America Information Systems, Inc. disclaims any liability arising out of the failure to obtain such a license. Toshiba America Information Systems, Inc. reserves the right to change any of this information including, but not limited to, product characteristics and operating specifications, without prior notice.

[Page 3: Table Of Contents](#)

SUBJECT PAGE INTRODUCTION General Descriptioniii Add-on Module (ADM)—Strata DK8 and DK16iii Direct Station Selection (DSS) Button—Strata DK16 Only iii Organizationiii How to Use This Guide..... iv CHAPTER 1 ADD-ON MODULE 1-1 Feature Buttons 1-2 Button LED Indications

[Page 4](#) STRATA DK ADD-ON MODULE / DSS CONSOLE TABLE OF CONTENTS This page intentionally left blank.

[Page 5: Introduction](#)

INTRODUCTION GENERAL DESCRIPTION The Add-on Module (ADM) for Strata DK8 and DK16, and the Direct Station Selection (DSS) console for Strata DK16 enable you to process a heavy load of calls quickly and efficiently. ADD-ON MODULE (ADM)—STRATA DK8 AND DK16...

[Page 6: How To Use This Guide](#)

STRATA DK ADD-ON MODULE / DSS CONSOLE INTRODUCTION HOW TO USE THIS GUIDE Your DSS console's features are determined by assignments made in system programming. Your system administrator can provide details on DSS console button function assignments. Once you are aware of the features that are available to you, review each feature's description and operational procedure contained in this guide.

[Page 7](#) STRATA DK ADD-ON MODULE / DSS CONSOLE INTRODUCTION ACTION TEXT SPECIFIC INSTRUCTIONS ON HOW TO PERFORM A PROCEDURE ARE NUMBERED AND ENTERED IN THE LEFT-HAND COLUMN. CHAPTER TITLES STRATA DK ADD-ON MODULE/DSS CONSOLE ADD-ON MODULE TRANSFER TO AN IDLE STATION FIRST LEVEL HEADINGS You can transfer outside calls to an idle station.

[Page 9: Add-On Module](#)

2000-series telephone operating with a Strata DK8 or DK16 system. Figure 1-1 shows an illustration of the Strata DK8 and DK16 ADM button assignments. The Strata DK16 DSS button assignments are fixed and cannot be changed. The Strata DK8 button assignments for the following are also fixed and cannot be changed: DSS (10-19), Speed Dial (SD10 ~ 17), All Call Page, and Night Transfer button.

[Page 10: Feature Buttons](#)

DSS buttons are used to call a station or transfer an outside call to a station. A label identifies the station associated with each DSS button. The ADM for Strata DK16 is equipped with 20 Direct Station Selection (DSS) buttons. Each button has a label that identifies the station that is associated with the button.

[Page 11: Transfer To An Idle Station](#)

STRATA DK ADD-ON MODULE / DSS CONSOLE ADD-ON MODULE TRANSFER TO AN IDLE STATION You can transfer outside calls to an idle station. To Transfer an outside call to an idle station: 1. Press the DSS button The outside line is placed on hold automatically. The Line LED will flash corresponding to the station to green at double the on-hold rate, and the DSS LED will flash green.

[Page 12: Speed Dial](#)

STRATA DK ADD-ON MODULE / DSS CONSOLE ADD-ON MODULE 2. Hang up. The outside line will ring the called station once with the camp-on tone after you hang up. While the called station is receiving this tone, the Line LED will flash green at the on-hold rate, and the DSS LED will remain steady red.

[Page 13: Dss Console](#)

SD33 SD43 SD12 SD22 SD32 SD42 SD11 SD21 SD31 SD41 SD10 SD20 SD30 SD40 Console

button assignments for the DK16 are flexible and may be changed by service personnel. Figure 2-1 Strata DK16 Initialized DDSS Console Button Assignments (DDSS2060 shown)

[Page 14: Feature Buttons](#)

STRATA DK ADD-ON MODULE / DSS CONSOLE DSS CONSOLE FEATURE BUTTONS The DSS console has 60 buttons which can be assigned with any of the following features: All Call Page Press the All Call (or AC) button to page a group of telephone speakers assigned in system programming.

[Page 15: Dss Button Operation](#)

STRATA DK ADD-ON MODULE / DSS CONSOLE DSS CONSOLE The LEDs will light red during all other conditions. The LEDs of the HDSS6560 model DSS console are always red when lit, no matter what the condition. Status distinctions are indicated by different flash rates. NOTE: The LED color indications described in this chapter apply specifically to the DDSS2060 and DDSS1060 models.

[Page 16: Call Answering \(Co Line Or Intercom\)](#)

STRATA DK ADD-ON MODULE / DSS CONSOLE DSS CONSOLE CALL ANSWERING (CO LINE OR INTERCOM) Use the same procedures as with a digital or electronic telephone. See the Digital or Electronic Telephone User Guides for more details. DSS CONSOLE CALL FORWARD OVERRIDE Either your telephone or your DSS console can be set in system programming to ring stations that are in the Call Forward mode, instead of being forwarded.

[Page 17: Date/Time/Day Adjustment](#)

STRATA DK ADD-ON MODULE / DSS CONSOLE DSS CONSOLE Different ringing patterns are chosen by pressing the Night button (or the Night 1 or Night 2 button; see notes that follow). Each ringing pattern has distinct CO line-to-station ringing assignments. Depending upon system programming, either two or three ringing patterns are available.

[Page 18: Time Setting](#)

STRATA DK ADD-ON MODULE / DSS CONSOLE DSS CONSOLE TIME SETTING To set the Time: 1. Make sure the handset is on-hook. 2. Press the Intercom button Listen for confirmation tone. and dial 6 5 2. 3. Enter the time in the 24-hour HHMMSS = Hour/Minutes/Seconds.

This manual is also suitable for:

[Strata dk8](#)