Introduction; General Description; Add-On Module (Adm)-Strata Dk8 And Dk16; Organization - Toshiba Strata DK16 User Manual

Add-on module and direct station selection console

```
Table Of Contents
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
```

Table of Contents







Introduction

GENERAL DESCRIPTION

The Add-on Module (ADM) for Strata DK8 and DK16, and the Direct

Station Selection (DSS) cancels for Strate DK16 anable you to process a

heavy load of calls quickly and emciently.

ADD-ON MODULE (ADM)—STRATA DK8 AND DK16

The ADM attaches to a 2000-series Digital Telephone to provide the following: For Strata DK8, it provides 10 DSS buttons, eight Speed Dial buttons, a Night Transfer button, and an All Call Page button. For Strata

DK16, it provides 20 Direct Station Selection (DSS) buttons. With a DSS button, you can call a station or transfer outside calls to stations with just the push of a button. Each DSS button is associated with a particular station and has an LED which indicates whether the station is busy or idle.

DIRECT STATION SELECTION (DSS) CONSOLE—STRATA DK16 ONLY
The DSS console operates alongside a digital telephone (2000 or 1000 series), or an electronic telephone for a dedicated answering position.
The DSS console has 60 buttons which allow immediate access to features frequently used by an attendant. In addition to having DSS buttons (like the A

Speed Dial buttons, an All Call Page button, and a Night Transfer button.

ORGANIZATION

This user guide is divided into the following sections:

The Introduction provides a general description of the Strata DK8 and DK16 ADM, and the DK16 DSS console. It also describes the organization of this user guide and offers suggestions on how to use it. Chapter 1, "Add-on Module," contains a description and operating instructions for the ADM. The instructions explain how to access stations with the DSS buttons that appear on the ADM (as well as on the DSS console for Strata DK16). This chapter also provides an explanation of the DSS button LEDs/indications.

Chapter 2, "DSS Console," applies only to the Strata DK16 and contains operating procedures and an explanation of the LEDs/indications for the DSS console. (The DSS buttons on the DSS console operate like the DSS buttons on the ADM; so refer to Chapter 1 for DSS button operating procedures.)

iii

Table of Contents

Previous Page Next Page

Related Manuals for Toshiba Strata DK16

<u>Telephone System Toshiba Strata DK8 Installation And Maintenance</u> Manual

Digital key telephone systems (609 pages)

<u>Telephone Toshiba strata DK8 Installation Instructions Manual</u>

(584 pages)

<u>Telephone System Toshiba Strata DK 16 Installation And Maintenance</u> Manual

Toshiba digital key telephone systems installation and maintenance manual (321 pages)

IP Phone Toshiba Strata DK 2000-series User Manual

Toshiba digital telephone user guide (164 pages)

IP Phone Toshiba DK User Manual

Includes Icd, add-on module, and direct station selection console (163 pages)

IP Phone Toshiba CT User Manual

Includes Icd, add-on module, and direct station selection console (136 pages)

Telephone Toshiba Strata DK User Manual

Electronic telephone (134 pages)

Handsets Toshiba Strata AirLink User Manual

Integrated wireless handset (132 pages)

Handsets Toshiba Strata AirLink Integrated Wireless Handset User

Manual

Toshiba integrated wireless handset user guide (131 pages)

<u>Cordless Telephone Toshiba Strata DK User Manual</u>

Cordless digital telephone (107 pages)

Telephone Toshiba Strata DK8 User Manual

Digital telephone (90 pages)

Telephone Toshiba Strata DK System Administration Manual

(60 pages)

IP Phone Toshiba Strata DK User Manual

Digital single line telephone (60 pages)

Telephone System Toshiba Strata DK14 System Administrator Manual

Strata dk digital business telephone systems (56 pages)

Telephone Toshiba Strata DK8 User Manual

Dk digital lcd telephone (48 pages)

Telephone Toshiba Strata DK8 Quick Reference Manual

Business telephone (9 pages)

Related Content for Toshiba Strata DK16

Strata DK 2000 Series Introduction Organization

Toshiba Strata DK 2000 Series

STRATA CIX Introduction

Toshiba STRATA CIX

DKT3000 Series Introduction

Toshiba DKT3000 Series

DP5000-Series Introduction

Toshiba DP5000-Series

<u>IP4100 Series Introduction</u>

Toshiba IP4100 Series

Strata CIX IP5000-Series Introduction

Toshiba Strata CIX IP5000-Series

Strata CIX DP-5000 series Introduction

Toshiba Strata CIX DP-5000 series

Strata DK Introduction

Toshiba Strata DK

This manual is also suitable for:

Strata dk8