


Asus Zenfone ZE551KL User Manual


2								
•								



Download this manual	Quick Links	



Enlarged version



User Guide

E10822

Charging your ASUS Phone

To charge your ASUS Phone:

1. Connect the USB connector into the power adapter's USB port.

Connect the other end of the micro USB cable to your ASUS Phone.

a power outlet, the grounded power outlet must be near to the unit and easily accessible.

When charging your ASUS Phone through your computer, ensure that you plug the micro USB cable to your computer's USB 2.0 / USB 3.0 port.

Avoid charging your ASUS Phone in an environment with ambient temperature of above

35

C (95

NOTES:

Use only the power adapter that came with your device. Using a different power adapter may damage your device

Using the bundled power adapter and ASUS Phone signal cable to connect your ASUS Phone to a power outlet is the best way to charge your ASUS Phone

The input voltage range between the wall outlet and this adapter is AC 100V - 240V. The output voltage of the micro USB cable is DC +5.2V, 1A, 5W. First Edition/ August 2015

Model: ZE551KL (ASUS_Z00TD)
Before you start, ensure that you have read all the safety information and operating instructions in this User Guide to prevent injury or damage to your device. NOTE: For the latest updates and more detailed information, please visit www.asus.com.

Receiver LED indicator

Sensor Front camera Touch screen display

Touch keys Installing a micro SIM card

To install a micro SIM card:

Locate the groove on the bottom-right corner of ASUS Phone.

Pry the cover loose and then pull the

rear cover off 3. Remove the battery.

Side features

Audio jack

Power Key Groove Micro USB port

Microphone

NOTE: Pry open the rear cover from the groove. 4. Insert the micro SIM card into one of the micro SIM

card slots. Micro SIM card slot 2

Micro SIM/ microSD combo

card slot NOTE: The micro SIM card slot 1 is at the lower part of

the micro SIM/ microSD combo card slot.

IMPORTANT: Both micro SIM card slots support 3G WCDMA/ 4G LTE network band. But only one micro SIM card can connect to 3G WCDMA/ 4G LTE service


CAUTION: Do not use sharp tools or solvent on your device to avoid scratches on it.


Installing a microSD card

To install a microSD card:

Locate the groove on the bottom-right corner of your ASUS Phone.

Rear features

















Rear camera Camera flash Laser focus Volume key Rear cover Speaker NOTES:

Remove the rear cover to display the dual micro SIM and microSD card slots.

The micro/SIM card slots supportfUTE WCDMA, and GSM/EDGE network bands.

and GSM/EDGE network bands.


The microSD tard soc supports microSD and microSDHC card formats.

2.
Pry the cover tose and then pull the rear cover off.

3. Remove the battery.

4. Insert the microSD card into the microSD card slot. Micro SIM/ microSD combo card slot sat the upper part of the micro SIM/ microSD combo card slot.





Next Page
1 2

Related Manuals for Asus Zenfone ZE551KL

Cell Phone Asus Zenfone 2 Laser User Manual

(158 pages)

Smartphone Asus Zenfone 2 Laser ZE550KL User Manual

(158 pages)

Cell Phone Asus Zenfone 2 Laser ZE500KL User Manual

(158 pages)

Cell Phone Asus ZenFone 3 Product Manual

(85 pages)

Cell Phone Asus ZE553KL User Manual

(119 pages)

Cell Phone Asus Zenfone 4 User Manual

(100 pages)

Cell Phone Asus ZENFONE 2 User Manual

(161 pages)

Cell Phone Asus ZE550ML User Manual

(161 pages)

Cell Phone Asus ZenUI User Manual

(155 pages)

Cell Phone Asus X009DD User Manual

(107 pages)

Cell Phone Asus ZenFone Max Plus User Manual

(22 pages)

Cell Phone Asus A600CG User Manual

(154 pages)

Cell Phone Asus Zenfone 5 User Manual

(90 pages)

Cell Phone Asus Zenfone 2 Laser User Manual

(154 pages)

Cell Phone Asus Zenfone Max User Manual

(94 pages)

Cell Phone Asus Zenfone 10 User Manual

(85 pages)

Summary of Contents for Asus Zenfone ZE551KL

Page 1: User Guide

ASUS Phone. • Using the bundled power adapter and ASUS Phone signal cable to connect your ASUS Phone to a power outlet is the best way to charge your ASUS Phone. • The input voltage range between the wall outlet and NOTE: The microSD card slot is at the upper part of the this adapter is AC 100V - 240V. The output voltage...

Page 2: Ce Rf Exposure Compliance

• Do not remove and dispose of the battery in fire. It You acknowledge that all rights of this Manual remain with ASUS. Any to the OPERATOR by the use of the same TOOL, or and all rights, including without limitation, in the Manual or website, and could explode and release harmful

substances into DO NOT throw this product in fire. DO...