




# Sanyo A1303SA Operating Instructions Manual



1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18

19  
20  
21  
Table Of Contents  
22



•

•

## Bookmarks

[Download this manual](#)

## Quick Links





## FCC RF EXPOSURE INFORMATION

***WARNING! Read this information before using your phone***

In August 1996 the Federal Communications Commission (FCC) of the United States with its action in Report and Order FCC 96-326 adopted an updated safety standard for human exposure to radio frequency electromagnetic energy emitted by FCC regulated transmitters. Those guidelines are consistent with the safety standard previously set by both U.S. and international standards bodies. The design of this phone complies with the FCC guidelines and these international standards.

Use only the supplied or an approved antenna. Unauthorized antennas, modifications, or attachments could impair call quality, damage the phone, or result in violation of FCC regulations.

Do not use the phone with a damaged antenna. If a damaged antenna comes into contact with the skin, a minor burn may result. Please contact your local dealer for replacement antenna.



## Body-worn Operation

This device was tested for typical body-worn operations with the back of the phone kept 1.5 cm. from the body. To maintain compliance with FCC RF exposure requirements, use only belt-clips, holsters or similar accessories that maintain a 1.5 cm. separation distance between the user's body and the back of the phone, including the antenna, whether extended or retracted. The use of belt-clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

*For more information about RF exposure, please visit the FCC website at*

[www.fcc.gov](http://www.fcc.gov)

[Table of Contents](#)

Next Page

1  
2  
3  
4  
5

## Related Manuals for Sanyo A1303SA

[Cell Phone Sanyo A5514SA Basic Manual](#)

(104 pages)

[Cell Phone Sanyo A5514SA Operating Instructions Manual](#)

(30 pages)

[Cell Phone Sanyo A5527SA Basic Manual](#)

(92 pages)

[Cell Phone Sanyo au W22SA Basic Manual](#)

(106 pages)

[Cell Phone Sanyo SANYO Innuendo User Manual](#)

(140 pages)

[Cell Phone Sanyo Cell Phone User Manual](#)

Sprint pcs vision phone (256 pages)

[Cell Phone Sanyo Juno User Manual](#)

(115 pages)

[Cell Phone Sanyo SCP-3100 User Manual](#)

Pcs vision phone (270 pages)

[Cell Phone Sanyo VL-2300 Phone Manual](#)

Pcs vision phone (286 pages)

[Cell Phone Sanyo SCP-8100 User Manual](#)

Dual band/tri mode phone (71 pages)

[Cell Phone Sanyo SCP-2400 User Manual](#)

Sanyo cell phone user guide (140 pages)

[Cell Phone SANYO PRO -200 User Manual](#)

Mobile phone (3 pages)

[Cell Phone Sanyo PRO-200 User Manual](#)

Sanyo cell phone user guide (236 pages)

[Cell Phone Sanyo SCP-3810 Operating Manual](#)

(68 pages)

[Cell Phone Sanyo Sprint SCP-7200 User Manual](#)

Pcs vision ready link phone (197 pages)

[Cell Phone Sanyo SCP-2700 User Manual](#)

Sprint cell phone (160 pages)

## Summary of Contents for Sanyo A1303SA

### [Page 1: Fcc Rf Exposure Information](#)

FCC RF EXPOSURE INFORMATION WARNING! Read this information before using your phone In August 1996 the Federal Communications Commission (FCC) of the United States with its action in Report and Order FCC 96-326 adopted an updated safety standard for human exposure to radio frequency electromagnetic energy emitted by FCC regulated transmitters.

[Page 2](#) Operating Instructions Name & Function of Parts □ □ □ □ □ □ □ □ □ □ Antenna □ Incoming call light □ Blinks when the phone rings, and lights red during battery charging. Built-in camera (Lens) □ Used to take digital images. Built-in flash □...

[Page 3](#) External connection terminal Used to hear other party's voice, [ ] [ ] Used to connect an optional devices various messages. Display such as Sanyo DC adapter 01. [ ] [ ] Shows various settings, phone (End) key [ ] [ ] numbers. Used to turn on and off the power, to Flexible keys end a call, or to hold a call.

## [Page 4: Display Indications](#)

Display Indications Icons appear on the display to show the status of the handset. ● [ ] [ ] [ ] [ ] [ ]  
[ ] [ ] Secret is set [ ] 10:10 Secret is temporarily set [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]  
[ ] [ ] [ ] [ ] Battery voltage level [ ]...

[Page 5](#) Invalidation of side key operation is set Character entry mode display [ ] [ ] [ ] [ ] Task time limit display (alarm is set) [ ] [ ] [ ] Kanji and hiragana characters Nothing will be displayed until 8 days before the set time [ ] [ ] [ ]...

[Page 6](#) ■ Power saving during standby In order to minimize the power consumption, the A1303SA display turns automatically to power saving mode when key operation is stopped for a while. The indication restores with key operation. ■ Using the flexible keys Each key is allocated to an item shown in the bottom of the display.

[Page 7](#) Sub-display Indications When the handset is closed, the sub-display tells the status of the handset. (The ● screens in this manual are somewhat different in fonts and shapes from actual ones.) [ ] [ ] [ ] [ ] [ ] 10/10Fri 10[ ]10 Battery voltage level Codes for roaming areas [ ]...

## [Page 8: Getting Ready To Make A Call](#)

1. Insert the connector of the Sanyo AC adapter 02 firmly into the desktop charging holder. 2. Connect the plug of the Sanyo AC adapter 02 into an AC wall outlet. 3. Put the telephone (A1303SA) with battery pack attached into the desktop charging holder, paying attention to the installing direction.

## [Page 9: Extending The Antenna](#)

Extending the antenna The radio waves cannot be transmitted or received well if the antenna is not extended. To facilitate transmission and reception of radio waves, use the phone by positioning the antenna vertically with respect to the ground. Extending the antenna Retracting the antenna ●...

[Page 10](#) Checking the display screen Check the display screen and make sure it is shown in the figure below after you turn the power on. This will indicate if the phone is in good working order. The availability of power is indicated in three levels. 10:10 [ ] [ ] [ ] [ ] [ ]...

## [Page 11: Switch To English](#)

Set up for first use 1. Just after you have bought the handset or you have initialized all functions and memories by performing M453 operation, press 2. Select " [ ] [ ] [ ] [ ] " and press 3. Press 4. Select "YES" and press [ ] [ ]...

## [Page 12: Making An International Call](#)

Calling to general, mobile and PHS phones 1. Enter the phone number you want to call. Area code - Local code - Subscriber's number. Example: 03-0001-XXXX Always include the area code, even when calling to a number in the same area you are in.

## [Page 13: Answering A Call](#)

Answering a call 1. The ringer tone sounds/vibrator buzzes, and the incoming call lamp flashes. 2. Press to answer the call. An incoming call can also be answered by pressing any of the ~ , or keys when M52: AnyKey Answer is set. If you do not answer the call or the caller disconnects before the call is answered, "Missed Call X"...

[Page 14](#) [Assignment of characters and key functions] Characters are assigned to each key as shown below. Press a key repeatedly to cycle through characters assigned to that key. "Kanji", "Hiragana" "Katakana" "Alphanumeric" "Number" "Phone entry mode (full size) (half size) (half size) (half size) number"...

## [Page 15: Registering In The Address Book](#)

Registering in the Address Book You can register frequently used phone numbers and E-mail addresses. Up to 500 addresses can be registered in the address book. ■ Registering in the address book 1. Press and hold for more than one second. The address book item list is displayed.

## [Page 16: Calling From The Address Book](#)

Calling from the Address Book You can make a call by using phone ■ Searching for a phone numbers saved in the Address Book. number using the dial keys There are 8 ways to search numbers You can make a call from a list of the saved in the Address Book.

[Page 17](#) 4. Select "Reading Search" and 8. Perform Steps 3 to 5 described press in "Searching for a phone number by scrolling".(→ Page 15) 5. Enter the first several characters of desired name. ■ Searching the address book 6. Press Search by history 7.

## [Page 18: List Of Basic Setup](#)

List of Basic Setup ■ M0 Profile Mode No. Function Description Profile Displaying own phone number and E-mail address ■ M1 Call/Toll Mode No. Function Description M11☆ Previous Call Displaying last call's estimated talk time and charge M12☆ Accum.Display Displaying estimated total talk time and charge M13☆...

[Page 19](#) ■ M3 Screen Mode No. Function Description Main Display Setting Main display M311\* Wall Paper Setting wallpaper on standby screen M312\* Screen-Saver Setting screen saver M313\* Mail Connect Setting E-mail, C-mail connection screen M314\* EZ Connect Setting EZweb connection screen M315 Power Saving Setting Power save screen Sub Display...

[Page 20](#) ■ M5 User Support Mode No. Function Description Char.Entry Setting character entry method M511 Entry Setup Setting character entry method/forecast conversion M512 Edit Format Editing formatted text M513 EditFaceMark Editing face marks M514 EditUsrDict. Registering/Editing User dictionary M515\* D/L Dict. Registering the dictionary downloaded from EZweb M516 Learning Clr Initializing learned information...

## [Page 21: Specifications](#)

■ NetworkService□M8□ Mode No. Function Description Voice Mail Answering message service M811 Play VoMail Listening to messages M812 VoMail1 ON Setting the answering message service 1 M813★ VoMail2 ON Setting the answering message service 2 M814 VoMail OFF Stopping the answering message service M815★...