



Sanyo 36K72R Dimensional Information

Wall mounted air conditioner

1

| |
|--|
| |
|--|

•

Bookmarks


[Download this manual](#)

Quick Links

Dimensional Data for 36K72R

Indoor unit : KH3672R

Indoor unit : Wall Mounted Type 30, 36 Type



Related Manuals for Sanyo 36K72R

[Air Conditioner Sanyo C4272R S/C Installation Instructions Manual](#)

Sanyo split system heat pump air conditioner installation instructions (111 pages)

[Air Conditioner Sanyo RCS-BH80UA.WL Instruction Manual](#)

Split system air conditioner (48 pages)

[Air Conditioner Sanyo 36TH72R Dimensional Information](#)

Sanyo air conditioner data sheet (1 page)

[Air Conditioner Sanyo 36TS32A Datasheet](#)

Ceiling suspended air conditioner (3 pages)

[Air Conditioner Sanyo 36U72R Dimensional Information](#)

Sanyo air conditioner data sheet (1 page)

[Air Conditioner Sanyo 36UW72R Specifications](#)

Concealed duct air conditioner (2 pages)

[Air Conditioner Sanyo 26UHW72R Specifications](#)

Concealed duct air conditioner & heat pump (2 pages)

[Air Conditioner Sanyo 36XLS32A Specifications](#)

Ceiling recessed (4-way) air conditioner (3 pages)

[Air Conditioner Sanyo KHS3672R Datasheet](#)

Wall mounted air conditioner (2 pages)

[Air Conditioner Sanyo KS3082 Instruction Manual](#)

Inverter-controlled split system air conditioner (36 pages)

[Air Conditioner Sanyo 36KS82 Submittal Data](#)

Split system wall mounted air conditioner (2 pages)

[Air Conditioner Sanyo THW3672R Specifications](#)

Ceiling suspended air conditioner (2 pages)

[Air Conditioner Sanyo 36T72R Dimensional Information](#)

Sanyo air conditioner data sheet (1 page)

[Air Conditioner Sanyo 24K12W Service Manual](#)

Split system air conditioner (102 pages)

[Air Conditioner Sanyo 24KS12W Service Manual](#)

Split system air conditioner (114 pages)

[Air Conditioner Sanyo 26 series Installation Instructions Manual](#)

Split system heat pump air conditioner (110 pages)