

Wiring Instructions - Sanyo C4272R S/C Installation Instructions Manual

Sanyo split system heat pump air conditioner installation instructions

1

2

3

4

5

Table Of Contents

6

7

8

9

10

11

12

13

14


15

16

17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111




•

[Table of Contents](#)

•

Bookmarks



Enlarged version

07-115 SSHP_II
5/7/07
4:00 PM

KHH(S)2672R

Tubing can be extended in 4 directions as shown in Fig. 3-54.

Arrangement for Left Tubing

(a) Cut out the left tubing outlet. (Fig. 3-55)

Arrangement for Right Tubing

(a) Cut out the right tubing outlet using a hacksaw. (Fig. 3-56)


Arrangement for Left-rear and Right-rear Tubing

(a) It is not necessary to cut a hole.

3-15. Wiring Instructions

General Precautions on Wiring

(1) Before wiring, confirm the rated voltage of the unit as shown on its nameplate, then carry out



- the wiring closely following the wiring diagram.
- (2) Provide a power outlet to be used exclusively for each unit. A power supply disconnect and circuit breaker for overcurrent protection should be provided in the exclusive line.
 - (3) To prevent possible hazards from insulation failure, the unit must be grounded.
 - (4) All wiring must be connected tightly.
 - (5) Do not allow wiring to touch refrigerant tubing, compressor, or any moving parts of the fan.

Page 42

Unauthorized changes in the internal wiring can be very dangerous. The manufacturer will accept no responsibility for any damage or misoperation that occurs as a result of such unauthorized changes.

Left tubing
 Left-rear tubing
 Left tubing outlet






Fig. 3-55
42

Right-rear tubing
 (Recommended)
 Right tubing

Fig. 3-54
 Right tubing outlet
Fig. 3-56



[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1
...
39
40
41
42
43
44
45
46

Quick Links:

[Indoor Unit](#)

[Trouble Diagnostics](#)

Related Manuals for Sanyo C4272R S/C

[Air Conditioner Sanyo C4272R Service Manual](#)

Sanyo split system air conditioner service manual (181 pages)

[Air Conditioner Sanyo CH1872 Technical & Service Manual](#)

Dc inverter split system air conditioner (111 pages)

[Air Conditioner Sanyo 26 series Installation Instructions Manual](#)

Split system heat pump air conditioner (110 pages)

[Air Conditioner Sanyo RCS-BH80UA.WL Instruction Manual](#)

Split system air conditioner (48 pages)

[Air Conditioner Sanyo C3072R Parts List](#)

Outdoor unit (4 pages)

[Air Conditioner Sanyo KH3672R Parts List](#)

Sanyo air conditioner parts list (4 pages)

[Air Conditioner Sanyo CH3672R Parts List](#)

Outdoor unit (4 pages)

[Air Conditioner Sanyo THHW3672R Parts List](#)

Sanyo air conditioner parts list (4 pages)

[Heat Pump Sanyo 26THW72R Specifications](#)

Ceiling suspended heat pump (2 pages)

[Air Conditioner Sanyo 26UW72R Specifications](#)

Concealed duct air conditioner (2 pages)

[Air Conditioner Sanyo 36KHS72R Datasheet](#)

Wall mounted heat pump (2 pages)

[Air Conditioner Sanyo 36UW72R Specifications](#)

Concealed duct air conditioner (2 pages)

[Air Conditioner Sanyo KHS3672R Datasheet](#)

Wall mounted air conditioner (2 pages)

[Air Conditioner Sanyo THW3672R Specifications](#)

Ceiling suspended air conditioner (2 pages)

[Air Conditioner Sanyo XHW2672R Specifications](#)

Ceiling recessed air conditioner (2 pages)

[Air Conditioner Sanyo 30K72R Dimensional Information](#)

Sanyo air conditioner data sheet (1 page)

Related Content for Sanyo C4272R S/C

[KMS0772 Wiring Instructions](#)

Sanyo KMS0772

[KHS0951 Wiring Instructions](#)

Sanyo KHS0951

[SAP-KRV9AEH Wiring Instructions For The Outdoor Unit](#)

Sanyo SAP-KRV9AEH

[SAP-KRV9AEH Wiring Instructions For The Outdoor Unit](#)

Sanyo SAP-KRV9AEH

[SAP-KMRV74EH Wiring Instructions](#)

Sanyo SAP-KMRV74EH

[26 series Wiring Instructions](#)

Sanyo 26 series

[COOL Wiring Instructions](#)

Sanyo COOL

[SAP-CMRV1424EH Wiring Instructions](#)

Sanyo SAP-CMRV1424EH

This manual is also suitable for:

[Ch4272r h/pUhw2672rUhw3672r26khs72r26ks72r26uhw72r ...](#) [Show all](#)