Placing The Unit Inside The Ceiling -Sanyo CH2442 Installation Instructions Manual

Split system heat pump air conditioner


(

Table of Contents

•

Bookmarks


•



3-3. Placing the Unit Inside the Ceiling

(1) When placing the unit inside the ceiling, determine the pitch of the suspension bolts using the supplied full-scale installation diagram. (Fig. 3-4) The size of the opening for the indoor unit can be confirmed by attaching the full-scale installation diagram beneath the unit. (Fig. 3-4) Tubing and wiring must be laid inside the ceiling when suspending the unit. If the ceiling is already constructed, lay the tubing and wiring into position for connection to the unit before placing the unit inside the ceiling.

(2) The length of suspension bolt must be appropriate for a distance between the bottom of the bolt



and the bottom of the ceiling of 19/32 in. or more as shown in Fig. 3-4.

(3) Thread the 2 hexagonal nuts (field supply) and washers onto the 4 suspension bolts as shown in Fig. 3-5.

Use 2 sets of nuts and washers (upper and lower), so that the unit will not fall off the suspension lugs.

(4) Remove the protective cardboard used to protect the fan parts during transport.

(5) Adjust the distance between the unit and surface of the ceiling. (1-7/8 in.) (Fig. 3-4)

Full-scale installation diagram (printed on a cardboard packing) Nuts and washers (Use above and below) Double nuts 15 S4359146 Full-scale installation diagram 2040_X_1

Fig. 3-4

Suspension bolt Suspension lug Upper Lower Notch 1-7/8 inch

Fig. 3-5

1971_X_I

Table of Contents

Previous Page Next Page

 Quick Links: Indoor Unit How to Install the Wired Remote...

Related Manuals for Sanyo CH2442

Air Conditioner Sanyo KH2442 / CH2442 Service Manual Split system air conditioner (202 pages) Air Conditioner Sanyo RCS-SH80UA Instruction Manual Split system air conditioner (64 pages) Heat Pump Sanyo XHWX2672R Specifications Ceiling recessed heat pump (2 pages) Air Conditioner Sanyo 42XW72R Submittal Data Ceiling recessed air conditioner (2 pages) Air Conditioner Sanyo 26XW72R Specifications Ceiling recessed air conditioner (2 pages) Heat Pump Sanyo 42XHW72R Specifications Ceiling recessed heat pump (2 pages) Air Conditioner Sanyo XHW2672R Specifications Ceiling recessed air conditioner (2 pages) Air Conditioner Sanyo XHW3672R Specifications Ceiling recessed air conditioner (2 pages) Air Conditioner Sanyo XHW4272R Specifications Ceiling recessed air conditioner (2 pages) Air Conditioner Sanyo XHS3632 Service Manual Split system air conditioner (106 pages) Air Conditioner Sanyo 24KHS72 Submittal Data Split system indoor/outdoor wall mounted heat pump (2 pages) Air Conditioner Sanyo 18KHS72 Specifications Wall mounted air conditioners & heat pumps 9,000-24,000 btu/h 16-20 seer (2 pages) Air Conditioner Sanyo CH1872 Technical & Service Manual Dc inverter split system air conditioner (111 pages) Air Conditioner Sanyo KHS2422 Service Manual Split system air conditioner (44 pages) Air Conditioner Sanyo C4272R S/C Installation Instructions Manual Sanyo split system heat pump air conditioner installation instructions (111 pages) Air Conditioner Sanyo C4272R Service Manual

Sanyo split system air conditioner service manual (181 pages)

Related Content for Sanyo CH2442

XMS1272 Placing The Unit Inside The Ceiling Sanyo XMS1272 W-3WAY ECO-i 85464369098000 Placing The Unit Inside The Ceiling Sanyo W-3WAY ECO-i 85464369098000 Mini ECO-i 85464359981002 Placing The Unit Inside The Ceiling Sanvo Mini ECO-i 85464359981002 PNR-XS2432 Placing The Unit Inside The Ceiling Sanyo PNR-XS2432 C4272R S/C Placing The Unit Inside The Ceiling Sanyo C4272R S/C 85464359982001 Placing The Unit Inside The Ceiling Sanyo 85464359982001 XS3632 Unit Specifications Sanyo XS3632 C4272R Indoor Unit : Ceiling Mounted Type 26 Type Sanyo C4272R

This manual is also suitable for:

Th2442Ch3642Kh2442Th3642Kh3642Th4242 ... Show all