


Removing The Casing To Install The Indoor Unit - Sanyo CH2442 Installation Instructions Manual

Split system heat pump air conditioner

1
2
Table Of Contents
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94




•

[Table of Contents](#)

•

Bookmarks



Enlarged version

3-13. Removing the Casing to Install the Indoor Unit


KH2442

How to Remove the Casing

- (1) Remove the plastic cover. (Fig. 3-31)
- (2) Remove the clamp for the wiring connector. (Fig. 3-32)
- (3) Disconnect the wiring connector. (Fig. 3-33)
- (4) Set the flap in the horizontal position. (Fig. 3-34)
- (5) Remove the 3 screws. (Fig. 3-34)
- (6) Remove the casing. (Fig. 3-34)

NOTE

When replacing the casing, be careful not to crush the lead wires between the casing and the frame. (Fig. 3-34)



Casing
Flap
Screws
Fig. 3-34

Clamp
Screw

Frame
0947_T_I

25
S4359146

Fig. 3-31
Fig. 3-32

2023_T_I
Fig. 3-33

Plastic cover

Screw
0945_T_I
Wiring
connector
2024_T_I




Table of Contents

[Previous Page](#)
[Next Page](#)

1
...
23
24
25
26
27
28
29
30

Quick Links:

[Indoor Unit](#)

[How to Install the Wired Remote...](#)

Related Manuals for Sanyo CH2442

[Air Conditioner Sanyo KH2442 / CH2442 Service Manual](#)

Split system air conditioner (202 pages)

[Air Conditioner Sanyo RCS-SH80UA Instruction Manual](#)

Split system air conditioner (64 pages)

[Heat Pump Sanyo XHWX2672R Specifications](#)

Ceiling recessed heat pump (2 pages)

[Air Conditioner Sanyo 42XW72R Submittal Data](#)

Ceiling recessed air conditioner (2 pages)

[Air Conditioner Sanyo 26XW72R Specifications](#)

Ceiling recessed air conditioner (2 pages)

[Heat Pump Sanyo 42XHW72R Specifications](#)

Ceiling recessed heat pump (2 pages)

[Air Conditioner Sanyo XHW2672R Specifications](#)

Ceiling recessed air conditioner (2 pages)

[Air Conditioner Sanyo XHW3672R Specifications](#)

Ceiling recessed air conditioner (2 pages)

[Air Conditioner Sanyo XHW4272R Specifications](#)

Ceiling recessed air conditioner (2 pages)

[Air Conditioner Sanyo XHS3632 Service Manual](#)

Split system air conditioner (106 pages)

[Air Conditioner Sanyo 24KHS72 Submittal Data](#)

Split system indoor/outdoor wall mounted heat pump (2 pages)

[Air Conditioner Sanyo 18KHS72 Specifications](#)

Wall mounted air conditioners & heat pumps 9,000-24,000 btu/h 16-20 seer (2 pages)

[Air Conditioner Sanyo CH1872 Technical & Service Manual](#)

Dc inverter split system air conditioner (111 pages)

[Air Conditioner Sanyo KHS2422 Service Manual](#)

Split system air conditioner (44 pages)

[Air Conditioner Sanyo C4272R S/C Installation Instructions Manual](#)

Sanyo split system heat pump air conditioner installation instructions (111 pages)

[Air Conditioner Sanyo C4272R Service Manual](#)

Sanyo split system air conditioner service manual (181 pages)

Related Content for Sanyo CH2442

[SAP-KR184GJH Remove The Grille To Install The Indoor Unit](#)

Sanyo SAP-KR184GJH

[KMS0772 How To Install The Indoor Unit](#)

Sanyo KMS0772

[KHS0951 How To Install The Indoor Unit](#)

Sanyo KHS0951

[SAP-KRV9AEH How To Install The Indoor Unit](#)

Sanyo SAP-KRV9AEH

[SAP-KRV9AEH How To Install The Indoor Unit](#)

Sanyo SAP-KRV9AEH

[SAP-KMRV74EH How To Install The Indoor Unit](#)

Sanyo SAP-KMRV74EH

[KHS1872 + CH1872 Remove The Grille To Install The Indoor Unit](#)

Sanyo KHS1872 + CH1872

[SAP91KC Remove The Casing In Order To Install The Indoor Unit](#)

Sanyo SAP91KC

This manual is also suitable for:

[Th2442Ch3642Kh2442Th3642Kh3642Th4242 ... Show all](#)