Suspending The Indoor Unit - Sanyo CH2442 Installation Instructions Manual

Split system heat pump air conditioner


(

Table of Contents

•

Bookmarks

•



3-23. Suspending the Indoor Unit

Depending on the ceiling type: Insert suspension bolts as shown in Fig. 3-74


or

Use existing ceiling supports or construct a

suitable support as shown in Fig. 3-75.

(1) When placing the unit inside the ceiling, determine the pitch of the suspension bolts referring to the dimensional data on the previous page.
 (Fig. 3-73) WARNING
 Tubing must be land and connected inside the

Tubing must be land and connected inside the ceiling when suspending the unit. If the ceiling is



already constructed, lay the tubing into position for connection to the unit before placing the unit inside the ceiling.

(2) Screw in the suspension bolts allowing them to protrude from the ceiling as shown in Fig. 3-74.
(Cut the ceiling material, if necessary.)
(3) Thread the 2 hexagonal nuts and washers (field supply) onto the 4 suspension bolts as shown in Figs. 3-76 and 3-77. Use 2 sets of nuts and washers (upper and lower), so that the unit will not fall off the suspension lugs.

It is important that you use

extreme care in supporting the indoor unit inside WARNING

ceiling. Encure that the ceiling is strong enough to support the weight of the unit. Before hanging the unit, test the strength of each

> ed suspension bolt. anchor plug

sion bolt (M10 or 3/8") Ipply)

Fig. 3-74

Fig. 3-75 Nuts and washers (2 sets) Upper Lower Fig. 3-76 Suspension bolt Hexagonal nut

Fig. 3-77

36 s4359146 Concrete Insert 0038_T_I Ceiling tiles Ceiling support 0039_S_I Suspension bolt Suspension lug 0041_X_I 0784_U_I

ManualsLib.co

自

Table of Contents

Previous Page Next Page

 Quick Links: Indoor Unit How to Install the Wired Remote...

Related Manuals for Sanyo CH2442

Air Conditioner Sanyo KH2442 / CH2442 Service Manual Split system air conditioner (202 pages) Air Conditioner Sanyo RCS-SH80UA Instruction Manual Split system air conditioner (64 pages) Heat Pump Sanyo XHWX2672R Specifications Ceiling recessed heat pump (2 pages) Air Conditioner Sanyo 42XW72R Submittal Data Ceiling recessed air conditioner (2 pages) Air Conditioner Sanyo 26XW72R Specifications Ceiling recessed air conditioner (2 pages) Heat Pump Sanyo 42XHW72R Specifications Ceiling recessed heat pump (2 pages) Air Conditioner Sanyo XHW2672R Specifications Ceiling recessed air conditioner (2 pages) Air Conditioner Sanyo XHW3672R Specifications Ceiling recessed air conditioner (2 pages) Air Conditioner Sanyo XHW4272R Specifications Ceiling recessed air conditioner (2 pages) Air Conditioner Sanyo XHS3632 Service Manual Split system air conditioner (106 pages) Air Conditioner Sanyo 24KHS72 Submittal Data Split system indoor/outdoor wall mounted heat pump (2 pages) Air Conditioner Sanyo 18KHS72 Specifications Wall mounted air conditioners & heat pumps 9,000-24,000 btu/h 16-20 seer (2 pages) Air Conditioner Sanyo CH1872 Technical & Service Manual Dc inverter split system air conditioner (111 pages) Air Conditioner Sanyo KHS2422 Service Manual Split system air conditioner (44 pages) Air Conditioner Sanyo C4272R S/C Installation Instructions Manual Sanyo split system heat pump air conditioner installation instructions (111 pages) Air Conditioner Sanyo C4272R Service Manual

Sanyo split system air conditioner service manual (181 pages)

Related Content for Sanyo CH2442

XMS1272 Suspending The Indoor Unit

Sanyo XMS1272 W-3WAY ECO-i 85464369098000 Suspending The Indoor Unit Sanyo W-3WAY ECO-i 85464369098000 Mini ECO-i 85464359981002 Suspending The Indoor Unit Sanyo Mini ECO-i 85464359981002 PNR-XS2432 Suspending The Indoor Unit Sanyo PNR-XS2432 ECO R410A Suspending The Indoor Unit Sanyo ECO R410A C4272R S/C Suspending The Indoor Unit Sanyo C4272R S/C 85464359982001 Suspending The Indoor Unit Sanyo 85464359982001 XS3632 (A) Indoor Unit

This manual is also suitable for:

Th2442Ch3642Kh2442Th3642Kh3642Th4242 ... Show all