





## Sanyo POA-CFC20 Owner's Manual

Compact flash card



1  
2  
3  
4  
5  
6  
7  
8

--

•


[Table of Contents](#)

•

## Bookmarks

Available languages

- EN
- FR
- DE
- ES
- IT
- JP



More

### Quick Links

[Download this manual](#)





## **CompactFlash Card**

# **POA-CFC20**

This CompactFlash Card is to be used only with our Multi Card Imager. Using the product with any other devices is not guaranteed. Use it correctly after take a close look at the following handling instructions. For details on handling, refer to the owner's manual of the device below

This CompactFlash Card comes with the CompactFlash Card adapter. Use it with the card slot Type-II of your computer.

**Compatible Multi Card Imager: POA-BOX20**

## **CAUTIONS**

G CF Cards / Adapters are precision electronic devices. Do not bend, drop, apply strong forces or shock or

place it where static electricity is easily built up.

G Do not touch the surface of the contact area with your fingers or allow it to be stained with foreign materials.

G Do not attempt to dismantle or alter CF Cards.

G Rapid movement of CF Card between hot and cold conditions may cause condensation and result in

damage of the product. To avoid this problem, seal the CF Card closely with a plastic bag to let it take to the room temperature before using it. If condensation should occur, place the CF Card at a constant temperature and let the moisture evaporate naturally.

G Store CF Cards / Adapters in the exclusive case.

G Do not use or store CF Cards / Adapters in places subject to the following conditions:

- strong magnetic fields
- abundant dirt or dust
- high temperatures, high humidity

Environment of CF Card / Adapter operation

Operating Temperature

Storage Temperature

---

## Use CF Card Adapter

### Attach CF Card

Insert the CF Card firmly into the CF Card Adapter, aligning the arrows on the CF Card and the adapter.

### Remove CF Card

Pull the CF Card straight out.

## Specifications

I CompactFlash Card Adapter (Compatible with PC card slot Type-II)

NOTE ; This adapter cannot be used for other memory cards.

I Compact Flash Card (Comforming to ATA standard) (32MB)

The specifications are subject to change without notice.

: 41 °F ~ 95 °F (5 °C ~ 35 °C)

: 14 °F ~ 140 °F (-10 °C ~ 60 °C)

— 1 —

Insert the CF Card aligning the arrows.

CF Card Adapter

CF Card

[Table of Contents](#)

[Next Page](#)

1  
2  
3  
4  
5

# Related Manuals for Sanyo POA-CFC20

## [Storage Sanyo POA-USB02 Owner's Manual](#)

Usb memory (26 pages)

## [Storage Sanyo VA-EXD1 W Instruction Manual](#)

External disc unit (12 pages)

## [Storage Sanyo VA-EXH Instruction Manual](#)

(44 pages)

## [Storage Sanyo VA-EXH Instruction Manual](#)

External storage unit (70 pages)

# Summary of Contents for Sanyo POA-CFC20

## [Page 1: Specifications](#)

CompactFlash Card POA-CFC20 This CompactFlash Card is to be used only with our Multi Card Imager. Using the product with any other devices is not guaranteed. Use it correctly after take a close look at the following handling instructions. For details on handling, refer to the owner's manual of the device below This CompactFlash Card comes with the CompactFlash Card adapter.

## [Page 2: Carte Compactflash](#)

Carte CompactFlash POA-CFC20 Cette carte CompactFlash doit être utilisée exclusivement avec notre Multi Card Imager. L'utilisation du produit avec tout autre dispositif n'est pas garantie. Utilisez-la correctement après avoir lu attentivement les instructions de manipulation suivantes. Pour plus de détails concernant les manipulations, reportez-vous au manuel du propriétaire du périphérique ci-dessous.

## [Page 3: Especificaciones](#)

Tarjeta CompactFlash POA-CFC20 Esta tarjeta CompactFlash se usa solo con nuestro Multi Card Imager. No se puede garantizar el funcionamiento usando el producto con cualquier otro dispositivo. Uselo correctamente después de leer cuidadosamente las siguientes instrucciones. Por detalles acerca de la manipulación, consulte el manual de instrucciones del dispositivo a continuación.

## [Page 4: Technische Daten](#)

CompactFlash-Karte POA-CFC20 Diese CompactFlash-Karte ist nur für die Verwendung mit Multi Card Imager vorgesehen. Eine einwandfreie Verwendung mit anderen Geräten wird nicht garantiert. Wenden Sie deshalb die Karte richtig an und beachten Sie die folgenden Hinweise zur Handhabung. Für weitere Einzelheiten wird auf die nachstehende Bedienungsanleitung verwiesen.

## [Page 5: Dati Tecnici](#)

Scheda CompactFlash POA-CFC20 Questa scheda CompactFlash è destinata esclusivamente all'utilizzo con l'unità Multi Card Imager. Il corretto funzionamento del prodotto con qualsiasi altro apparecchio non è garantito. Utilizzare la scheda correttamente dopo aver letto attentamente le seguenti istruzioni per l'uso. Per dettagli sull'uso, fare riferimento al manuale dell'utente dell'apparecchio.

## [Page 6](#)

POA-CFC20  
Type-II POA-BOX20

[Page 7](#) AVオーディオインターフェース 接続ケーブル 574 - 8534 オーディオケーブル 1 - 1 - 7 ...

[Page 8](#) Printed in Japan SANYO Electric Co., Ltd. 1AA6P1P4407--(IDLJ)