



Sanyo LNS LNS-W03 Installation Procedures Manual

Lcd projector lens

1
2
3
4
5
6
7

--

•

Bookmarks

[Download this manual](#)

Quick Links



LCD PROJECTOR LENS MODEL NO. LNS-W03 LENS REPLACEMENT AND INSTALLATION PROCEDURES NOTES ON REPLACEMENT AND INSTALLATION

The procedures and the needed parts for lens installation depend on the type of cabinet. Before installing or replacing the lens, make sure the type of cabinet and be sure to refer to the Installations corresponding with your projector.

When installing or replacing the lens, make sure the Lens Model No. matches with

your projector. Refer to the catalog, or contact your sales dealer for the proper Lens Model No.

TYPE OF THE CABINET AND INSTALLATION PROCEDURES

Refer to the Installation procedure corresponding to your projector and install the lens correctly. (See the chart below.)

Type of the Cabinet (1) See Page 2

For use the other models (other than above cabinet), contact your sales dealer.

Type of the Cabinet (2) See Page 4

1AA6P1P2952-- (ICYZ)

Next Page

1
2
3
4
5

Related Manuals for Sanyo LNS LNS-W03

[Projector Sanyo LNS-W03 Lens Replacement Manual](#)

Lcd projector (14 pages)

[Lenses Sanyo LNS-W03 - Wide-angle Lens - 30 mm Lens Replacement Manual](#)

Lcd projector (7 pages)

[Projector Accessories Sanyo LNS-T02 Series Replacement /Installation Instructions](#)

Sanyo lcd projector lens replacement and installation procedure (4 pages)

[Projector Accessories Sanyo LNS-S11 Specification Sheet](#)

Sanyo projector throw distance specification sheet (1 page)

[Projector Accessories Sanyo AH-23541 Replacement Procedure](#)

Lcd projector lens replacement (6 pages)

[Projector Accessories Sanyo LNS-T01Z Replacement /Installation Instructions](#)

Sanyo lcd projector lens replacement and installation procedures (4 pages)

[Projector Accessories Sanyo LNS-T31A Replacement Procedure](#)

Sanyo lcd projector lens replacement procedure installation guide (9 pages)

[Projector Accessories Sanyo LNS-T31A - Telephoto Zoom Lens Replacement Procedure](#)

Owners manual (9 pages)

[Projector Accessories Sanyo LNS-W04 Installation And Replacement Procedures](#)

Lcd projector lens (6 pages)

[Projector Accessories Sanyo LNS-T01 Lens Replacement Manual](#)

Sanyo lns-t01 projector-lens: user guide (3 pages)

[Projector Accessories Sanyo LNS-W32 Replacement Procedure](#)

Sanyo lcd projector lens replacement and installation procedures (10 pages)

[Projector Accessories Sanyo LNS-W32 - Wide-angle Lens - 22.3 mm Replacement Procedure](#)

Lcd projector lens (10 pages)

[Projector Accessories Sanyo LNS-W50 Replacement Procedure](#)

(4 pages)

[Projector Accessories Sanyo LNS-W20 Manual](#)

Projector lens replacement procedure (3 pages)

[Projector Accessories Sanyo LNS-W21 Replacement Procedure](#)

(3 pages)

[Projector Accessories Sanyo LNS-T03 - Telephoto Zoom Lens Replacement /Installation Instructions](#)

Owners manual (8 pages)

Summary of Contents for Sanyo LNS LNS-W03

PROCEDURES NOTES ON REPLACEMENT AND INSTALLATION The procedures and the needed parts for lens installation depend on the type of cabinet. Before installing or replacing the lens, make sure the type of cabinet and be sure to refer to the Installations corresponding with your projector.

[Page 2](#) NOTES ON LENS INSTALLATION The ZOOM, FOCUS and LENS SHIFT adjustment on the Top Control or the Remote Control cannot be operated with this Lens. • Lens installation and replacement should be made by the qualified service personnel. • Be sure to install the lens following this procedure precisely. •...

[Page 3](#) LENS REPLACEMENT AND INSTALLATION PROCEDURE Perform the steps First set the lens at the center position with lens shift adjustment. REMOVE THE LENS COVER. (See figure-1) 1. Remove screws A (2 screws). 2. Pull down the lower lens cover while pushing the part D, then remove it.

[Page 4: Adjust Focus](#)

INSTALL THE LENS. (See figure-4) 1. Remove protective caps(front and back) on the lens. 2. Mount the lens on mounting bracket of the main cabinet with 4 screws. Use the screws included with the lens. Use the driver included with the lens to fasten the screws.

[Page 5](#) LENS REPLACEMENT AND INSTALLATION PROCEDURE Perform the steps First set the lens at the center position with lens shift adjustment. REMOVE THE UPPER LENS COVER. (See figure-1) 1. Remove screws A (2 screws). 2. Push part B and pull Upper Lens Cover up. REMOVE THE LOWER LENS COVER.

[Page 6](#) DISCONNECT THE LENS SHIFT CONNECTORS. (See figure-4) Disconnect the Lens Shift Connectors ("K96S" and "K96R") from circuit board. INSTALL THE LENS. (See figure-5) 1. Remove protective caps(front and back) on the lens. 2. Mount the lens on mounting bracket of the main cabinet with 4 screws. Use the screws included with the lens.

[Page 7: Focus Adjustment](#)

MOUNT THE LENS COVER. (See figure-7) 1. Replace Lower Lens Cover. Slide Light-Block Sheet into the guide of Lower Lens Cover and set them in front of the flap. (See Fig. 7.) Fix Lower Lens Cover with 4 Screws C. (See Fig.