

Meanings Of Alarm Messages - Sanyo KH2442 / CH2442 Service Manual

Split system air conditioner


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68

69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118

119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168

169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202



•

[Table of Contents](#)

-

Troubleshooting

•

Bookmarks



NOTE

RCU

: Remote Control Unit (remote controller)

R.C.

: Refrigerant Circuit

comp. : Compressor

temp. : Temperature

PCB

: Printed Circuit Board

Remote controller is detecting error signal from indoor unit.

• Indoor unit is detecting error signal from the remote controller.
(No serial communications signal)

Indoor unit is detecting error signal from outdoor unit.

Outdoor unit is detecting error signal from indoor unit.

Indoor unit is not working correctly.

Outdoor unit is transmitting error signal.

Improper setting of indoor unit or remote controller.

When using group control, main indoor unit address setting is duplicated.
(For single heat pump type.)

Error in Auto. address setting.
(No. or capacity of judged indoor unit is small.)

Error in Auto. address setting.
(No. or capacity of judged indoor unit is large.)

Indoor unit is detecting error signal from another indoor unit.

Protective device in indoor unit is activated.

Protective device in outdoor unit is activated.

Protective device in indoor unit is activated.

• Thermal protector in indoor fan motor is activated.
• Thermal protector in outdoor fan motor is activated.

• Comp. thermal protector is activated.

Incorrect discharge gas temp. of comp.

High-pressure switch is activated.

Incorrect power supply voltage . Negative phase, defective phase or voltage drop.

Incorrect discharge gas temp. of comp.

Loose wiring connections of ceiling panel.
High-voltage switch is activated.

Reference procedures

ManualsLib.com

E2

E3

E4

E5



E6
E7
E8
E9
E12
E14
E15
E16
E18
P1
P2
P3
P4
P5
P17
P9
P10
SM830082

[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1

...

161

162

163

164

Quick Links:

[Technical Data](#)

[Service Manual](#)

[Unit Specifications](#)

[Troubleshooting](#)

Chapters

[Who Should Use This Manual](#) 3

[2. Processes and Functions](#) 121

[4. Service Procedures](#) 157

Troubleshooting

[Troubleshooting](#) 158

[Check before and after Troubleshooting](#) 159

[General Troubleshooting Flow Chart: Diagnosis and Remedy](#) 160

Related Manuals for Sanyo KH2442 / CH2442

[Air Conditioner Sanyo CH2442 Installation Instructions Manual](#)

Split system heat pump air conditioner (94 pages)

[Air Conditioner Sanyo RCS-SH80UA Instruction Manual](#)

Split system air conditioner (64 pages)

[Air Conditioner Sanyo 26K72R Dimensional Data](#)

Wall mounted type outdoor/indoor unit (1 page)

[Air Conditioner Sanyo C4272R S/C Installation Instructions Manual](#)

Sanyo split system heat pump air conditioner installation instructions (111 pages)

[Air Conditioner Sanyo C4272R Service Manual](#)

Sanyo split system air conditioner service manual (181 pages)

[Air Conditioner Sanyo RCS-BH80UA.WL Instruction Manual](#)

Split system air conditioner (48 pages)

[Air Conditioner Sanyo Mini ECO-i CHXR03652 Service Manual](#)

(93 pages)

[Air Conditioner Sanyo CHDZ07263 Service Manual](#)

(128 pages)

[Air Conditioner Sanyo Mini ECO-i 85464359981002 Installation Instructions Manual](#)

Sanyo air conditioner installation instructions (90 pages)

[Air Conditioner Sanyo CH0951 Technical & Service Manual](#)

Split system air conditioner (98 pages)

[Air Conditioner Sanyo KHS1822 Service Manual](#)

Split system air conditioner (38 pages)

[Air Conditioner Sanyo KHS3632 / CH3632 Service Manual](#)

Split system air conditioner (94 pages)

[Air Conditioner Sanyo 18KHS72 Installation Instructions Manual](#)

Indoor/outdoor unit inverter split system air conditioner (25 pages)

[Air Conditioner Sanyo 09KHS71 Instruction Manual](#)

Inverter-controlled split system air conditioner (50 pages)

[Air Conditioner Sanyo COOL/HEAT Installation Instructions Manual](#)

Split system air conditioner (20 pages)

[Air Conditioner Sanyo KHS1232 Technical Data Manual](#)

(24 pages)

Related Content for Sanyo KH2442 / CH2442

[Mini ECO-i SPW-ASR74GXH56\(A/B\) Meaning Of Alarm Messages](#)

Sanyo Mini ECO-i SPW-ASR74GXH56(A/B)

[MINI ECO-i XHX1252 Meaning Of Alarm Messages](#)

Sanyo MINI ECO-i XHX1252

[ECO-i AHX0752 Meaning Of Alarm Messages](#)

Sanyo ECO-i AHX0752

[MINI ECO-i SPW-CR365GXH56B Meaning Of Alarm Messages](#)

Sanyo MINI ECO-i SPW-CR365GXH56B

[SPW-CR363GVH8 Explanation Of Alarm Messages](#)

Sanyo SPW-CR363GVH8

[SPW-CR1503GDYH8 Explanation Of Alarm Messages](#)

Sanyo SPW-CR1503GDYH8

[KHS3632 / CH3632 Meanings Of Alarm Messages](#)

Sanyo KHS3632 / CH3632

[SPW-C256VH Meaning Of Alarm Messages](#)

Sanyo SPW-C256VH

This manual is also suitable for:

[Th4242Uh2442Kh3642Uh3642Xh2442Xh3642](#) ... [Show all](#)