



Sanyo DP50719 Owner's Manual

50" plasma hdtv

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18




•

[Table of Contents](#)

•

Bookmarks

Available languages



Quick Links

[1 Specifications](#)

[2 Getting Started](#)

[3 Table of Contents](#)


[4 Back Panel Jacks](#)

[5 Audio / Video Connections](#)

[6 On-Screen Menu Operation- Chanel Setting](#)

[7 Setup](#)

[Download this manual](#)



50"



© 2009 Sanyo Manufacturing Corporation

Plasma HDTV 50"

TVHD de Plasma

Table of Contents

Tabla de contenido

DP50719



Part No. / No. de parte : 1JC6P1P0337- -

4

21

50”

[Table of Contents](#)

[Next Page](#)

1
2
3
4
5

Chapters

English 3

Español 11

Related Manuals for Sanyo DP50719

[Plasma TV Sanyo DP50710 Owner's Manual](#)

50" plasma hdtv (60 pages)

[Plasma TV Sanyo DP50710 Owner's Manual](#)

50" plasma hdtv (24 pages)

[Plasma TV Sanyo DP50741 Owner's Manual](#)

50" plasma hdtv (48 pages)

[Plasma TV Sanyo DP50741 Setup Manual](#)

50" diagonal plasma 720p 600hz hdtv (2 pages)

[Plasma TV Sanyo DP50740 Owner's Manual](#)

50" plasma hdtv (56 pages)

[Plasma TV Sanyo DP50749 Owner's Manual](#)

50" hdtv plasma (67 pages)

[Plasma TV Sanyo DP50749 Service Manual](#)

Remote control digital color television (48 pages)

[Plasma TV Sanyo Vizzon DP50747 Owner's Manual](#)

Sanyo plasma hdtv owner's manual (52 pages)

[Plasma TV Sanyo DP50747 Owner's Manual](#)

Sanyo high-definition digital plasma television owner's manual (52 pages)

[Plasma TV Sanyo DP50747 Owner's Manual](#)

Plasma hdtv (52 pages)

[Plasma TV Sanyo DP50747 Service Manual](#)

Sanyo remote control plasma color television (52 pages)

[Plasma TV Sanyo DP50747 Service Manual](#)

Remote control plasma color television (62 pages)

[Plasma TV Sanyo DP42746 Owner's Manual](#)

(59 pages)

[Plasma TV Sanyo DP42746 Service Manual](#)

Remote control plasma color television (38 pages)

[Plasma TV Sanyo DP42545 Service Manual](#)

Remote control plasma color television (60 pages)

[Plasma TV Sanyo DP42545 Owner's Manual](#)

Sanyo dp42545: instruction manual (31 pages)

Summary of Contents for Sanyo DP50719

[Page 2: Important Safety Instructions](#)

This Class B digital apparatus complies with Canadian ICES-003. SANYO recommends keeping the TV set at its factory settings or moving Energy Saver settings from "Level 1" to "Level 2" or "Level 3" to further reduce power requirements and increase energy savings.

[Page 3: Table Of Contents](#)

CONTENTS PROTECTING THE PLASMA SCREEN IMPORTANT SAFETY INSTRUCTIONS2 FCC INFORMATION 3 The screen can be damaged if it is not maintained TRADEMARKS .

[Page 4: Pc Connections](#)

Temperature screen settings, and the Bass and Laptop Display on HDTV Treble audio settings. When using your Sanyo HDTV to display a Laptop's screen display, holding down the Fn (or FN) key while pressing the appropriate function key (F5, F7, F8, etc) should cycle through different display modes between the laptop and the HDTV.

[Page 5: Back Panel Jacks](#)

BACK PANEL JACKS Component Video Input (VIDEO2 or VIDEO3) USB Input View pictures stored in a USB flash drive. Green (Y), blue (Pb), and red (Pr) Video inputs plus the white and red Audio inputs. Analog / Digital Antenna Input Stereo Audio Out (L/R) Jacks HDMI (INPUT1, 2 &...

[Page 6: On-Screen Menu Operation- Chanel Setting](#)

GETTING STARTED— INITIAL CHANNEL SEARCH Plug in AC power cord 120V AC, 60Hz Turn On TV Wait for on-screen instructions to perform an Initial Channel Search. CHANNEL SEARCH Checks Antenna and Cable signals connected to the Antenna terminal. NOTE: "Auto" detects the mode detection, Cable or Air, first, and then proceeds with the channel search.

[Page 7: Setup](#)

ON-SCREEN MENU OPERATION SETUP Display the On Screen menu and use the CURSOR LM keys to select Setup. Press ENTER. Use the Setup menu to set the Menu Language, V-Chip rating settings, customize Digital Captions, set Energy Saver level, set the current time and on-time with the Clock Timer, establish the HDMI Linking CEC function, activate Light Sensor, and access the Panel Protection feature.

[Page 8: Energy Saver](#)

ON-SCREEN MENU OPERATION SETUP ENERGY SAVER Energy saver settings control the LCD backlight brightness to save power consumption. The higher the level number, the more brightness reduction and higher power saving. CLOCK TIMER Set the Current Time for your HDTV. You may also set a Switch on Time to use with the On Timer Function.

[Page 9: Manual Sound Settings](#)

ON-SCREEN MENU OPERATION SOUND Display the On Screen menu and use the CURSOR LM keys to select Sound. Press ENTER. Choose one of the four available options for your sound settings: Auto - Sound setting levels are adjusted and linked according to the current Picture option.

[Page 10: Warranty](#)

APPLY TO PRODUCTS USED FOR INDUSTRIAL OR COMMERCIAL PURPOSES. WARRANTY APPLICATION FOR ONE YEAR from the date of original retail purchase Sanyo Manufacturing Corporation (SMC) warrants this TV to be free from manufacturing defects in materials and workmanship under normal use and conditions for parts and labor.

[Page 11: Información Fcc](#)

ICES-003 de Canadá. RESOLUCIONES DE PC SANYO recomienda mantener su TV en el modo de fábrica o cambiar los ajustes del Ahorrador de Energía de "Nivel 1" a "Nivel 2" o "Nivel 3" para reducir el requerimiento de potencia y elevar el ahorro de energía.

[Page 12: Quitar La Base / Montar En Pared](#)

QUITAR LA BASE Y MONTAR PARA COMENZAR EN PARED (OPCIONAL) INSTALACIÓN DE BATERÍAS Herramienta necesaria: Desarmador de cruz No. 3 Instale baterías en el control remoto NOTA IMPORTANTE: (2 "AAA", no incluidas). Coloque la HDTV con el frente hacia abajo

sobre una superficie plana y acolchonada más grande que la pantalla para protegerla junto con el acabo- Para asegurarse de una buena...

[Page 13: Conectores Del Panel Trasero](#)

CONECTORES DEL PANEL TRASERO Entrada USB Entrada de video Componente (VIDEO2 o Despliegue fotos en pantalla utilizando una VIDEO3) memoria USB. Entradas verde (Y), azul (Pb) y roja (Pr) de video; Entrada de antena análoga / digital además de las entradas de audio roja y blanca. Salida de Audio Análogo (L/R) Entradas HDMI (INPUT1, 2 ó...

[Page 14: Configuración De Pc](#)

PC o LAPTOP Imagen y Audio PC Cable de monitor RGB Sanyo recomienda utilizar Estándar - Aplica valores predeterminados a los un cable de monitor con parámetros de Imagen y Audio. ferrita. Manual - Ajuste los parámetros de Contraste,...

[Page 15: Operación De Menú En Pantalla](#)

OPERACIÓN DEL MENÚ EN PANTALLA ESTABLECER CANALES Despliegue el menú en pantalla. Utilice las teclas CURSOR LM para seleccionar Establecer canales. Presione ENTER. BÚSQUEDA DE CANALES Auto - Busca en el modo detectado, Cable o Aire. Cable - Busca canales análogos y canales digitales de Cable no codificados.

[Page 16: V-Chip](#)

OPERACIÓN DEL MENÚ EN PANTALLA CONFIGURACIÓN V - CHIP Utilice esta función para bloquear automáticamente programación con contenido que crea inapropiado para ser visto por sus hijos. NOTA: Esta función está diseñada para cumplir con regulaciones de la FCC para V-Chip en los Estados Unidos de América.

[Page 17: Imagen](#)

OPERACIÓN DEL MENÚ EN PANTALLA IMAGEN Despliegue el menú en pantalla. Utilice las teclas CURSOR LM para seleccionar Imagen. Presione ENTER. Puede elegir entre Cine, Deporte, Noticiero, Juego y Normal, los cuales tienen valores fijos y predeterminados para los diferentes parámetros. O puede elegir una de las dos opciones Manuales para ingresar valores personalizados.

[Page 18: Reproductor De Imágenes](#)

APLICACIÓN DE LA GARANTÍA POR UN AÑO, desde la fecha de la compra original, Sanyo Manufacturing Corporation (SMC) garantiza esta televisión de estar libre de defectos de manufactura en materiales y mano de obra bajo uso y condiciones normales para partes y trabajo.

[Page 19](#) Visit our Web site: www.sanyoctv.com or call toll free: 1-800-877-5032 We'll be glad to Help Sanyo Manufacturing Corp. 3333 Sanyo Road, Forrest City, AR 72335 Printed in Mexico SMC, July 2009 Impreso en México SMC, julio 2009 YX6-E 50-J4FJ GXBJ...