

Sanyo HF-710 Instruction Manual

Manual defrost chest freezer

1

2

3

Table Of Contents

4

5

6

7

8

9


10

11

12

13

14



•

[Table of Contents](#)

-

Troubleshooting

•

Bookmarks

Quick Links

[1 Troubleshooting](#)

[Download this manual](#)



HF-710

INSTRUCTION MANUAL

Manual Defrost Chest Freezer

Help Line: 1-800-263-2244

Monday to Friday 9 am - 5 pm (Eastern)

www.ca.sanyo.com



Table of Contents

[Next Page](#)

1
2
3
4
5

Related Manuals for Sanyo HF-710

[Freezer Sanyo HF-5017 Instruction Manual](#)

(2 pages)

[Freezer Sanyo HF 1455W Service Manual](#)

Home freezer (10 pages)

[Freezer Sanyo MDF-193 Service Manual](#)

Ultra-low temp. freezer (30 pages)

[Freezer Sanyo MDF-C2156VAN Service Manual](#)

Ultra-low temperature freezer (43 pages)

[Freezer Sanyo MDF-U55V Service Manual](#)

Ultra-low temperature freezer (41 pages)

[Freezer Sanyo MDF-C2156VANC Brochure & Specs](#)

V.i.p. plus -150°c cryogenic freezers (4 pages)

[Freezer Sanyo MDF-C8V Service Manual](#)

Ultra-low temperature freezer (92 pages)

[Freezer Sanyo MDF-U53V Service Manual](#)

Ultra-low temperature freezer (68 pages)

[Freezer Sanyo MDF-137 Service Manual](#)

Biomedical freezer (35 pages)

[Freezer Sanyo MDF-394 Service Manual](#)

Ultra-low temp. freezer (34 pages)

[Freezer Sanyo MDF-U53VA Instruction Manual](#)

Ultra-low temperature freezer (35 pages)

[Freezer Sanyo MDF-593 Instruction Manual](#)

Ultra low temperature freezer (30 pages)

[Freezer Sanyo MDF-U3386S Brochure & Specs](#)

Hcfc-free ultra-low temperature freezer (2 pages)

[Freezer Sanyo MDF-U7386S Instruction Manual](#)

Ultra-low temperature freezer (37 pages)

[Freezer Sanyo MDF-C2156VAN Brochure & Specs](#)

Ultra-low temperature v.i.p. series freezers (6 pages)

[Freezer Sanyo MDF-U74V Instruction Manual](#)

Ultra-low temperature freezer (42 pages)

Summary of Contents for Sanyo HF-710

[Page 1](#) HF-710 INSTRUCTION MANUAL Manual Defrost Chest Freezer Help Line:
1-800-263-2244 Monday to Friday 9 am - 5 pm (Eastern) www.ca.sanyo.com...

[Page 2: Safety Precautions](#)

6. Do not use any electrical device or any sharp instrument in defrosting your freezer. 7. If your old freezer is not being used, we recommend that you remove the doors. This will reduce the possibility of danger to children.

[Page 3](#) Risk of child entrapment: Before you throw away your old refrigerator or freezer, take off the doors. Leave the shelves in place so that children may not easily climb inside. Thank you

for using our SANYO product. This easy-to-use manual will guide you in getting the best use of your freezer.

[Page 4: Table Of Contents](#)

Food Storage Baskets ... 8 Defrosting And Draining ... 8 Food Storage Information ... 9 Normal Operating Sounds ... 9 Proper Freezer Care and Cleaning ... 10 Cleaning and Maintenance ... 10 Power Interruptions ... 11 Vacation and Moving Care... 11 Troubleshooting ...

[Page 5: Parts And Features](#)

Parts and Features 1. Temperature Control Adjustment 2. Power-On Indicator (Green) 3. Vinyl Coated Wire Basket 4. Interior Drain Plug (See Insert) 5. Exterior Drain Plug English...

[Page 6: Installing Your Freezer](#)

- When moving the freezer, never tilt it more than a 45-degree angle. This could damage the compressor and the sealed system.
- If the freezer is tilted let it stand in an upright position for at least 24 hours prior to plugging. This is to allow the refrigerant to settle.

[Page 7: Electrical Requirements](#)

Install Limitations • Do not install your freezer in any location not properly insulated or heated e.g. garage etc. Your freezer was not designed to operate in temperature settings below 55° Fahrenheit or above 90° Fahrenheit.

[Page 8: Freezer Features And Use](#)

Freezer Features and Use Operating Your Freezer • Once the freezer is in its proper place, plug it in an electrical outlet having 115 volts and 15 amps. Turn on power switch. Power light will come on, and the green run light will be lit indicating that the freezer has power.

[Page 9: Food Storage Baskets](#)

When done, push the drain dial in. Re-plug the drain plug inside the freezer compartment. Note: monitor the container under the drain to avoid overflow. • Wipe the interior of the freezer and replace the electrical plug in the electrical outlet. • Reset the temperature control to the desired setting.

[Page 10: Food Storage Information](#)

Food Storage Information Frozen Food: • Wipe containers before storing to avoid needless spills. • Hot food should be allowed to cool before storing in the freezer. This will prevent unnecessary energy use. • When storing meats, keep in the original packaging or rewrap as necessary.

[Page 11: Proper Freezer Care And Cleaning](#)

Proper Freezer Care and Cleaning Cleaning and Maintenance Warning: To avoid electric shock always unplug your freezer before cleaning. Ignoring this warning may result in death or injury. Caution: Before using cleaning products, always read and follow manufacturer's instructions and warnings to avoid personal injury or product damage.

[Page 12: Power Interruptions](#)

Clean freezer before reusing. Vacation and Moving Care • For long vacations or absences, empty food from freezer, move the temperature DIAL to the OFF position and clean the door gaskets according to "General cleaning" section. Prop doors open, so air can circulate inside.

[Page 13: Troubleshooting](#)

- Check if freezer is plugged in.
- Check if there is power at the ac outlet, by checking the circuit breaker.
- Wait for 30-40 minutes to see whether freezer will start. Compressor cycle must be complete to operate.
- Food temperature appears too warm: •...

[Page 14](#) English...

