



Toshiba A5509T Basic Manual

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17

Table Of Contents

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102

--

•

[Table of Contents](#)

•

Bookmarks


--

Quick Links

[1 Charging the Battery Pack](#)

.....10

[Download this manual](#)



Basic

Manual

Contents/
Getting Ready
Making and
Answering Calls
Character Input
Character Input
Phone Book
Phone Book
Mail
Mail
Camera
Camera
EZweb
EZweb
EZnaviWalk
EZnaviWalk
Limit Mode
Limit Mode
Smart Mode
Smart Mode
Others/Index
Others/Index



[Table of Contents](#)

[Next Page](#)

1
2
3
4
5

Related Manuals for Toshiba A5509T

[Cell Phone Toshiba A5517T Basic Manual](#)

(62 pages)

[Cell Phone Toshiba A5516T Basic Manual](#)

(106 pages)

[Cell Phone Toshiba A5523T Basic Manual](#)

Au by kddi (118 pages)

[Cell Phone Toshiba PORTEGE G910 User Manual](#)

(13 pages)

[Cell Phone Toshiba W45T Basic Manual](#)

(126 pages)

[Cell Phone TOSHIBA TS10 User Manual](#)

Toshiba mobile phone (83 pages)

[Cell Phone Toshiba Regza ISO4 Basic Manual](#)

Toshiba regza is series mobile phone basic manual (79 pages)

[Cell Phone Toshiba VM4050 User Manual](#)

Pcs vision phone (249 pages)

[Cell Phone Toshiba SG4-E01 User Manual](#)

(33 pages)

[Cell Phone Toshiba Portege G710 User Manual](#)

Toshiba cell phone user guide (140 pages)

[Cell Phone Toshiba 2032SP Online User's Manual](#)

Dual-band pcs phone (106 pages)

[Cell Phone Toshiba G500 User Manual](#)

Toshiba cell phone user manual (123 pages)

[Cell Phone Toshiba T-01B User Manual](#)

(176 pages)

[Cell Phone Toshiba W53T Manual Manual](#)

Cdma 1x win (93 pages)

[Cell Phone Toshiba TX80 User Manual](#)

Toshiba cell phone user manual (145 pages)

[Cell Phone Toshiba RG4-E01 User Manual](#)

(120 pages)

Summary of Contents for Toshiba A5509T

[Page 1](#) Contents/ Getting Ready Basic Making and Answering Calls Manual Character Input Character Input Phone Book Phone Book Mail Mail Camera Camera EZweb EZweb EZnaviWalk EZnaviWalk Limit Mode Limit Mode Smart Mode Smart Mode Others/Index Others/Index...

[Page 2](#) Introduction Thank you for purchasing the A5509T. Before using your A5509T, be sure to read the A5509T Basic Manual (this PDF manual) to ensure correct usage. After you have finished reading this manual, store this PDF manual and the printed manuals in safe places so you can retrieve them whenever you need them.

[Page 3: Cell Phone Etiquette](#)

Cell Phone Etiquette Etiquette for Cell Phone Use ■ The cell phone always emits weak radio waves when power is on. ■ Use the cell phone in an enjoyable and safe manner without forgetting to be considerate of others around you. ● The use of cell phones is not ● Be considerate of where you are allowed in some places...

[Page 4: Cell Phone Basics](#)

Cell Phone Basics Cell Phone Features Making/ Limit Mode/ Camera Answering Calls Smart Mode You can take photos and movie Your cell phone is You can select a mode that clips and then packed with useful restricts operation, or a mode send them easily features such as a that allows simplified...

[Page 5: Manner Mode And Voice Memo](#)

.....3

Manner Mode and Voice Memo Manner Mode Voice Memo You can use manner mode to turn When you cannot answer calls, off the incoming call ring tone and the cell phone can play an other tones so as not to answering message (Japanese) inconvenience other people.

[Page 6: Do Not Use The Cell Phone While](#)

[Driving!](#).....4

Do not use the cell phone while driving! Holding a cell phone, talking on a cell phone, looking at a cell phone display to send mail or perform some other operation while driving is against the law in Japan. (Revised Traffic Control Law, effective November 1, 2004) x...

[Page 7: Spam And One-Ring Calls](#)

.....5

Spam and One-ring Calls If you receive spam: You can set the mail filters to reject only specific mail or mail indicated by □□□□※ (unsolicited advertisement), which often tends to be spam. The following mail filters are available for rejecting spam: Danger! □□□□□□□□□□...

[Page 8: Table Of Contents](#)

Contents ● Cell Phone Etiquette Etiquette for Cell Phone Use
.....1 ● Cell Phone Basics Cell Phone Features
.....2 Manner Mode and Voice Memo
.....3 Checking the Power, Signal Strength, and
Battery Level3 Do not use the cell phone while
driving!.....4 Spam and One-ring Calls
.....5 ●...

[Page 9](#) ● Mail Using E-mail

.....47 Using C-mail
.....47 Creating and Sending E-
mail Messages48 Reading Received E-mail Messages
.....51 Reading an E-mail Message with an Attached
Photo53 Replying to Received E-mail Messages
.....54 Rejecting Spam
.....56 Creating and Sending C-mail
Messages57 Reading Received C-mail Messages
.....58 ●...

[Page 10: Getting Ready](#)

Checking the Contents of the Box The box contains the cell phone and accessories. □ Cell phone □ Battery pack (attached to the cell phone) □ Desktop holder □ Toshiba AC adapter 02 □ Basic Manual (Japanese) □ Instruction Manual (Japanese) □□□□ □□□□□...

[Page 11: Names Of Parts](#)

.....9

Names of Parts Incoming indicator (green) Charge indicator (red) Sub display Earpiece Mobile light Camera (lens) Built-in antenna Speaker Display Battery pack cover (for built-in battery pack) Application key Side key 1 Side key 2 Warp function key Camera key/ Soft key 1 Phone

Page 12: Charging The Battery Pack 10

□Charging finished: The charge indicator goes out. Connect the Toshiba AC adapter 02 to the desktop holder. □With inscription of the connector facing up, connect the Toshiba AC adapter 02 to the power terminal of the desktop holder. Connect the Toshiba AC adapter 02's power plug to a 100 V AC power outlet.

Page 13: Built-In Antenna 11

Built-in Antenna The antenna of the A5509T is built into its case. Note Note Built-in antenna
□ Since the antenna of the A5509T is built into the case, there is no protruding antenna.
Touching or covering the area around the built-in antenna may weaken a signal.

Page 14: Learning The Basics.....12

Learning the Basics Key Assignment H □Incoming History I □Outgoing History □Camera □Phone Book □E-mail □EZweb Q □Make and receive calls R □Voice memo setting/delete; 0~9 character delete; ^□- operation cancel S □Power on/off; end □Phone number and call character input P □EZ application startup U □Mobile light on/off...

Page 15 Warp Function Key Use the up, down, left, and right parts of the key to select items and to move the cursor. Press the center of the key to confirm a selected item. Selects items, and moves the cursor up, down, □...

Page 16: Configuring Initial Settings 14

Configuring Initial Settings Initial menu When the standby screen is  displayed, press
@.  Launcher menu
Press 3  (Do Not  Setup). ...

Page 17: Switching The Display Language To English
.....15

Switching the Display Language to English You can switch the display language for function names and other items to English. When the standby screen is 日本語表示 displayed, press @. 日本語表示 日本語表示 aThe Launcher menu appears. 日本語表示 日本語表示 日本語表示...

Page 18: Using
Menus.....
16

Use G to select Alphabet and then press @ (Select). aThe display language is set to English. Using Menus Launcher Menu The Launcher menu provides you with access to various A5509T functions. The Launcher menu contains the following items. Voice Recorder Data Folder Voice Recorder...

Page 19 Use E to select an item. Limit Mode Voice Rec Smart Mode Notepad Calendar Data
Folder Calculator Profile Function Security EZnaviWalk Press @ (Select).
Launcher ... aThe item selected in the

Page 20: Indicators18

Indicators Display indicators keep you informed when new e-mail arrives, about the status of function settings, etc. ① ② ③ ④ ⑤ Indicator Description ① Indicates signal strength. ② Indicates battery level. ③ Indicates that EZweb is in use. ④... ⑤...

Page 21: Initializing E-Mail And

[Ezweb.....19](#)

Initializing E-mail and EZweb To use e-mail and EZweb, you need to apply for an EZweb subscription. If you did not apply for an EZweb subscription at the time of purchase, contact an au shop or the au Customer Service Center. Also, before use, be sure to configure initial settings.

[Page 22: Checking Your Phone Number And E-Mail Address.....20](#)

Checking Your Phone Number and E-mail Address When the standby screen is Limit Mode Voice Rec Smart Mode displayed, press @. Notepad Calendar Data Folder aThe Launcher menu appears. Calculator Alarm Profile Function Security EZnaviWalk Use E to select Profile and ...

[Page 23: Changing Your E-Mail Address.....21](#)

Changing Your E-mail Address You can change the account name part of the E-mail Address e-mail address as indicated to the right. $\Delta\Delta\Delta@ezweb.ne.jp$ Part you can change Domain name When the standby screen is $\square-\square\square\square\square\square\square\square\square$ displayed, press L and then ...

[Page 24](#) Changing Your E-mail Address (continued) Use G to select the entry $\square\square\square\square\square\square\square\square\square\square$ box, press @ (Edit), and $\square\square\square\square\square$ enter an e-mail address using $\square\square\square\square\square$ single-byte alphanumeric characters. For details on entering e-mail addresses, see page 39. Press @ (OK), use G to $\square\square\square\square\square\square\square$...

[Page 25: Using Extra Large Characters.....23](#)

Using Extra Large Characters Turning on extra large characters will display the names of callers and addressees on the Call Screen, the phone book list, etc. When the standby screen is Voice Rec Smart Mode Limit Mode displayed, press @. Calendar Notepad aThe Launcher menu appears.

[Page 26](#) Using Extra Large Characters (continued) Press 6 Extra Large. $\square\square\square\square\square\square\square\square$ aThe Extra Large setting screen appears. Use G to select ON and then press @ (OK).

[Page 27: Personal Identification Numbers And Passwords.....25](#)

Personal Identification Numbers and Passwords You can use the personal identification numbers and passwords described below to restrict use of your A5509T. Take care not to forget numbers and passwords, because they are required for performing various operations and using subscription services.

[Page 28: Making And Answering Calls](#)

Making and Answering Calls Making a Call When the standby screen is displayed, use 0 to 9 to enter the phone number you $\square\square\square\square\square\square\square\square$ want to call. When calling to a regular phone, you also need to enter the area code. Press Q.

[Page 29: Answering A Call.....27](#)

Answering a Call To answer the call, press Q. When you have finished the call, press S. Display When a Call is Received $\square\square\square\square\square\square$ The phone number of the caller appears. If the caller's name is in your phone book, the name is also displayed. ...

[Page 30: Redialing \(Outgoing History/Incoming History\).....28](#)

Redialing (Outgoing History/Incoming History) Example: Returning a call to a phone number in the incoming history When the standby screen is $\square\square\square\square\square\square\square\square\square\square$ $\square\square\square\square\square\square$ displayed, press $\square\square$ $\square\square\square\square\square\square$ $\square\square\square\square\square\square$ Pressing I while the standby screen $\square\square$ $\square\square\square\square\square\square$ $\square\square\square\square\square\square$ is displayed displays

Page 31: One-Ring Calls**29**

One-ring Calls What is a One-ring Call? A one-ring call is a call from an unknown caller that only rings once, causing it to be stored in the incoming history. One-ring calls are often used to get the receiver to return the call, which will connect you to a dating service or some other service that charges caller at high rates.

Page 32: Turning On Manner Mode**30**

Turning On Manner Mode The cell phone informs you of a call by vibrating. When the standby screen is displayed, hold down T (side key 2) for at least one second. This turns on manner mode, and ...

Page 33: Turning On Voice Memo**31**

Turning On Voice Memo When the standby screen is displayed, hold down R for at least one second. The answering message (Japanese) is played, then voice memo is turned on, which is indicated by on the standby screen.

Page 34: Playing A Voice Memo**32**

Playing a Voice Memo If a voice memo is recorded, Memo and the number of memos appear on the standby screen. Information ...

Page 35: Changing The Incoming Ring Tone**33**

Changing the Incoming Ring Tone When the standby screen is Limit Mode Voice Rec Smart Mode displayed, press @. Calendar Notepad Data Folder The Launcher menu appears. Calculator Alarm Profile Function EZnaviWalk Security Use E to select Function and ...

Page 36 Changing the Incoming Ring Tone (continued) Use G to select Fixed Pattern and then press @ (Select). The Fixed Pattern menu appears. Play Use G to select Pattern 3 ...

Page 37: Adjusting The Incoming Ring Tone Volume**35**

Adjusting the Incoming Ring Tone Volume When the standby screen is Voice Rec Limit Mode Smart Mode displayed, press @. Calendar Notepad Data Folder The Launcher menu appears. Alarm Profile Calculator Security Function EZnaviWalk Use E to select Function and ...

Page 38: Adjusting The Earpiece Volume During A Call**36**

Adjusting the Incoming Ring Tone Volume (continued) Use G to adjust the volume and then press @ (OK). Each press of G changes the volume one step. After a vibration alert, the ring tone sounds while gradually increasing in volume. STEP DOWN The ring tone sounds while gradually decreasing in volume.

Page 39: Character Input

Character Input Character Entry Modes When a character entry screen is displayed, you can select the character entry mode if you press J. Menu Items Kanji conversion mode Double-byte alphanumeric mode ...

Page 40 Entering Two or More Characters Assigned to the Same Key After you enter the first

character, press C to move the cursor (■) to the right and then enter the next character.
Example: Entering "ab" Press 2 once. Press C once.

[Page 41: Entering E-Mail](#)

[Addresses.....39](#)

- Two or more periods (.) cannot be used in succession. - Zero (0) cannot be used as the first character. How to Enter E-mail Addresses Use 1 to 0 to enter characters and numbers. Example: Entering "taro.23@toshiba.co.jp" for the recipient's e-mail address Enter "taro.23". ■■■■■■
■ ■■■■ ■■■ ■■■■■■■■...

Page 42 (continued) Entering E-mail Addresses Press J (abAB) and then ■■■■■■■■ ■■■■
■■■■■ press # ■■■■■■■■ Phrase. ■■■■■■■■ ■■■■■■ aThe category list appears. ■■■■■■■■
■■■■■■■ Use G to select Internet and ■■■■■■■■ ■■ ■■■■■■■■■■■■××××
■■ △△△△△■■■■■■■■■■ then press @ (Select). ■■ ■■■■■■■■■■■■...

[Page 43: Entering Pictograms](#)

[.....41](#)

Entering Pictograms When a character entry screen ■■■■ ■■■■■■■■■■ ■ is displayed, press J (abAB). ■■■■■■ ■■■■ ■ ■■ ■■■■ ■ ■■■■ aThe character entry mode menu appears. ■■ ■■■■■■ ■You can also enter symbols, emoticons, ■■■■...

[Page 44: Phone Book](#)

Phone Book Saving a Phone Book Entry New Screen ■■■■ Hold down K ■■■■
■■■■■ ■■■■ for at least one second. ■■
■■■■■ Use G to select (Name) ■■■■...

Page 45 Use G to select a phone ■■■■ ■■■■■■ ■■■■■■■■■■■■ number class and then press ■■■■■■■■■■■■ @ (Select). ■■ ■■■■■■ aThe New screen reappears. ■Follow the next two steps to enter an e-mail address. If you do not want to enter an e-mail address, proceed to Step 8.

[Page 46: Dialing From The Phone Book](#)

[.....44](#)

Dialing from the Phone Book When the standby screen is ■■■■■■■■■■ ■■ displayed, press K to display ■■ ■■ ■■ the phone book name list. ■■ ■■■■■■■■■■ ■■■■■■
Use E to select the entry ■■■ ■■■■■■ ■■■■■■ ■■■■■■■■■■■■ ■■■■
■■■■■■■■■■■■■■■■■■■■...

[Page 47: Editing Phone Book Entries](#)

[.....45](#)

Editing Phone Book Entries Select the entry you ■■■■■■■■■■ ■■■■ ■■■■■■ ■■■■■■
■■■■■■■■■■■■■■■■■■■■ want to edit, ■■ ■■■■■■■■■■ ■■ ■■■■
■■■■■■■■■■■■■■■■■■■■ press @ ■■ ■■ ■■■ ■■■■ ■■ (Select). ■■
■■■■■■■■■■■■■■■■■■■■ C-mail Select Option Press K (Option) and then ...

Page 48 Saving a Phone Number from the Incoming/Outgoing History Example: Saving a phone number from the incoming history to the phone book When the standby screen is ■■
■■■ ■■■■■■■■ ■■ ■■■■ ■■■■■■ displayed, press H and use ■■■■■■■■■■
■■ ■■■■ ■■■■■■ ■■■■ ■■■■■■ G to select the phone ■■ ■■■■ ■■■■■■.
..

[Page 49: Mail](#)

Mail Using E-mail To use e-mail, you need to apply for an EZweb subscription. If you did not apply for an EZweb subscription at the time of purchase, contact an au shop or the au Customer Service Center. Also, before use, be sure to configure initial settings.

[Page 50: Creating And Sending E-Mail Messages](#)

[.....48](#)

Creating and Sending E-mail Messages When the standby screen is ■■■■■■ ■■■■ ■■ displayed, press L and then ■■■■■■■■ ■■■■■■■■■■ ■■■■ press 1 Create New.

aThe Create Mail screen appears. Use G to select To and then ...

Page 51 Use G to select Subject and then press @ (Select).
aThe Subject entry screen appears. Enter a subject and then
press @ (OK).
...

Page 52 Creating and Sending E-mail Messages (continued) Press J (Send).
aThe Way of Send menu appears. Use G
to select Send and then press @ (Select). aThe animation for sending e-mail
is displayed and the e-mail message is ...

Page 53: Reading Received E-Mail Messages

Reading Received E-mail Messages When you receive an e-mail message
a" Email" appears on the standby screen along with the number of messages
received. Information ...

Page 54 Viewing a Received Message Message subject Time and date the
message was received. Message text
Sender of the message The e-mail address of
Name of attached file, if any the sender may appear ...

Page 55: Reading An E-Mail Message With An Attached Photo

Reading an E-mail Message with an Attached Photo Display the e-mail message (page 51).
Use G to select the file name
...

Page 56: Replying To Received E-Mail Messages

Replying to Received E-mail Messages When the standby screen is
displayed, press L and then press 2 Inbox. aThe Inbox opens.
Press @ (Select). ...

Page 57 Refer to "Creating and Sending E-mail Messages" (Steps 8 and 9 on page 49) and
the text of the message. Send Select Option Press J (Send). ...

Page 58: Rejecting Spam

Rejecting Spam The setting of mail filters to reject spam is recommended. Setting Mail Filters
Mail Filters Setting screen When the standby screen is displayed, press L. aPress 7 E-
mail Setup. aPress 3 Other Setup. ...

Page 59: Creating And Sending C-Mail Messages

Creating and Sending C-mail Messages When the standby screen is
displayed, hold down L for at least one second, and then press 1 Create
New. aThe Text entry screen appears. Enter the text of the message ...

Page 60: Reading Received C-Mail Messages

Reading Received C-mail Messages Received c-mail messages are saved to the Inbox. When
you receive a c-mail message a" Cmail" appears on the standby
screen along with the number of received messages. Information
...

[Page 61: Camera](#)

Camera Your cell phone has a mega pixel camera that you can use to shoot photos (snapshots) and movies. It also has a self-timer for taking photos. You can use images you record for the standby screen, and you can attach them to e-mail messages.

[Page 62: Photo And Movie Shooting Tips](#)

.....60

Photo and Movie Shooting Tips When shooting photos (snapshots) or movies, frame the subject within the display or sub display and hold the A5509T steady with both hands to avoid shaking. Taking a Photo Recording a Movie Photo Mail, Wallpaper, and Multiple Modes...

[Page 63: Data](#)

[Sizes](#).....
...61

Data Sizes The following shows the number of photos/movies you can capture in each mode when all photos/movies are captured in the same mode and the Data folder has the same amount of space as at the time of purchase. However, the following numbers may vary depending on photography/recording conditions.

[Page 64: Taking A Photo](#)

.....62

Taking a Photo When the standby screen is Monitor Screen displayed, press J. aThe monitor screen appears. To turn on the mobile light, press U (side key 1) while the monitor screen is ...

[Page 65: Recording A Movie](#)

.....63

Recording a Movie When the standby screen is Monitor Screen displayed, hold down J for at least one second. aThe monitor screen appears. To turn on the mobile light, press U (side key 1) while the ...

[Page 66](#) Note Note If you press) while the monitor screen is displayed, the key-operation guidance screen will appear for approximately 15 seconds. Movies are saved in the Movie Folder, which is located in the Data Folder. If you do not want to save the movie, press , use to select Yes, and then press...

[Page 67: Viewing Photos/Movies](#)

.....65

Viewing Photos/Movies Example: Viewing a photo When the standby screen is displayed, press J. aThe monitor screen appears. Shot Option Press K (Option) and then press # ...

[Page 68: Attaching Photos/Movies To E-Mail Messages](#)

.....66

Attaching Photos/Movies to E-mail Messages While the preview screen is displayed after shooting a photo or move, press J (E-mail). aThe photo or movie is attached to an e-mail message and the Create Mail screen appears. The (Attachment) indicator changes automatically to , indicating that an image has been attached.

[Page 69: Ezweb](#)

EZweb What is EZweb? EZweb is an information service that allows you to enjoy using the Internet on your cell phone. You can also download Chaku-Uta(TM), news, and other data from information web pages. To use e-mail and EZweb, you need to apply for an EZweb subscription. If you did not apply for an EZweb subscription at the time of purchase, contact an au shop or the au Customer Service Center.

[Page 70: Accessing Sites](#)

.....68

Accessing Sites Displaying the Top Menu MON

Use G to select Current Point, press @ (Select) to obtain the GPS information, and then press @ (OK). aYour current location is registered as your home. Looking Up the Way Home Using this feature makes it easy to navigate from your current location to the location indicated by GPS information you registered as your home using My Spot.

[Page 80: Limit Mode](#)

Limit Mode Limit Mode allows parents or superiors to impose limits on the how much each function can be used. This helps to prevent overuse of the cell phone by offspring or subordinates. Restrictions can be placed on incoming and outgoing calls, incoming and outgoing e-mail and c-mail, EZweb use, and EZ application (including EZnaviWalk) use.

Page 81 If you do not want to enter a hint, select No and then press @ (OK). Note Note For the hint, enter something that will help to remind you of the password. Example: Password :20050214 Hint :Day I bought A5509T...

[Page 82: Setting The Use Limit](#)

.....80

Setting the Use Limit You can configure the cell phone to prohibit outgoing calls and mail send if a monthly use limit amount is exceeded. On the Limit Mode screen (page 78), press 4 Limit ...

Page 83 Use G to select Use Limit and then press @ (Select). Use G to select Call and then press @ (Select).

[Page 84: Turning Limit Mode On And Off](#)

.....82

Turning Limit Mode On and Off On the Limit Mode screen (page 78), press 5 Limit . Cancel. Back Hint Enter the current Limit Mode password and then press ...

[Page 85: Checking The Limit Mode Status Of Use](#)

.....83

Checking the Limit Mode Status of Use On the Limit Mode screen (page 78), press 2 This . Last Mth Use. Use G to select Call and ...

[Page 86: Smart Mode](#)

Smart Mode Setting Smart Mode limits phone function, phone book, camera, mail, EZweb and other often-used functions, which keeps operation simple. Entering Smart Mode When the standby screen is Data Folder displayed, press @. Limit Mode Voice Rec Smart Mode aThe Launcher menu appears.

[Page 87: Exiting Smart Mode](#)

.....85

Exiting Smart Mode When the standby screen is Call displayed, press @. Camera Alarm aThe Launcher menu appears. Data Folder Mail Call One-touch Function My Number then press @ (Select).

[Page 88: Using The Smart Mode Launcher Menu](#)

.....86

Using the Smart Mode Launcher Menu The Smart Mode Launcher menu contains the following items. Call Phone Book Call Call Phone Book Camera Alarm Camera Alarm Alarm Camera Data Folder Mail Data Folder Mail Data Folder Mail Call...

Page 89 Indicator Function Name Description See: Volume Call ring tone setting – Melody Standby Screen Standby screen setting – Character Size Display character size setting – Function Manner Mode Normal manner mode setting – Function Voice memo setting/voice Memo – recorder recording Exit SmartMode Smart mode exit P.85...

[Page 90: Saving A Phone Book Entry Using Smart Mode](#)

.....88

Saving a Phone Book Entry Using Smart Mode When the standby screen is displayed, press K. Use G to select Yes and then press @ (OK). ...

Page 91 Use G to select Input and then press @ (Select). The e-mail address input screen appears. If you do not want to enter an e-mail address, press @ (OK) and advance to Step 8.

Page 92: One-Touch Phone Number Recording90

One-touch Phone Number Recording You can make up to three phone numbers one-touch numbers for quick and easy dialing. When the standby screen is displayed, press Q. The One-touch list appears. Select Edit Cancel Use G to select NO entry and ...

Page 93: One-Touch Dialing91

One-touch Dialing When the standby screen is displayed, press Q. The One-touch list appears. Use G to select the entry containing the phone number you want to dial and then ...

Page 94: Creating And Sending E-Mail/C-Mail Messages In Smart Mode92

Creating and Sending E-mail/C-mail Messages in Smart Mode Example : Creating and sending an e-mail message When the standby screen is displayed, press L. The Select Mail menu appears. Use G to select E-mail and ...

Page 95 Enter a subject and then press @ (OK). The Text entry screen appears. Enter the text of the message and then press @ (OK). ...

Page 96: Using The Camera In Smart Mode94

Using the Camera in Smart Mode Taking a Photo When the standby screen is displayed, press J. The Camera menu appears. Use G to select Take A Picture and then press @ (Select). ...

Page 97 Viewing a Photo When the standby screen is Call displayed, press @. Camera Alarm The Launcher menu appears. Data Folder Mail Call One-touch Function My Number Use E to select Data Folder and then press @ (Select).

Page 98: Other Functions96

Other Functions In addition to the functions covered in this Basic Manual, the A5509T also has the following features. Only Mail You can send a message with a movie or photo attachment to a specific recipient without opening the A5509T.

Page 99 (silent indicator) displayed on Increase the volume of the not play. incoming call ring tone. the standby screen? Cannot charge the Is the Toshiba AC adapter 02 Insert the adapter in the power outlet properly. battery pack. plugged into a power outlet?

Page 100 Index Enter39 Entering characters37
Accessories8 Entering characters from the same key 38 Adjusting earpiece volume36 Entering pictograms41 Antenna11 Extra large characters23 EZnaviWalk74 Current Mail75 Battery level11 Current Map74 Go Home74,77 Battery pack8,9,10 Going-Out Menu75 My

Spot75,76...

[Page 101](#) Photos65 Voice memo32 Mail C-mail
.....47 Power supply E-mail47 Turning off power
.....11 Manner mode30 Turning on power11 Movies
Attaching to e-mail66 Photo mail service66 Ring tones Recording
.....63 Changing the type.....33 Viewing65 Changing
the volume35 Signal11 Names of parts.....9...

[Page 102](#) "157" on your au cellphone. Sales: KDDI CORPORATION □ OKINAWA CELLULAR
TELEPHONE COMPANY Cellphone and PHS operators collect and Manufactured by: TOSHIBA
CORPORATION recycle unused telephones, batteries and battery chargers at stores bearing the
February 2005 Edition logo regardless of brand and manufacturer to protect the environment
and reuse valuable resources.