

Advanced Mode - Asus Rog Strix H370-I Gaming Manual

1
2
Table Of Contents
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89

•

[Table of Contents](#)

•

Bookmarks



3.2.2

Advanced Mode

The Advanced Mode provides advanced options for experienced end-users to configure the BIOS settings. The figure below shows an example of the Advanced Mode. Refer to the following sections for the detailed configurations.

To switch from EZ Mode to Advanced Mode, click Advanced Mode(F7) or press the <F7> hotkey.

Configuration fields

Pop-up Menu

Menu bar

Language

Menu items

3-4



MyFavorite(F3)
Qfan Control(F6)
Last modified settings
General help
Search(F9)
Scroll bar
EZ Tuning Wizard(F11)
Hot Keys
Go back to EZ Mode
Displays the CPU temperature,
CPU, and memory voltage output
Chapter 3: BIOS Setup
AURA ON/OFF(F4)
Search on the FAQ

[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

[1](#)
[...](#)
[53](#)
[54](#)
[55](#)
[56](#)
[57](#)
[58](#)
[59](#)
[60](#)

Quick Links:

[Motherboard Overview](#)

[Motherboard Layout](#)

[Jumpers and Holes](#)

[Onboard Leds](#)

[M.2 Installation](#)

Related Manuals for Asus Rog Strix H370-I Gaming

[Motherboard Asus ROG STRIX H370-F GAMING User Manual](#)

(96 pages)

[Motherboard Asus PRIME H370-PLUS Manual](#)

(36 pages)

[Motherboard Asus PRIME H370-PLUS Quick Start Manual](#)

(2 pages)

[Motherboard Asus PRIME B360-PLUS Manual](#)

(28 pages)

[Motherboard Asus TUF H370-PRO GAMING Manual](#)

(40 pages)

[Motherboard Asus PRIME H370-A Quick Start Manual](#)

(2 pages)

[Motherboard Asus PRIME H370-A Manual](#)

(36 pages)

[Motherboard Asus H370 MINING MASTER Manual](#)

(25 pages)

[Motherboard Asus PRIME H370M-PLUS User Manual](#)

(40 pages)

[Motherboard Asus PRIME H370M-PLUS Manual](#)

(40 pages)

[Motherboard Asus PRIME H310M-E Manual](#)

(28 pages)

[Motherboard Asus PRIME H310M-A R1.0 Instruction Manual](#)

(29 pages)

[Motherboard Asus PRIME H310M-C R2.0 Manual](#)

(28 pages)

[Motherboard Asus PRIME H310M-A R2.0 Manual](#)

(29 pages)

[Motherboard Asus PRIME H310M-E R2.0 Manual](#)

(28 pages)

[Motherboard Asus PRIME H310M-K R2.0 Manual](#)

(27 pages)

Related Content for Asus Rog Strix H370-I Gaming

[PRIME X570-PRO Advanced Mode](#)

Asus PRIME X570-PRO

[STRIX Z270F GAMING Advanced Mode](#)

Asus STRIX Z270F GAMING

[B450M-A/CSM Advanced Mode](#)

Asus B450M-A/CSM

[MAXIMUS VII HERO Advanced Mode](#)

Asus MAXIMUS VII HERO

[STRIX Z270H GAMING Advanced Mode](#)

Asus STRIX Z270H GAMING

[PRIME B250M-J Advanced Mode](#)

Asus PRIME B250M-J

[H110M-K X Advanced Mode](#)

Asus H110M-K X

[PRIME H310M-C/PS R2.0 Advanced Mode](#)

Asus PRIME H310M-C/PS R2.0