



Asus MyPal A620BT User Manual

1

2

3

4

Table Of Contents

5

6

7

8

9

10

11

12

13

14

15

16

17

--

•

•

Bookmarks

--

Quick Links

[Download this manual](#) See also: [User Manual](#)



MyPal A620BT

User's Manual

[Table of Contents](#)

[Next Page](#)

1
2
3
4
5

Related Manuals for Asus MyPal A620BT

[Handhelds Asus MyPal A620BT User Manual](#)

Asus mypal a620bt user's manual (156 pages)

[Handhelds Asus MyPal A716 Quick Start Manual](#)

Asus mypal a716: quick start (6 pages)

[Handhelds Asus MyPal A716 User Manual](#)

Asus mypal a716: user guide (166 pages)

[Handhelds Asus MyPal A716 Manual De L'utilisateur](#)

Asus mypal a716 french user guide (166 pages)

[Handhelds Asus MyPal A730 Handbook](#)

Asus mypal a730: user guide (204 pages)

[Handhelds Asus MyPal A730W Handbook](#)

Asus mypal a730w: user guide (218 pages)

[Handhelds Asus MyPal A730 User Manual](#)

(80 pages)

[Handhelds Asus MyPal A730W Quick Start Manual](#)

Asus mypal a730w: quick start (6 pages)

[Handhelds Asus MyPal A632 Quick Start Manual](#)

Asus gps receiver user manual (6 pages)

[Handhelds Asus MyPal A632 User Manual](#)

Asus mypal a632: user guide (104 pages)

[Handhelds Asus A626 - MyPal - Win Mobile 6.0 312 MHz User Manual](#)

Mypal pocket pc (109 pages)

[Handhelds Asus MyPal A632N User Manual](#)

Asustek computer user manual pocket pc (104 pages)

[Handhelds Asus MYPAL A639 User Manual](#)

User manual (106 pages)

[Handhelds Asus MyPal A600 User Manual](#)

Asustek computer inc. user's manual pocket pc mypal a600 (110 pages)

[Handhelds Asus MyPal A620 User Manual](#)

Asustek computer user's manual mypal a620 (136 pages)

[Handhelds Asus MyPal A620 User Manual](#)

User manual (136 pages)

Summary of Contents for Asus MyPal A620BT

[Page 1](#) MyPal A620BT User's Manual...

[Page 2](#) Product warranty or service will not be extended if: (1) the product is repaired, modified or altered, unless such repair, modification or alteration is authorized in writing by ASUS; or (2) the serial number of the product is defaced or missing.

[Page 3](#) • Chapter 2 - Learn the basics 2-1 This chapter will teach you the basic functions in MyPal A620BT. You will learn how to enter, find, and organize information, customize the device, and use the bundled ASUS utilities.

[Page 4](#) • CF GPRS card • User's Manual (UL/CEE/UK/SAA/CCEE) • Bluetooth dongle • Quick Start Guide • GPS mouse • Bluetooth GPS • Warranty card • Bluetooth earphone English version keyboard. Visit the ASUS website to check the availability of other language version keyboards.

[Page 5: Table Of Contents](#)

Chapter 1 Get started! ♦ ♦ ♦ ♦ ♦ Introducing MyPal1-2 Front features1-2 Left side features1-3 Top features1-4 Bottom features 1-4 Back features1-5 The stylus 1-5 The cradle1-6 ♦...

[Page 6: Introducing Mypal](#)

Backlight button Notes button Built-in microphone LCD touch screen Contacts button Calendar button ASUS Launcher button Tasks button Speaker Navigation button • Power/Backlight button - turns the device power on or off if you press the button quickly. Pressing and holding the button for a few seconds turns the backlight on or off.

[Page 7: Left Side Features](#)

The screen lumination is increased or decreased by changing the backlight settings. • ASUS Launcher, Calendar, Tasks, and Contacts buttons - allow you quick access to commonly used programs. • Navigation button - functions like the four arrow keys and the Enter key on a keyboard.

[Page 8: Top Features](#)

Top features Headphone jack CF card slot Stylus • Headphone jack - connects a headphone. • CF card slot - accommodates a CompactFlash (CF) card. See list of supported CF cards on page iv. • Stylus - used for tapping or writing on the LCD touch screen. Slide out the stylus from its compartment.

[Page 9: Back Features](#)

Back features CF card slot cover Reset switch • Reset switch - allows you to perform a soft reset in case the device malfunctions, or when an application hangs. Press the tip of the stylus on the switch to reset the system. •...

[Page 10: The Cradle](#)

The cradle The cradle has three connectors. • Device connector - holds the device in place. This is a 26-pin connector that matches the connector on the bottom of the device. • USB connector - synchronizes the device with your PC. NOTE The USB cable/connector is not detachable from the back of the cradle.

[Page 11: Setting Up Mypal](#)

Setting up MyPal Placing on the cradle Position the device on the cradle as shown. Match the connectors and carefully insert the device until it fits in place. Connecting the AC adapter • Connect the AC adapter cable to the connector at the back of the cradle. Connect the power plug to a grounded wall socket.

[Page 12: Installing And Removing A Cf Card](#)

The CF card slot on your device supports several types of CF card. Refer to the list of supported cards under "Optional Accessories" on page iv of this manual. Install a CF card for additional storage, or if you wish to use the ASUS backup features. To install a CF card: 1.

[Page 13](#) To remove a CF card: 1. Remove the CF card slot cover by pushing on the dent on the surface, and sliding the cover outward. Dent on the cover surface 2. Slide out the CF card. 3. Replace the cover back into the slot. Get started!

[Page 14: Charging The Battery](#)

Charging the battery Your device includes a rechargeable Lithium Ion battery. You must charge the battery before using the device the first time. The battery starts charging as soon as you connect the AC adapter to a power source. Use the AC adapter to plug your device to a power source whenever possible, especially when you are using a modem or other peripherals, using the device backlight,...

[Page 15: Basic Screens On Mypal](#)

Basic screens on MyPal Today screen Normally, the Today screen appears when you turn on your device for the first time each day. NOTE When the device is already on and the screen displays another program, you can display the Today screen by tapping the icon.

[Page 16: Start Menu](#)

Start menu From the Start menu, you can select programs, settings, and Help topics. To display the Start menu, tap the icon from the top of the screen. Tap to open a recently used program Tap to open a program Tap to open the Programs menu Tap to open the Settings menu Tap to display the Help topics...

[Page 17: Command Bar](#)

Command bar At the bottom of the screen is the Command bar. You can use the menus and buttons on the Command bar to perform tasks in programs. NOTE The menus and buttons vary depending on the programs you are using. Tap to select menu Tap to select Tap to display...

[Page 18](#) The pop-up menus are also available in most other programs in your device. The pop-up menu items vary depending on the program or application. For example, the File Explorer pop-up menu includes more items than in Tasks. Tap outside the pop-up menu to close it without performing an action Tap the action that you wish to perform Tap and hold until the pop-up menu appears...