



# **TOSHIBA**

Toshiba BookPlace MONO Setup Manual



1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16

• PAGE

1

---

- 

[Table of Contents](#)

•

Bookmarks

--

[Download this manual](#)

### Quick Links





# Setup guide



Thank you for purchasing this product.

Keep the warranty and manuals in a safe place where you can

use them when needed.

Before using the product, read the "Safe

---

operation and  
support guide" supplement.

Electronic book reader

GX1C00XXXXXX 2012.12 Printed in China

©2012 Toshiba Corporation All rights reserved.

**TOSHIBA**  
**Leading Innovation >>>**

## BookPlace MONO

[Table of Contents](#)

[Next Page](#)

1  
2  
3  
4  
5

# Summary of Contents for Toshiba BookPlace MONO

[Page 1](#) Thank you for purchasing this product. Keep the warranty and manuals in a safe place where you can use them when needed. Before using the product, read the "Safe operation and support guide" supplement. GX1C000XXXXX 2012.12 Printed in China ©2012 Toshiba Corporation All rights reserved.

[Page 2](#) Introduction What you need to get started • Wireless LAN environment You need an environment in which you can connect to the internet by Wi-Fi (wireless LAN environment) to use the product. If you do not have access to a wireless LAN environment, refer to "Create a wireless LAN environment"...

## [Page 3: Entering Text](#)

You can type text the same as on a computer keyboard. 10-key You can type text the same as on a mobile phone. Typing text (using QWERTY) Example : Typing "toshiba" 1. Tap to change the character input mode to 2. Type t, o, s, h, i, b, and a.

## [Page 4: Getting Ready](#)

Check the accessories, model number, and serial number • Check the accessories About the accessories See the "Welcome to the BookPlace MONO Series Electronic Book Reader" pamphlet • Check the model number and the serial number The model number and serial number are written on the side of the product.

[Page 5](#) Connect to a computer to charge the battery Use the power cord provided to connect to a USB connector on a computer. Charging starts automatically. ① ② Power cord Side with hooks is up Insert straight into the product You can use the product while it is charging. Continue charging until you have finished the initial settings.

[Page 6](#) Turn on the power Note Do not touch the screen as you turn on the power. If you are touching the screen while turning on the power, the touch panel may stop operating normally. Press the power button for two seconds The logo screen appears after a few seconds.

[Page 7](#) Do the initial settings Follow the on-screen instructions to do the initial settings. Memo After turning on the power, if no operations are done for a while the screen turns off and goes dark. Briefly touch the power button to turn the screen on.

[Page 8](#) For automatic set up (WPS) (If the wireless LAN access point you are using has the WPS mark (supports Wi-Fi Protected Setup™)). 1. Tap [Automatic set up (WPS)] 2. Press and hold the wireless LAN access point's WPS button until the access point's lamp starts to flash Do it within two minutes after the [WPS Settings] screen appears.

[Page 9](#) If the date and time are correct, tap [Next] \* If the date and time are not correct, tap to adjust them. Do the [Book Place] settings Using "Book Place" for the first time 1. Tap [Register as a member for free now] 2.

[Page 10](#) 3. Tap [Confirm information that was entered] \* If the step 4 screen does not appear, there is an error in the text field in which the cursor is. Check the explanation on the screen, and enter the information again. 4.

[Page 11](#) To customers without access to wireless LAN Create a wireless LAN environment You need an environment in which you can connect to the internet by Wi-Fi to use the product. This is because you need to communicate with digital book stores on the internet to purchase digital books.

## [Page 12: Contact Information](#)

\* Current as of December 2012. The business hours and conditions for each company may be different. About initial settings, operations, setting procedures, and repairs Toshiba (Toshiba PC support center) 0120-97-1048 Domestic phone line: (telephone access and support are free) The automated answering service will handle your call.

[Page 13](#) About the product's wireless LAN function Overview of the wireless LAN function ■

The product is equipped with a wireless LAN function that supports all or some of the following standards IEEE 802.11b, IEEE 802.11g, and IEEE 802.11n. • Wireless LAN function specifications  
Radio IEEE 802.11b, frequency...

[Page 14](#) ■ Characteristics of wireless communications There is a correlative relationship between the communication range and transmission rate of wireless devices. The lower the transmission rate of the wireless communications, the broader the communication range. Memo The range of communications of a wireless device is affected if the antenna is placed near a ●...

[Page 15](#) However, the broadcast energy has been suppressed to levels that are much lower than mobile telephones or other radio devices. Toshiba assures that the wireless LAN component built into this device can be used safely in accordance with the guidelines of the radio frequency safety standards and recommendations.

### [Page 16: Fcc Statement](#)

FCC Statement This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by party responsible for compliance could void the user's authority to operate the equipment.