



# Asus EeeKeyboard PC EK1542 User Manual



1
2
Table Of Contents
3
4
5
6
7
8
9
10
11
12
13
14
15
16

--	--

•

[Table of Contents](#)


•

Bookmarks

--

[Download this manual](#)

### Quick Links





F5  
F6  
F7  
F2  
F3  
F4  
F1  
ESC

2  
3  
4  
5

Q  
W  
R  
E  
T  
V  
A  
S  
D  
F  
G  
Z  
X  
C  
V

**ASUS®**


*EeeKeyboard*

# ASUS® EK1542

## User Manual

### *EeeKeyboard*

easy to learn , work and p



F12  
F8  
F11  
F9  
F10  
Prt Sc  
SysRq  
7  
7  
8  
8  
9  
9  
0  
-  
/  
U  
I  
P  
O  
{  
4  
5  
6  
I  
H  
:  
J  
K  
L  
-  
1  
2  
;  
3  
-  
N  
M  
<  
>  
?  
,  
0  
.  
/  
Ctrl  
Delete  
Insert  
Scr LK  
Num LK  
}  
Home  
]  
PgUp  
Enter  
End  
PgDn  
Pause  
Break

15xxxxxxxxx

[Table of Contents](#)

[Next Page](#)

1  
2  
3  
4  
5

## Related Manuals for Asus EeeKeyboard PC EK1542

### [Keyboard Asus EK1542 User Manual](#)

User manual (48 pages)

### [Keyboard Asus Strix Tactic Pro User Manual](#)

(14 pages)

### [Keyboard Asus Cerberus User Manual](#)

Led baklit usb gaming keyboard (7 pages)

### [Keyboard Asus Cerberus User Manual](#)

Multi-color backlit gaming keyboard (8 pages)

### [Asus ROG STRIX SCOPE RX - Mechanical Gaming Keyboard Quick Start](#)

(article)

### [Asus ROG Strix Scope RX TKL Wireless Deluxe Quick Start Guide](#)

(article)

### [Keyboard Asus Cerberus Quick Start Manual](#)

Mechanical rgb keyboard (48 pages)

### [Keyboard Asus GK1100 Quick Start Manual](#)

Mechanical keyboard (2 pages)

### [Asus TUF GAMING K5 - Mechanical Gaming Keyboard Quick Start Guide](#)

(article)

### [Keyboard Asus Cerberus MKII User Manual](#)

Multi-color backlit gaming keyboard (8 pages)

### [Keyboard Asus ROG STRIX SCOPE TKL Quick Start Manual](#)

(3 pages)

### [Keyboard Asus GK1050 User Manual](#)

(21 pages)

### [Keyboard Asus ROD STRIX SCOPE TKL GUNDAM LTD Quick Start Manual](#)

(2 pages)

### [Keyboard Asus CERBERUS Quick Start Manual](#)

Led baklit usb gaming keyboard (46 pages)

### [Keyboard Asus TUF GAMING K1 Quick Start Manual](#)

Membrane gaming keyboard (4 pages)

### [Keyboard Asus CERBERUS Quick Start Manual](#)

Multi-color backlit gaming keyboard mkii (48 pages)

## Summary of Contents for Asus EeeKeyboard PC EK1542

[Page 1](#) Delete Prt Sc Insert SysRq Scr LK Num LK Home PgUp “ Enter ‘ PgDn < > Pause Break  
Ctrl EK1542 User Manual 15xxxxxxxx...

### [Page 2: Notices](#)

Product warranty or service will not be extended if: (1) the product is repaired, modified or altered, unless such repair, modification or alteration is authorized in writing by ASUS; or (2) the

serial number of the product is defaced or missing.

### [Page 3: Table Of Contents](#)

Turning the battery ON/OFF .....1-6 Charging the battery .....1-7 Starting up .....1-8  
Turning your EKB PC ON/OFF .....1-9 Turning your EKB PC ON .....1-9 Managing power usage  
.....1-10 Changing the power mode ..... 1-10 ASUS EeeKeyboard PC...

[Page 4](#) Connecting devices .....1-11 Connecting an external monitor ..... 1-11 Connecting  
a projector .....1-13 Connecting an HDTV ..... 1-14 Setting up your UWB connection ....1-15  
Connecting an external monitor wirelessly.....1-17 Connecting two external monitors ....1-18  
Connecting a USB mouse .....1-19 Connecting an external ODD .....

[Page 5](#) Wired connection .....3-1 Connecting to a wireless network ....3-7 Using Bluetooth®  
..... 3-8 Setting up the basic Bluetooth environment ..... 3-8 Adding Bluetooth devices  
.....3-12 Appendices Notices ..... 4-1 ASUS Contact information .....4-7 ASUS  
EeeKeyboard PC...

### [Page 6: About This Manual](#)

About this manual This user manual contains the information you need in using your EKB PC  
and connecting other devices to it. How this user manual is organized Chapter 1: Getting  
started Provides information on getting started with the EKB PC. Chapter 2: Using your EKB PC  
Provides information on using the EKB PC.

### [Page 7: Safety Information](#)

DO NOT throw the EKB exposure. PC in municipal waste. Check local regulations DO NOT  
expose to for disposal of electronic strong magnetic or products. electrical fields. DO NOT  
expose to or use near liquids, rain, or moisture. ASUS EeeKeyboard PC...

[Page 8](#) Transportation Precautions To prepare your EKB PC for transport, follow these  
guidelines: • Turn OFF the EKB PC and disconnect all external peripherals to prevent damage to  
the connectors. • Put your EKB PC in a carrying case to protect it from dirt, water, shock, and  
scratches.

[Page 9](#) You can send your EKB PC and discs through airport X-ray machines. However, we  
recommend that you do not send your EKB PC or discs through airport magnetic detectors or  
expose them to magnetic wands. ASUS EeeKeyboard PC...

### [Page 10: Ek1542 Specifications Summary](#)

EK1542 Specifications summary Display 5" , 800 x 480 Touch Panel OS support Windows® XP  
Home edition Intel® Atom N270 Chipset 945GSE / ICH7-M Memory Onboard DDR2 1GB Storage  
16GB / 32GB SSD Video decoder Broadcom AV-VD904 Onboard 10/100/1000Mbps Wireless  
video transfer Ultra-Wideband (UWB) technology Wireless standards Wi-Fi 802.11b/g/n and  
Bluetooth V2.1...

### [Page 11: Package Contents](#)

Wireless antenna \* UWB AC adapter (Wi-Fi+UWB\*) \* UWB or Ultra Wideband technology allows  
wireless connection to devices within five to ten meter range. If any of the above items is  
damaged or missing, contact your retailer. ASUS EeeKeyboard PC...

### [Page 12: Chapter 1: Getting Started](#)

Chapter 1 Getting started Proper posture when using your EKB PC Maintaining the proper  
posture is necessary to prevent strain to your wrists, hands, and other joints or muscles. This  
section provides you with tips on avoiding physical discomfort and possible injury while using  
and fully enjoying your EeeKeyboard PC (EKB PC).

### [Page 13: Using Peripherals](#)

Using peripherals If you intend to use your EKB PC for a long time: • Connect an external  
monitor for a larger external display. • Use an external mouse. Position the external mouse  
within easy reach. For more details on connecting an external monitor or other devices, refer to  
the chapter Getting your EKB PC ready in this user manual.

[Page 14](#) Storage device indicator: Indicates the storage device status. • Solid white: Storage device is accessed. • Blinking white: Reading/writing to/from storage device. 5" Touch Panel Lightly touch the screen to navigate through the various features and functions of the EKB PC. ASUS EeeKeyboard PC...

### [Page 15: Additional Features](#)

Additional features Stylus Use the stylus to navigate around the touch panel. Wireless antenna ports (Wi-Fi + Ultra Wideband) Insert the bundled wireless receiver into these ports. USB 2.0 ports Insert USB devices such as PDAs, scanners, printers, cameras, and storage devices, into these ports. Air vents The air vents allow cool air to enter and warm air to exit the EKB PC.

[Page 16](#) Ultra Wideband indicator: Indicates that there is an active Ultra Wideband connection. • Solid white: Ultra Wideband receiver is connected to the EKB PC. • Blinking white: Ultra Wideband connection is active. Power indicator: Indicates that the Ultra Wideband receiver is turned on. ASUS EeeKeyboard PC...