



# Hardware And System Checklist - Toshiba A200 Series User Manual

Toshiba portable personal computer user's manual



1  
2  
3  
4  
5  
6  
7  
8  
9


Table Of Contents

10  
11  
12  
13  
14  
15  
16  
17

18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67

68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92  
93  
94  
95  
96  
97  
98  
99  
100  
101  
102  
103  
104  
105  
106  
107  
108  
109  
110  
111  
112  
113  
114  
115  
116  
117

118  
119  
120  
121  
122  
123  
124  
125  
126  
127  
128  
129  
130  
131  
132  
133  
134  
135  
136  
137  
138  
139  
140  
141  
142  
143  
144  
145  
146  
147  
148  
149  
150  
151  
152  
153  
154



•

[Table of Contents](#)



- 

Troubleshooting

•

## Bookmarks





Record your observations so you can describe them to your dealer.

## Software

### Hardware

Record your observations so you can describe the

## Hardware and system checklist

### Software

This section discusses problems caused by your computer's hardware or attached peripherals. Basic problems may occur in the following areas.

### System start-up

n

### Self test

The problems may be caused if you cannot load a software package or the software may be damaged or corrupted. Try loading another software package.

If an error message appears when you load a software package, check the software documentation. These documents contain a problem solving section.

Power		Record your observations so you can describe the
Battery	<b>Software</b>	The problems may be caused by software. If you cannot load a software package, the media may be damaged or the program might be corrupted. Try loading another copy of the software.
Keyboard		If an error message appears while you are using a software package, check the software documentation. These documents usually include a problem solving section or a summary of error messages.
LCD panel		Next, check any error messages in the operating system documentation.
Hard disk drive	<b>Hardware</b>	If you cannot find a software solution, check the hardware. First run through the preliminary checklist about the hardware. To correct the problem, try to replace the hardware. The next section provides checklists for the hardware components and peripherals.
Password		
i.LINK (IEEE1394)		
Wireless LAN		
Monitor		
Sound system		

## Hardware and system checklist

User's Manual	This section discusses problems caused by your computer and attached peripherals. Basic problems may occur in the following areas:	
The problems may be caused by your software. If you cannot load a software package, the media may be damaged or the program might be corrupted. Try loading another copy of the software.	<ul style="list-style-type: none"> <li>■ System start-up</li> <li>■ Self test</li> <li>■ Power</li> <li>■ Battery</li> <li>■ Keyboard</li> <li>■ LCD panel</li> <li>■ Hard disk drive</li> <li>■ Password</li> <li>■ i.LINK (IEEE1394)</li> <li>■ Wireless LAN</li> </ul>	<ul style="list-style-type: none"> <li>■ Pointing device</li> <li>■ USB</li> <li>■ TV output</li> <li>■ LAN</li> <li>■ Sleep/Hibernate</li> <li>■ Memory card</li> <li>■ Modem</li> <li>■ CD-RW/DVD drive</li> <li>■ DVD SuperMulti double layer</li> </ul>

If you cannot find a software problem, check your hardware. First run through the items in the preliminary checklist above. If you still cannot correct the problem, try to identify the source. The next section provides checklists for individual components and peripherals.

Pointing Device

n

USB

n

TV output signal

n

LAN

n

Sleep/Hibernation

n

Memory expansion

n

Modem

n

CD-RW/DVD-ROM drive

n

DVD Super Multi drive with

n

double layer disc recording

support

Disk drive

n

Real Time Clock

n

Troubleshooting

9-3

Record your observations so you can describe the

### Software

The problems may be caused by software. If you cannot load a software package, the software may be damaged or the package may be corrupted. Try loading another software package.

If an error message appears when you load a software package, check the software documentation. These documents contain a problem solving section with error messages.

Next, check any error messages in the system documentation.

### Hardware

If you cannot find a software problem, check your hardware. First run through the preliminary checklist above. If you still cannot correct the problem, try to identify the source. The next section provides checklists for individual components and peripherals.

## Hardware and system checklist

This section discusses problems caused by your computer and attached peripherals. Basic problems may occur in the following areas:

- System start-up
- Self test
- Power
- Battery
- Keyboard
- LCD panel
- Hard disk drive
- Password
- Pointing Device
- USB
- TV output signal
- LAN
- Sleep/Hibernation
- Memory expansion
- Modem
- CD-RW/DVD-ROM drive

[Previous Page](#)  
[Next Page](#)



1

...

116

117

118

119

## Related Manuals for Toshiba A200 Series

[Laptop Toshiba PORTEGE A200 series Maintenance Manual](#)

Personal computer (342 pages)

[Laptop Toshiba A205-S5800 User Manual](#)

A205-s5800 user's guide (245 pages)

[Laptop Toshiba Satellite A205 Series User Manual](#)

(244 pages)

[Laptop Toshiba Satellite A200 User Manual](#)

Portable personal computer (232 pages)

[Laptop TOSHIBA Satellite A200 Series User Manual](#)

Toshiba notebook computer (227 pages)

[Laptop TOSHIBA Satellite A200 Series User Manual](#)

Toshiba satellite a200/satellite pro a200 series portable personal computer (222 pages)

[Laptop Toshiba A200 series User Manual](#)

(194 pages)

[Laptop Toshiba Satellite A200 series User Manual](#)

(188 pages)

[Laptop Toshiba SATELLITE A200 Maintenance Manual](#)

Personal computer (186 pages)

[Laptop Toshiba A200 Series User Manual](#)

Portable personal computer (154 pages)

[Laptop Toshiba Satellite A205-S4577 Resource Manual](#)

Toshiba satellite a205-s4577: reference guide (56 pages)

[Laptop Toshiba Satellite A200-0MD00X Resource Manual](#)

Toshiba satellite a200-0md00x: reference guide (52 pages)

[Laptop Toshiba Satellite A200-ST2041 Series Specifications](#)

Toshiba satellite a200-st2041: specifications (8 pages)

[Desktop Toshiba Satellite A300 Maintenance Manual](#)

(263 pages)

[Desktop Toshiba Tecra A3 Maintenance Manual](#)

Personal computer (202 pages)

[Desktop Toshiba Satellite M45 Maintenance Manual](#)

Personal computer (284 pages)

## Related Content for Toshiba A200 Series

[Qosmio PX30t Series Hardware And System Checklist](#)

Toshiba Qosmio PX30t Series

[DX1210 series Hardware And System Checklist](#)

Toshiba DX1210 series

[Stratagy 4 Setting Up Stratagy System Hardware](#)

Toshiba Stratagy 4

[T100 System](#)

Toshiba T100

[HX-10 Connecting To An Audio System](#)

Toshiba HX-10

[EQUIUM M40 Chapter 1 Hardware Overview](#)

Toshiba EQUIUM M40

[HX-10 Connecting To An Audio System](#)

Toshiba HX-10

[PORTEGE R300 Chapter 1 Hardware Overview](#)

Toshiba PORTEGE R300

This manual is also suitable for:

[Psaf4u-00l004Satellite a200-st2041](#)