

Connecting Your Computer To A Network - Toshiba PORTEGE R700 SERIES User Manual

Toshiba computer drive user manual

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22
23
24
25
26
27
28
Table Of Contents
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117

118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167

168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217

218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246

--

•

[Table of Contents](#)

•

Bookmarks



136

Exploring Your Computer's Features

Setting up for communications

For information on how to set up a wireless connection, refer to your wireless networking device documentation or your network administrator.

NOTE

NOTE

For help with common Wi-Fi networking problems" on page

Connecting your computer to a network

You can connect your computer to a network to increase its capabilities and functionality using one of its communication ports.

Accessing a network

To access a network, connect an Ethernet cable to the Network port (RJ45) on your computer. For specific information about connecting to the network, consult your network administrator.

Many hotels, airports, and offices offer Wi-Fi computer has Wi-Fi

®

Wi-Fi

Setting up the connection

To set up an office connection, consult your network administrator

for network settings and additional considerations.

To set up a dial-up connection, use the Connect to the Internet wizard:

1

Click Start, Control Panel, Network and Internet, and then under Internet Options, click Connect to the Internet.

2

Click Dial-up.

3

Enter the phone number and account information of your Internet connection.

4

Click Connect and let the program dial the number.
The computer connects to the Internet.

To enable or disable wireless communication, use the Hot Key

. For more information see

Fn + F8

[page](#)

207.

When the Wireless antenna is ON, the wireless indicator light
be lit.

®

, ask them for help when connecting to their
network.

["Hot Keys/TOSHIBA Cards" on](#)

®

networking problems, see

195.

["Wireless](#)

®

access. If your

will

[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1

...

135

136

137

138

Quick Links:

[Your Computer's Features and Specifications](#)

[Adding Memory \(Optional\)](#)

Related Manuals for Toshiba PORTEGE R700 SERIES

[Laptop Toshiba PORTÉGÉ R700 Series Maintenance Manual](#)

Personal computer (474 pages)

[Laptop Toshiba TECRA R700 User Manual](#)

(198 pages)

[Laptop Toshiba Portege R700 User Manual](#)

Toshiba laptop user manual (191 pages)

[Laptop Toshiba PSLD8U-01601E User Manual](#)

User manual (165 pages)

[Laptop Toshiba Portege R700-S1320 Specifications](#)

Toshiba portege r700-s1320: specifications (4 pages)

[Laptop Toshiba Portege R700-S1321 Specifications](#)

Toshiba portege r700-s1321: specifications (4 pages)

[Laptop Toshiba Portege R700-S1322 Specifications](#)

Toshiba portege r700-s1322: specifications (4 pages)

[Laptop Toshiba Portege R700-S1332 Specifications](#)

Toshiba portege r700-s1332: specifications (4 pages)

[Laptop Toshiba Portege R700-ST1303 Specifications](#)

Toshiba portege r700-st1303: specifications (4 pages)

[Laptop Toshiba Portege R705-P35 Specifications](#)

Toshiba portege r705-p35: specifications (4 pages)

[Laptop Toshiba Portege R705-ST2N03 Specifications](#)

Toshiba portege r705-st2n03: specifications (4 pages)

[Laptop Toshiba Portege R705-ST2N04 Specifications](#)

Toshiba portege r705-st2n04: specifications (4 pages)

[Laptop Toshiba Portege R700-S1310 Specifications](#)

Toshiba portege r700-s1310: specifications (4 pages)

[Laptop Toshiba Portege R700-S1311 Specifications](#)

Toshiba portege r700-s1311: specifications (4 pages)

[Laptop Toshiba Portege R700-S1312 Specifications](#)

Toshiba portege r700-s1312: specifications (4 pages)

[Laptop Toshiba Portege R705-P42 Specifications](#)

Toshiba portege r705-p42: specifications (3 pages)

Related Content for Toshiba PORTEGE R700 SERIES

[satellite fusion 15 series Connecting Your Computer To A Network](#)

Toshiba satellite fusion 15 series

[Satellite CL10 Series Connecting Your Computer To A Network](#)

Toshiba Satellite CL10 Series

[Satellite S70-B Series Connecting Your Computer To A Network](#)

Toshiba Satellite S70-B Series

[Satellite CL40 Series Connecting Your Computer To A Network](#)

Toshiba Satellite CL40 Series

[Satellite E40-A Connecting Your Computer To A Network](#)

Toshiba Satellite E40-A

[Portege 2010 Connecting Your Computer To A Network](#)

Toshiba Portege 2010

[Satellite A35 Series Connecting Your Computer To A Network](#)

Toshiba Satellite A35 Series

[C50 Series Connecting Your Computer To A Network](#)

Toshiba C50 Series

This manual is also suitable for:

[R700-s1310R700-s1311R700-s1312R700-s1320R700-s1321R700-s1322](#) ... [Show all](#)