



# Display Brightness - Toshiba PORTEGE R700 SERIES User Manual

Toshiba computer drive user manual



1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18

19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
Table Of Contents  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67

68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92  
93  
94  
95  
96  
97  
98  
99  
100  
101  
102  
103  
104  
105  
106  
107  
108  
109  
110  
111  
112  
113  
114  
115  
116  
117

118  
119  
120  
121  
122  
123  
124  
125  
126  
127  
128  
129  
130  
131  
132  
133  
134  
135  
136  
137  
138  
139  
140  
141  
142  
143  
144  
145  
146  
147  
148  
149  
150  
151  
152  
153  
154  
155  
156  
157  
158  
159  
160  
161  
162  
163  
164  
165  
166  
167

168  
169  
170  
171  
172  
173  
174  
175  
176  
177  
178  
179  
180  
181  
182  
183  
184  
185  
186  
187  
188  
189  
190  
191  
192  
193  
194  
195  
196  
197  
198  
199  
200  
201  
202  
203  
204  
205  
206  
207  
208  
209  
210  
211  
212  
213  
214  
215  
216  
217



218  
219  
220  
221  
222  
223  
224  
225  
226  
227  
228  
229  
230  
231  
232  
233  
234  
235  
236  
237  
238  
239  
240  
241  
242  
243  
244  
245  
246

--

•

[Table of Contents](#)

•

## Bookmarks





## NOTE

### **Display brightness**

---

Fn +

Fn +

Cycle through the display modes, then select the desired mode.

Not all functions are supported on all models.

Some systems also support an additional Swap Image Display mode. This mode is available only if the current setting is an

extended desktop mode (Built-in Display and External Monitor, or Built-in Display and TV). In extended desktop mode, the image is split into two sides, one side per display device. To swap sides, select Swap Image Display.

This TOSHIBA Card decreases or increases the screen brightness.

This hot key decreases the screen brightness.

This hot key increases the screen brightness.

Selecting this Card or pressing either hot key displays the following options:

*(Sample Image) Display brightness*

Move the slider or press the appropriate hot key repeatedly to decrease or increase the display brightness.

**Hot Keys/TOSHIBA Cards**

*Hot key functions*

# 217

[Table of Contents](#)

[Previous Page](#)  
[Next Page](#)



1

...

216

217

218

219

Quick Links:

[Your Computer's Features and Specifications](#)

[Adding Memory \(Optional\)](#)

## Related Manuals for Toshiba PORTEGE R700 SERIES

[Laptop Toshiba PORTÉGÉ R700 Series Maintenance Manual](#)

Personal computer (474 pages)

[Laptop Toshiba TECRA R700 User Manual](#)

(198 pages)

[Laptop Toshiba Portege R700 User Manual](#)

Toshiba laptop user manual (191 pages)

[Laptop Toshiba PSLD8U-01601E User Manual](#)

User manual (165 pages)

[Laptop Toshiba Portege R700-S1320 Specifications](#)

Toshiba portege r700-s1320: specifications (4 pages)

[Laptop Toshiba Portege R700-S1321 Specifications](#)

Toshiba portege r700-s1321: specifications (4 pages)

[Laptop Toshiba Portege R700-S1322 Specifications](#)

Toshiba portege r700-s1322: specifications (4 pages)

[Laptop Toshiba Portege R700-S1332 Specifications](#)

Toshiba portege r700-s1332: specifications (4 pages)

[Laptop Toshiba Portege R700-ST1303 Specifications](#)

Toshiba portege r700-st1303: specifications (4 pages)

[Laptop Toshiba Portege R705-P35 Specifications](#)

Toshiba portege r705-p35: specifications (4 pages)

[Laptop Toshiba Portege R705-ST2N03 Specifications](#)

Toshiba portege r705-st2n03: specifications (4 pages)

[Laptop Toshiba Portege R705-ST2N04 Specifications](#)

Toshiba portege r705-st2n04: specifications (4 pages)

[Laptop Toshiba Portege R700-S1310 Specifications](#)

Toshiba portege r700-s1310: specifications (4 pages)

[Laptop Toshiba Portege R700-S1311 Specifications](#)

Toshiba portege r700-s1311: specifications (4 pages)

[Laptop Toshiba Portege R700-S1312 Specifications](#)

Toshiba portege r700-s1312: specifications (4 pages)

[Laptop Toshiba Portege R705-P42 Specifications](#)

Toshiba portege r705-p42: specifications (3 pages)

## Related Content for Toshiba PORTEGE R700 SERIES

[satellite fusion 15 series Display Brightness](#)

Toshiba satellite fusion 15 series

[Satellite CL10 Series Display Brightness](#)

Toshiba Satellite CL10 Series

[Portege Z20-B Series Display Brightness](#)

Toshiba Portege Z20-B Series

[Satellite S70-B Series Display Brightness](#)

Toshiba Satellite S70-B Series

[Satellite Click 2 PRO Display Brightness](#)

Toshiba Satellite Click 2 PRO

[Satellite CL40 Series Display Brightness](#)

Toshiba Satellite CL40 Series

[Satellite E40-A Display Brightness](#)

Toshiba Satellite E40-A

[Portege 2010 Display Brightness](#)

Toshiba Portege 2010

This manual is also suitable for:

[R700-s1310R700-s1311R700-s1312R700-s1320R700-s1321R700-s1322](#) ... [Show all](#)