




Asus E15906 User Manual

1
2
3
4
5
6
7
8
9
10
11
12
Table Of Contents
13



•

[Table of Contents](#)

•


Bookmarks

Quick Links

[1 Getting Started](#)

[2 Service and Support](#)

[Download this manual](#)



E15906

Revised Edition V3 / October 2019

User Guide

E15906_P1440F_UM_V3_12pages.indd 1

2019/10/15

05:29:10



HDMI™
HIGH DEFINITION MULTIMEDIA INTERFACE



Table of Contents

[Next Page](#)

1
2
3
4
5

Related Manuals for Asus E15906

[Laptop Asus E15695 User Manual](#)

(17 pages)

[Laptop Asus E15162 Manual](#)

(102 pages)

[Laptop Asus E15729 E-Manual](#)

(94 pages)

[Laptop Asus E15630 Manual](#)

(110 pages)

[Laptop Asus E15025 Manual](#)

(86 pages)

[Laptop Asus Eee PC 1015 Series User Manual](#)

(58 pages)

[Laptop Asus E1916 Hardware User Manual](#)

Asustek computer notebook pc user's manual (72 pages)

[Laptop Asus E10229 User Manual](#)

Z stylus (28 pages)

[Laptop Asus E10745 E-Manual](#)

(98 pages)

[Laptop Asus VivoBook E12 E-Manual](#)

(94 pages)

[Laptop Asus E11226 E-Manual](#)

(102 pages)

[Laptop Asus E10295 Manual](#)

(118 pages)

[Laptop Asus E14902 E-Manual](#)

(96 pages)

[Laptop Asus E11966 E-Manual](#)

(110 pages)

[Laptop Asus E13480 Manual](#)

(104 pages)

[Laptop Asus E16099 E-Manual](#)

(92 pages)

Summary of Contents for Asus E15906

[Page 1](#) E15906 Revised Edition V3 / October 2019 User Guide
E15906_P1440F_UM_V3_12pages.indd 1 2019/10/15 05:29:10...

[Page 2: Top View](#)

Top View NOTE: The keyboard's layout may vary per region or country. The top view may also vary in appearance depending on the Notebook PC model. Camera Camera indicator
Microphone Display panel Power button Keyboard Fingerprint sensor Touchpad
Bluetooth/Wireless indicator Capital lock indicator Optical drive Optical drive Optical disk drive
eject button...

[Page 3: Getting Started](#)

I/O ports and slots Status indicators USB 2.0 port VGA port Headphone/Headset jack HDMI port Kensington® security slot LAN port Power (DC) input port USB 3.1 Gen 1 port Memory card reader Getting started 1. Charge your Notebook PC A. Connect the AC power cord to the AC/DC adapter. B.

[Page 4](#) SKU. • Power adapter information: - Input voltage: 100-240Vac - Input frequency: 50-60Hz - Rating output current: 3.42A (65W) - Rating output voltage: 19V WARNING! Read the following precautions for your Notebook PC's battery: • Only ASUS-authorized technicians should • Never attempt to short-circuit your remove the battery inside the device Notebook PC's battery. (for non-removable battery only). • Never attempt to disassemble and • The battery used in this device may present reassemble the battery a risk of fire or chemical burn if removed or (for non-removable battery only).

[Page 5: Avis Concernant Les Batteries Remplaçables](#)

Warranty Statement, up to the listed contract price of each product. ASUS will only be responsible for or indemnify you for loss, damages or claims based in contract, tort or infringement under this Warranty Statement.

[Page 6: Coating Notice](#)

FCC Radio Frequency (RF) Exposure Caution Statement WARNING! Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. To maintain compliance with FCC RF exposure compliance requirements, please avoid direct contact to the transmitting antenna during transmitting. End users must follow the specific operating instructions for satisfying RF exposure compliance. UL Safety Notices • DO NOT use the Notebook PC near water, for example, near a bath tub, wash bowl, kitchen sink or laundry tub, in a wet basement or near a swimming pool.

[Page 7: India Rohs](#)

ASUS follows the green design concept to design and manufacture our products, and makes sure that each stage of the product life cycle of ASUS product is in line with global environmental regulations. In addition, ASUS disclose the relevant information based on regulation requirements.

[Page 8: Ecodesign Directive](#)

CSR website. Further information could be found at <https://csr.asus.com/english/article.aspx?id=1555>. EPEAT Registered Products The public disclosure of key environmental information for ASUS EPEAT (Electronic Product Environmental Assessment Tool) registered products is available at <https://csr.asus.com/english/article.aspx?id=41>. More information about EPEAT program and purchase guidance can be found at www.epeat.net.

[Page 9: Optical Drive Safety Information](#)

For your safety, contact a professional technician for assistance. Simplified EU Declaration of Conformity ASUSTek Computer Inc. hereby declares that this device is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. Full text of EU declaration of conformity is available at <https://www.asus.com/support/>. The WiFi operating in the band 5150-5350 MHz shall be restricted to indoor use for countries listed in the table below: Notebook PC User Guide E15906_P1440F_UM_V3_12pages.indd 9...

[Page 10: Federal Communications Commission Interference Statement](#)

• Reorient or relocate the receiving antenna. • Increase the separation between the equipment and receiver. • Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. • Consult the dealer or an experienced radio/TV technician for help. FCC COMPLIANCE INFORMATION Per FCC Part 2 Section 2.1077 Asus Computer International Responsible Party: Address: 48720 Kato Rd., Fremont CA 94538 Phone/Fax No: (510)739-3777/(510)608-4555 hereby declares that the product Product Name :...

[Page 11: Red Rf Output Table](#)

RED RF Output table CB231NF Function Frequency Maximum Output Power (EIRP) 2412 - 2472

MHz 15 dBm WiFi 5150 - 5350 MHz 16 dBm 5470 - 5725 MHz 15 dBm Bluetooth 2402 - 2480
MHz 3 dBm INTEL9560NGW Function Frequency Maximum Output Power (EIRP) 2412 - 2472
MHz 16 dBm 5150 - 5350 MHz 18 dBm WiFi 5470 - 5725 MHz 17 dBm 5725 - 5850 MHz 8 dBm...

[Page 12](#) Notebook PC User Guide E15906_P1440F_UM_V3_12pages.indd 12 2019/10/15
05:29:12...

This manual is also suitable for:

[X512jaX512jf](#)