

TOSHIBA

Toshiba B-EP700-BLTH-QM-R Installation Manual

Bluetooth module

1
2
3
4
5
6
7
8

--

•

Bookmarks

[Download this manual](#)

Quick Links



TOSHIBA Bluetooth Module

TOSHIBA B-EP700-BLTH-QM-R Installation Manual

Thank you for purchasing TOSHIBA Bluetooth module, B-EP700-BLTH-QM-R.

The B-EP700-BLTH-QM-R is an optional Bluetooth module for the B-EP2DL/EP4DL Series.

The pictures used in this document are those of the B-EP4DL, but the installation procedure is common with the

B-EP2DL unless otherwise noted.

1. Follow all manual instructions. Failure to do so could create safety hazards such as fire or electrocution.

- Manual instructions must be followed when installing option kits or adding cables to avoid system

failures and to insure proper performance and operation.

• Failure to follow manual instructions or any unauthorized modifications, substitution or change to this product will void the limited product warranty.



2. Turn the power off and remove the battery before installing the Bluetooth module.
3. Be careful not to pinch your fingers or hands with the covers.

1. PACKING LIST

The following parts are supplied with the kit. Make sure you have all items shown below.

- Bluetooth Module (1 pc.)
- Installation Manual (1 copy)
- Standard Label (1 pc.)

WARNING!

FPC Cable

For B-EP4DL Series (1pc.)

Connected to
Bluetooth module

For B-EP2DL Series (1pc.)

Connected to
Bluetooth module

1/8

EO2-38061

Connected to

Main PCB

Connected to

Main PCB

[Next Page](#)

1
2
3
4
5

Related Manuals for Toshiba B-EP700-BLTH-QM-R

[Control Unit Toshiba BMS-SM1280HTLE Installation Manual](#)

(24 pages)

[Control Unit Toshiba BMS-SM1280HTLE Owner's Manual](#)

Smart manager (12 pages)

[Control Unit Toshiba B-FV904T-H-QM-R Installation Manual](#)

(3 pages)

[Control Unit Toshiba B-EX906-H-QM-R Manual](#)

Peel-off module with backing paper coiling-round structure (13 pages)

[Control Unit Toshiba B-EX700-WLAN2-QM-R Manual](#)

Wireless lan board (9 pages)

[Control Unit Toshiba B-EX206-QM-R Manual](#)

Disc cutter module (12 pages)

[Control Unit Toshiba B-EX906-FF-QM-R Installation Manual](#)

Fanfold paper guide module (2 pages)

[Control Unit Toshiba B-8204-QM-R Installation Manual](#)

Rotary cutter module (22 pages)

[Control Unit Toshiba 3 axis TB6560 User Manual](#)

Driver board (10 pages)

[Control Unit Toshiba GN-4030-A3 Quick Start Manual](#)

Multifunctional digital color systems / multifunctional digital systems wireless lan/bluetooth (6 pages)

[Control Unit Toshiba nv Series User Manual](#)

Type1 light profibus-dp module (70 pages)

[Control Unit Toshiba GN-4020 Manual](#)

Wireless lan/bluetooth precautions for use (12 pages)

[Control Unit Toshiba RBM-A101VAE Installation Manual](#)

Vrf dx valve kit (53 pages)

[Control Unit Toshiba Smart Manager Engineering Book](#)

(106 pages)

[Control Unit Toshiba RBM-SV1121HUPE Installation Manual](#)

Shut-off valve unit (14 pages)

[Control Unit Toshiba Adjustable Speed Drive H7 Series Specification](#)

Adjustable speed drives (8 pages)

Summary of Contents for Toshiba B-EP700-BLTH-QM-R

[Page 1](#) B-EP700-BLTH-QM-R Installation Manual Thank you for purchasing TOSHIBA Bluetooth module, B-EP700-BLTH-QM-R. The B-EP700-BLTH-QM-R is an optional Bluetooth module for the B-EP2DL/EP4DL Series. The pictures used in this document are those of the B-EP4DL, but the installation procedure is common with the B-EP2DL unless otherwise noted.

[Page 2: Installation Procedure](#)

2. INSTALLATION PROCEDURE Step 1. Turn off the printer. Step 2. Slide the battery lever in the direction of the arrow, and remove the battery pack from the printer. Step 3. Remove the four

tapping screws from the bottom cover. T-3x10 Tapping Screw Battery Lever...

[Page 3](#) Step 6. Remove the right side cover and the front cover in the direction of the arrow, respectively. Right Side Cover Front Cover Step 7. Connect the FPC cable to the Bluetooth module in the correct orientation. Two FPC cables are supplied with the Bluetooth module. One is designed for the B-EP2DL series, and the other is for the B-EP4DL series.

[Page 4](#) Step9. Fit the Bluetooth module into the following position. Pass the FPC cable as shown below so that they do not get caught on the gears or by the cover. B-EP2DL B-EP4DL FPC Cable FPC Cable Bluetooth Module Bluetooth Module Step10.

[Page 5](#) Step11. Mount the left side cover to the printer while fitting the tabs on the left side cover into the slots of the printer enclosure. Place the cables avoiding the protrusions on the left side cover. Especially, be careful of the protrusion E on the cover for the B-EP2DL series. B-EP4DL Series: Fit the tabs A to D into the slots A'...

[Page 6](#) Step12. Mount the right side cover to the printer while fitting the tabs on the right side cover into the slots of the printer enclosure. B-EP4DL Series: Fit the tabs A to C into the slots A' to C'. Tab C Tab B Tab A C'...

[Page 7](#) For Europe for Bluetooth Hereby, TOSHIBA TEC CORPORATION, declares that the TEC-BTM-R is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. This equipment uses a radio frequency band that has not been harmonized throughout all EU and EFTA countries, and can be used in EU and EFTA countries.

[Page 8](#) TOSHIBA TEC sales agent. Do not disassemble, modify, or repair the product. Doing so may cause injury. Also, modification is against the Laws and Regulations for Radio Equipment. Please ask your TOSHIBA TEC sales agent for repair. Precaution in use This product communicates with other devices by radio.