

Overview Of Steps For Installing, Setting Up, And Using Your New Tv; Black - Toshiba 42HPX95 Owner's Manual

Integrated high definition plasma television

1

2

3

4

5

Table Of Contents

6

7

8

9

10

11

12

13

14

15


16

17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117

118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138



•

[Table of Contents](#)

-

Troubleshooting

•

Bookmarks



Overview of steps for installing, setting up, and using your new TV

Follow these steps to set up your TV and begin using its many exciting features.

1. Carefully read the important safety, installation, care, and service information on pages 2-5. **Keep this manual for future reference.**

2. Observe the following when choosing a location for the TV:

- Place the TV on the floor or a sturdy, level, stable surface that can support the weight of the unit. Secure the TV to a wall, pillar, or other immovable structure as described on page 3, item 19.

- Place the TV in a location where light does not reflect on the screen.

- Place the TV far enough from walls and other objects to allow proper ventilation. Inadequate ventilation may cause overheating, which will damage the TV. THIS TYPE OF DAMAGE IS NOT COVERED UNDER THE TOSHIBA WARRANTY.

- Read "Installation" on pages 3-4.

- Read "Important notes about your Plasma TV" on page 5.

3. Do not plug in any power cords until AFTER you have connected all cables and devices to your TV.

4. BEFORE connecting cables or devices to the TV, learn **the functions of the TV's connections and controls (pages 10-12).**

5. **Connect** your other electronic device(s) to the TV (pages 14-30).

6. Connect the G-LINK™ cable (either one of the enclosed IR blaster cables) from your VCR and/or Cable box (if applicable) to the G-LINK™ terminal so you can use the TV Guide On Screen™ features (applies to VCRs and cable boxes only). See page 28.

7. Install the batteries in the remote control (page 33).

8. See "Learning about the remote control" (pages 31-32) **for an overview of the buttons on the remote control.**

9. Program the remote control to operate your other **device(s) (pages 33-39).**

#01E_008-009_4250HPX95

9

Black

(E) 42/50HPX95 *web 213:276

Chapter 1: Introduction

10. AFTER connecting all cables and devices, plug in the **power cords for your TV and other devices.**

"Now Booting..." will be displayed on the screen until the picture appears or the green LED will blink until the TV goes into standby mode.

When the TV is in standby mode, press POWER on the TV side panel or remote control to turn on the TV.

If the TV stops responding to the controls on the remote control or TV side panel and you cannot turn the TV off or on, press and hold the POWER button for 5 or more seconds to reset the TV.

11. See "Menu layout and navigation" for a quick overview **of navigating the TV's menu system (pages 40-41).**

12. See Chapter 5 for details on setting up the TV Guide **On Screen™ system (if available in your area).**

13. See Chapter 7 for details on using the TV Guide **On Screen™ program guide (if available in your area).**

14. Program channels into the TV's channel memory (page 47).

15. Set up the TheaterNet™ on-screen device control **feature (if applicable to your particular home theater system components) (page 50).**

16. For details on using the memory card JPEG picture **viewer and MP3 audio player, see page 102.**

17. For details on using the TV's features, see Chapter 8.

18. For help, refer to the Troubleshooting Guide (Chapter **12).**

19. For technical specifications and warranty information, **see Chapter 13.**

20. Enjoy your new TV!

Note: If you sell or transfer this television to a third party, be sure to reset the PIN code as described on page 98 under the heading,

"If you cannot remember your PIN code. "

Copyright © 2005 TOSHIBA CORPORATION. All rights reserved.

05.9.12, 10:16 PM

9

Table of Contents

[Previous Page](#)
[Next Page](#)

1
...
6
7
8
9
10
11
12
13

Troubleshooting

[Chapter 12: Troubleshooting](#) 121

[Home network troubleshooting](#) 124

Related Manuals for Toshiba 42HPX95

[TV Toshiba 42HPX95 Owner's Manual](#)

Integrated hd plasma tv (144 pages)

[Plasma TV Toshiba 50HPX95 Owner's Manual](#)

Integrated high definition plasma television (126 pages)

[Plasma TV Toshiba 42HPX95 Service Manual](#)

(61 pages)

[TV Toshiba 42HPX95 Service Manual](#)

Plasma color television (21 pages)

[Plasma TV Toshiba 42HP66 - 42" Plasma TV Manuel Du Propriétaire](#)

Owner's manual - french (52 pages)

[50HPX95 Overview Of Steps For Installing, Setting Up, And Using Your New Tv](#)

Toshiba 50HPX95

[42HP95 Overview Of Steps For Installing, Setting Up, And Using Your New Tv](#)

Toshiba 42HP95

[42HP86 Features Of Your New Tv](#)

Toshiba 42HP86

[42HP66 Exploring Your New Tv](#)

TOSHIBA 42HP66

[42HPX84 Exploring Your New Tv](#)

Toshiba 42HPX84

[50HP16 Features Of Your New Tv](#)

Toshiba 50HP16

[42HP66 - 42" Plasma TV Explorando Su Nueva Tv](#)

Toshiba 42HP66 - 42" Plasma TV

- [Flat Panel Television Saving Your New Preferences](#)

Toshiba Flat Panel Television

This manual is also suitable for:

[50hpx95](#)

